
Getting started with the Sigfox S2-LP kit

Introduction

The [STSW-S2LP-SFX-DK](#) is an evaluation SW package for Sigfox networking with the [S2-LP](#) high performance, ultra-low power RF transceiver. It is designed to operate in the majority of radio configuration zones (RCZ) described by Sigfox.

The STSW-S2LP-SFX-DK SW package supports the STEVAL-FKI868V1, [STEVAL-FKI868V2](#), [STEVAL-FKI915V1](#) and the [X-NUCLEO-S2868A1](#) kit platforms.

In addition, the package includes the support for the STEVAL-IDB007V2 and STEVAL-IDB008V2 kits to be used in conjunction with the shields included in the above mentioned kits. The latter solution enables the support for BlueNRG1/2 System-on-Chip alternatively to the STM32 microcontroller.

It provides an S2-LP Sigfox library with a complete set of APIs to develop embedded applications.

The S2-LP - Sigfox Demo GUI PC application provides an interactive interface to transmit messages to the Sigfox network and program the STEVAL-FKI nodes with the Sigfox ID to set the node for network communication.

For details regarding the BlueNRG-1 hardware and software development kit, refer to STSW-BLUENRG1/2-DK.

1 Sigfox S2-LP kit content

The package includes:

- the Sigfox Demo GUI and corresponding firmware to:
 - prepare the board with ID/PAC/Key from the pool assigned to ST devices (see [Section 4 Demo description](#))
 - run a demo that transmits user defined messages to the Sigfox network (see [Section 5 Push button demo description](#))
- a framework to develop embedded Sigfox-enabled applications, with examples in the source code.
- an application note which describes the Sigfox firmware framework based on the [S2-LP](#) transceiver and on both STM32 MCU and BlueNRG1/2 SoC, with guidelines on how to develop solutions that are optimized for power.
- a tool and related software APIs to store Sigfox credentials and manufacturing calibration values (frequency offset and RSSI), in a secure way, into the MCU internal Flash.

2 Requirements

2.1 Hardware requirements

A Windows® PC with:

- 2 USB ports
- 125 MB free hard disk space

At least one of the following ST evaluation kits:

- [STEVAL-FKI868V2](#) (and [STEVAL-FKI868V1](#)) (for RCZ1 and RCZ3) kit with:
 1. [STEVAL-FKI868V2](#) (and [STEVAL-FKI868V1](#)) evaluation board featuring the [S2-LP](#) sub-1 GHz (860-940 MHz) ultra-low power low data-rate transceiver
 2. STM32 Nucleo-64 development board or [STEVAL-IDB007V2/IDB008V2](#) board
- [STEVAL-FKI915V1](#) (for RCZ2 and RCZ4)
 1. [STEVAL-FKI915V1](#) evaluation board based on the [S2-LP](#) sub-1 GHz (860-940 MHz) ultra-low power low data-rate transceiver, with external power amplifier
 2. STM32 Nucleo-64 development board or [STEVAL-IDB007V2/IDB008V2](#) board

2.2 Software prerequisites

- Microsoft Windows 7 or later
- Adobe Acrobat Reader 6.0 or later

One of the following integrated development environments (to develop embedded sigfox-enabled applications):

1. IAR EWARM 8.22.1 or later
2. Keil MDK-ARM µVision 5.17 or later


3 Board registration

3.1 ST-side registration

This registration procedure need only be performed once via the ST GUI.

- Step 1.** Connect the STM32 Nucleo-64 development board to a PC via USB
Windows should automatically recognise the board as a hard drive

Figure 1. NUCLEO disk drive




- Step 2.** Flash the development board by simply dragging the appropriate bin file (in the Binary folder) to the NODE drive.
Choose the bin file according to your STM32 Nucleo-64 development board:
- SIGFOX_CLI_DEMO_NUCLEO_XX.bin

Table 1. Sigfox radio configuration zone

Frequency range	Zone	RC
862-876	1 - EMAEI	RC1
902-928	2 - APAC1 (Americas)	RC2, 4
	3 - APAC2 (Japan and South Korea)	RC3a, RC3c, RC5


- Step 3.** Open the ST Sigfox GUI and open the COM port associated with the STM32 Nucleo-64 development board.

Figure 2. Sigfox Demo GUI main window



- Step 4.** Click on the Open button.
If the board does not contain Sigfox data, a Board Preparation wizard appears.

Figure 3. ST Registration procedure 1/3



- Step 5.** Click the Next button
You will be prompted to complete a short form with your:
- name
 - company name
 - e-mail address
 - radio configuration zone (RCZ) number

Note: You must specify the correct RCZ to avoid generating an incorrect ID.

Figure 4. ST Registration procedure 2/3

Board Preparation

Registration procedure 2/3

Please fill the following form with the requested info and click the Generate mail button:

User Name:

Company:

User E-Mail:

RCZ: (hover the mouse pointer on the RCZ box to see the associated list of countries)

Insert here below the activation string that will be provided to You by mail:

- Step 6.** Click on the Generate mail button
A window appears with the e-mail data you need to send.

Figure 5. Generated mail pop-up

Generated Mail

Please send the following e-mail

Destination Address:

Subject:

Body:

SigFox license request
User name: aaa
User company: bbb
User email: xxx.yyy@zzz.com
Board model: STEVAL-FKI868V1
RCZ: 1
Node Code: 868'868868'868'868'868868868'868868'868'

This email has been generated by ST-SIGFOX_DEMO_GUI

- Step 7.** Send an email with the Destination Address, Subject and e-mail text shown in the popup window.
You will receive an answer (at the e-mail address you specified previously) with an activation string.
- Step 8.** Paste the activation string you receive in the text box and click Next.

Figure 6. ST Registration procedure 3/3

Step 9. If the activation string is correct, the board is programmed with the Sigfox account data and the ID and PAC is shown on the final page.

The board is now ready and you can register the board in its own Sigfox backend.

3.2 Sigfox side registration

Visit <https://buy.sigfox.com/activate> for ST development kit registration.

- Step 1.** Insert the country where the board should operate the ID and PAC of the board.
- Step 2.** Then fill a form to obtain an account on the sigfox backend.
An e-mail will be sent to the specified e-mail address.
- Step 3.** Choose a password and sign in to its own backend from <https://backend.sigfox.com>.
- Step 4.** Go to the DEVICE section.
This section provides a list of registered devices and other data.

Figure 7. Sigfox device page

Average Rssi	Average SNR	Communication status	Device type	Id	Last seen	Name	Activation date
[Signal Icon]	11.7	[Status Icon]	STMicroelectronics ST HR	20F65A	2018-06-06 09:06:10	Device 20F65A	2018-03-07 14:09:26
[Signal Icon]		[Status Icon]	STMicroelectronics ST HR	4D79C1	N/A	Device 4D79C1	N/A

Step 5. Click on the device ID to access a node summary page:

Figure 8. Sigfox device information

Device 20F65A - Information

Name: Device 20F65A
Protocol: V1
Activable state: ☒
Last seen:
Product certificate:
Latitude: 0.000 (degrees)
Longitude: 0.000 (degrees)
Device type: STMicroelectronics ST kit
Average SNR : 19.79 dB
Average RSSI : -129.01 dBm
State: OK
Communication status: ☐
Contract: Free eval board contract2
Activation date: 2018-03-07 14:49:26
Token validity: 2020-03-07
Subscription automatic renewal status: Not allowed
Subscription automatic renewal: ☐
Creation date: 2018-03-07 14:49:02
Created by:
Last edition date:
Last edited by:

MODEM CERTIFICATE **PRODUCT CERTIFICATE**

Certification id:
Modem manufacturer: ST_MICRO_DEV_MAKER
Modem name: S2-LP_NUCLEO-L152RE
Modem version: -
Radio Configurations: RC1
Modes: Downlink

Step 6. Click on messages to show a list of all sent messages.
For each message, the following information is shown:

- the date and time
- the data in hex (so if the transmission occurred with the S2-LP Sigfox GUI, the data should be the transmitted message in hex)
- the location of the node (link to a map)
- a link quality indicator (SNR bar)

Figure 9. Sigfox device messages

Device 20F65A - Messages

From date:
To date:

page 1

Time	Data / Decoding	Location	Link quality	Callbacks
2018-06-06 09:06:10	506c8f67746f68			
2018-06-06 08:49:31	00000003			
2018-06-06 08:49:13	00000002			
2018-06-06 08:48:52	00000001			
2018-06-06 08:47:42	00000002			
2018-06-06 08:47:26	00000001			
2018-06-06 08:41:32	00000001			
2018-06-05 13:13:29	00000001			
2018-06-05 08:33:14	00000007			

4 Demo description


The demo can run either on a kit connected to a PC running the Sigfox Demo GUI (Section 4.1 Sigfox Demo GUI), or on a kit supplied via USB in standalone mode (Section 4.2 Demo without connection to a PC).

4.1 Sigfox Demo GUI

After board registration, you can transmit messages using the GUI.


- Step 1.** Connect the STM32 Nucleo-64 development board to a PC via USB.
- Step 2.** Ensure jumper JP1 (near the USB connector) is open so the PC to assign a COM port to it. LEDs LD1 and LD3 on the board should both be lit.

Figure 10. JP1 position on STM32 Nucleo board



- Step 3.** Launch the Sigfox Demo GUI on your PC

Figure 11. Sigfox Demo GUI main window




- Step 4.** Click on the TX button to transmit data.
- In adherence with protocol, the frame is repeated three times with a 500 ms interval; the duration of each frame is shown in the Frame duration box.
- The frames received by the base-stations are shown in the DEVICE > Messages section of the sigfox backend.

Note: The maximum length of a message is 12 bytes, as per the sigfox protocol.

- Step 5.** Check the Ask for response checkbox and then click TX again.
- The message is sent with a response request and the transmission is followed by a reception phase of up to 50 s. The received message is shown in the Messages section of the GUI.
- Step 6.** To set the response for each device from the sigfox backend, log-in, go to the DEVICE TYPE tab and click on the device type description.

Figure 12. Sigfox DEVICE TYPE tab



- Step 7.** Click Edit to change the Downlink data parameters.

Figure 13. Sigfox DEVICE TYPE parameters

Step 8. Check the uC goes to low power checkbox to set the microcontroller in low power mode during radio transactions.

4.1.1 Sigfox Demo GUI menu items

The File menu can be used to access the Demo firmware and Sigfox library version information. For radio configuration zones 2 and 4, there is also the Set Std Configuration option described in [Section 4.3.3 node_set_std_config command description](#). The Help menu provides GUI version information.

4.2 Demo without connection to a PC

In this mode, the board is not connected to a PC


- Step 1.** Close jumper JP1 in [Figure 10. JP1 position on STM32 Nucleo board](#). This allows the STM32 to execute the firmware program without being enumerated to a USB host device. LED LD1 will blink and LD3 will remain lit.
- Step 2.** Press the blue button repeatedly. The node transmits a 32-bit counter to the network representing the number of times this button has been pressed since the last reset.

4.3 Using the command line

The SIGFOX_CLI_DEMO_NUCLEO firmware lets send simple commands using a serial terminal.

- Step 1.** Open the COM port with a baudrate of 115200
A simple command shell opens.
- Step 2.** Press the reset button.
The STM32 Nucleo board resets and a string containing ID and PAC in hex format is printed.

Figure 14. Command line terminal box



- Step 3.** Type help.
A list of all commands is shown.

Figure 15. Command line function list

```
ID: 0020F653 - PAC: D202961D46388CC8
help
help List commands

fw_version Get fw version

reboot reboots the uC

node_close close the library

node_reset reset the library

node_open open the library

node_get_info

node_get_version

node_send_frame buu send a frame

node_set_std_config wwwv

node_get_std_config

set_low_power u low power is used only in the radio phases

get_id ID of the current node

get_pac PAC of the current node

get_rcz RCZ of the current node

switch_public_key u

node_reduce_power u

node_test_mode uu enter a specified test mode

get_lib_version u Get version of specified module. 0=Sigfox, 1=MCU_API, 2=RF_API, 5=MONARCH_API, 6=DEVICE_CONFIG_API

VENDOR_set_payload_encryption u

VENDOR_set_frequency_offset w

VENDOR_set_rssi_offset w

VENDOR_get_rssi_offset

>
```

4.3.1 Command line function description

Table 2. Available command line functions

NAME	ARGUMENTS	DESCRIPTION
fw_version	None	Return the firmware version
get_id	None	Return the sigfox ID of the board
get_pac	None	Return the sigfox PAC of the board
get_rcz	None	Return the RCZ
node_open	None	Open the sigfox library Must be called before performing any send operation
node_close	None	Close the sigfox library
node_send_frame	list-of-bytes: must be enclosed between { } brackets and represented in hex without spaces. tx_repetitions: integer require_downlink: integer	See Section 4.3.2 node_send_frame command description
node_set_std_config	conf_word0,conf_word1, conf_word2 : 3 conf words of 32bits each default_sigfox_channel can be from 1 to 82	Set the standard channel configuration. This function is only for RCZ2 and 4. See Section 4.3.3 node_set_std_config command description

NAME	ARGUMENTS	DESCRIPTION
node_reset	None	Reset the sigfox library state
node_reduce_power	reduction: the reduction factor in 0.5 dB (approx) = reduction argument * 0.5 dB	Reduces the output power of the transmitted signal by a factor.
set_low_power	1: enable_low_power (default) 0: disable_low_power	Enable or disable microcontroller low power mode during transmission and reception operations
switch_public_key	1: switch to the public key 0: use the key of this specific node.	The public key is [00, 11, 22, ... , FF]
reboot	None	Reboot the device
node_get_version	None	Returns the version of the Sigfox Library
node_get_std_config	None	Returns the standard channel configuration in memory
node_test_mode	RCZ: integer Test_Mode: integer	Executes a specified test mode
get_lib_version	Lib_ID: Integer 0=Sigfox 1=MCU_API 2=RF_API 5=MONARCH_API 6=DEVICE_CONFIG_API	Get version of specified module.
VENDOR_set_payload_encryption	1: enable payload encryption 0: disable payload encryption	Enables payload encryption
VENDOR_set_frequency_offset	Offset: real	Overrides default offset calibration
VENDOR_set_rssi_offset	Offset: real	Set RSSI calibration value
VENDOR_get_rssi_offset	None	Returns the last RSSI offset in memory
node_send_bit	Bit to send: 1 or 0 Number of repetition: integer	Send a single bit n times
node_open_with_zone	RCZ: integer	Open Sigfox Library with a specified RC zone (see Table 7. Sigfox RC zones)
switch_test_credentials	1: Enable test credentials 0: Disable test credentials	Enable credentials to be used during Sigfox verified tests

4.3.2 node_send_frame command description

To send a frame, call the `node_open` command and then the `node_send` command specifying the following parameters:

- The list of bytes to be transmitted: given as a hexadecimal string (12 bytes max.).
- tx_repetitions:
 - If `require_downlink` is set, the frame is sent tx_repetitions + 1 times (tx_repetitions ≤ 2)
 - If `initiate_downlink_flag` is not set, tx_repetitions is forced to 2.
- require_downlink: Request a downlink frame from the base-station and wait for reception.

Note: *The behavior of the node is different in uplink (require_downlink=0) and downlink (require_downlink=1).*

The following procedures are initiated in the different cases:

- uplink :

- Send uplink frames (3)

```
Command example: node_send_frame {012345} 0 0
```

```
Command response: {(node_send_frame)} API call...{sfx_error:00}
```

- downlink :
 - Send uplink frames (1 to 3)
 - Receive downlink frame
 - Send out of band frame (Voltage, temperature and RSSI)

```
Command example: node_send_frame {012345} 2 1
```

```
Command response: {(node_send_frame)} API call...{sfx_error:00}
```

```
{customer_resp: 0x00,0x00,0x00,0x50,0x6C,0x75,0x74,0x6F}}
```

4.3.3 node_set_std_config command description

FCC allows the transmitters to choose different macro channels to implement a frequency hopping pattern allowed by the standard. These macro channels can be chosen through three 32-bit configuration words.

Each bit of the `config_words[0,1,2]` array represents a macro channel according to the following mapping:

Table 3. Macro channel mapping - config_words[0]

Macro Ch.	1	2	3	4	5	6	7	...	32
Frequency (MHz)	902.2	902.5	902.8	903.1	903.4	903.7	904.0	...	911.5
config_words[0] bit	0	1	2	3	4	5	6	...	31

Table 4. Macro channel mapping - config_words[1]

Macro Ch.	33	34	35	36	37	38	39	...	64
Frequency (MHz)	911.8	912.1	912.4	912.7	913.0	913.3	913.6	...	921.1
config_words[1] bit	0	1	2	3	4	5	6	...	31

Table 5. Macro channel mapping - config_words[2]

Macro Ch.	65	66	67	68	69	70	71	...	86
Frequency (MHz)	921.4	921.7	922.0	922.3	922.6	922.9	923.2	...	927.7
config_words[2] bit	0	1	2	3	4	5	6	...	21

A macro channel is only enabled when the corresponding `config_words[]` bit is set to 1. At least 9 macro channels must be enabled to meet the FCC specifications.

The last argument is an integer representing the `sigfox_default_channel`. It should be set as follows:

- For RCZ2, the operational frequency should be 902.2MHz and the default channel is 1.
- For RCZ4, it is necessary to keep the 902.2 MHz frequency in the open function but, since the sigfox operational channel is at 920.8MHz, we need to set the default channel to 63.

By default the GUI uses the following `std_config`:

Table 6. Default STD config

Parameter	RCZ2	RCZ4
config_words[0]	0x000001FF	0x00000000
config_words[1]	0x00000000	0xF0000000
config_words[2]	0x00000000	0x00001F
sigfox_default_channel	1	63

Note: This command is ineffective for RCZ1.

5 Push button demo description

This is an ST-Sigfox demo showing how to use the Sigfox protocol for a message to a base station each time the blue button on the STM32 Nucleo board , or the button 2 of the STEVAL-IDB007V2/STEVAL-IDB008V2 board, is pressed. The data sent is a number representing the number of times the button has been pressed since the last boot sequence.

If something goes wrong during initialization, the green LED on the STM32 Nucleo board or the red ILED on the STEVAL-IDB007V2/STEVAL-IDB008V2 board will blink continuously. This may be due to:

1. The firmware configuration used is not coherent with the board type (ETSI fw used with the STEVAL-FKI915V1 or FCC fw used with the STEVAL-FKI868V1).
2. The board is not ready because ID/PAC and KEY have not been loaded on the board.
3. The sigfox library open function returns an error.

The root folder of the project is in Projects/Projects_Cube/Sigfox_Applications/Sigfox_PushButton_Demo_Project.

The same example is provided for MDK-ARM Keil and IAR Embedded Workbench integrated development environments.

5.1 KEIL project

To use the project with KEIL µVision 5 for ARM®:

- Step 1.** Open the KEIL µVision 5 for ARM and select Project→Open Project.
- Step 2.** Open the KEIL project
.../Projects/Projects_Cube/Sigfox_Applications/Sigfox_PushButton_Project/MDK-ARM/
Sigfox_PushButton_Project.uvprojx
- Step 3.** Select desired configuration to build
NUCLEO_XX_ETSI for RCZ1 or NUCLEO_XX_FCC for RCZ2/4
- Step 4.** Select Project→Rebuild all target files.
This will recompile and link the entire application
- Step 5.** Select Project→Download to download the corresponding binary image.

5.2 IAR project

To use the project with IAR Embedded Workbench for ARM®:

- Step 1.** Open the Embedded Workbench for ARM and select File→Open→Workspace.
- Step 2.** Open the IAR project
.../Projects/Projects_Cube/Sigfox_Applications/Sigfox_PushButton_Project/EWARM/
Sigfox_PushButton_Project.eww
- Step 3.** Select desired configuration to build
NUCLEO_XX_ETSI for RCZ1, NUCLEO_XX_FCC for RCZ2/4, NUCLEO_XX_ARIB for RCZ3 or
NUCLEO_XX_ALL to include all.
- Step 4.** Select Project→Rebuild All.
This will recompile and link the entire application
- Step 5.** Select Project→Download and Debug to download the corresponding binary image.

6 Sigfox CLI demo description

This ST-Sigfox demo shows how to use a command line interface (CLI) to send commands which use the Sigfox protocol to send messages and perform pre-certification tests (for the available commands refer to [Section 4.3 Using the command line](#)).

6.1 STEVAL-IDB007V2/STEVAL-IDB008V2 limitations

As described in [Section 6.4 BlueNRG-1/2 support](#), the STEVAL-IDB007V2/STEVAL-IDB008V2 evaluation boards cannot use the UART and the external EEPROM at the same time, so the EEPROM cannot be used in this project.

For this reason, in the CLI Project, you should use the define `USE_FLASH` for the MCU Flash to store credentials and any other Sigfox nonvolatile data.

6.2 Sigfox pre-certification tests

The CLI project includes the SIGFOX ADDON library that allows performing the entire test suite before the official certification.

The test procedure requires the RSA-SDR-Dongle kit from Sigfox.

Test can be performed calling the `node_test` command specifying RCZ and Test ID.

6.2.1 Sigfox RCZ values

Table 7. Sigfox RC zones

RCZ ID	RCZ Name	Description
0	SFX_RC1	Radio Configuration 1
1	SFX_RC2	Radio Configuration 2
2	SFX_RC3A	Radio Configuration 3A
3	SFX_RC3C	Radio Configuration 3C
4	SFX_RC4	Radio Configuration 4
5	SFX_RC5	Radio Configuration 5
6	SFX_RC101	Radio Configuration 101

6.2.2 Sigfox test ID values

Table 8. Sigfox suitable test ID values

Test ID#	Test name
0	SFX_TEST_MODE_TX_BPSK
1	SFX_TEST_MODE_TX_PROTOCOL
2	SFX_TEST_MODE_RX_PROTOCOL
3	SFX_TEST_MODE_RX_GFSK
4	SFX_TEST_MODE_RX_SENSI
5	SFX_TEST_MODE_TX_SYNT
6	SFX_TEST_MODE_TX_FREQ_DISTRIBUTION
7	SFX_TEST_MODE_RX_MONARCH_PATTERN_LISTENING_SWEEP

Test ID#	Test name
8	SFX_TEST_MODE_RX_MONARCH_PATTERN_LISTENING_WINDOW
9	SFX_TEST_MODE_RX_MONARCH_BEACON
10	SFX_TEST_MODE_RX_MONARCH_SENSI

6.3 IAR project

To use the project with IAR Embedded Workbench for ARM®:

- Step 1.** Open the Embedded Workbench for ARM®.
- Step 2.** Select [File]>[Open]>[Workspace].
- Step 3.** Open the IAR project
 ../Projects/Projects_Cube/SigFox_Applications/SigFox_CLI_Demo_Project/EWARM/
 SigFox_CLI_Demo_Project.eww
- Step 4.** Select the desired configuration.
- Step 5.** Select [Project]>[Rebuild All]
- Step 6.** Select [Project]>[Download and Debug] to download the corresponding binary image.

6.4 BlueNRG-1/2 support

The [STSW-S2LP-SFX-DK](#) SW package supports the STEVAL-IDB007V2/STEVAL-IDB008V2 platforms.

To use them, you have to download and install the latest [STSW-BLUENRG1-DK](#) software package from www.st.com to install the USB-to-serial driver needed for the applications requiring the serial port.


Some hardware modifications are also needed to ensure compatibility with [S2-LP](#) evaluation kits.

6.4.1 Hardware requirements

To run the demo of this package you need:

- a [BlueNRG-1](#) STEVAL-IDB007V1/2 or a STEVAL-IDB008V1/2 kit based on [BlueNRG-2](#) (for further details, see [UM2071](#) on www.st.com).
- an [S2-LP](#) STEVAL-FKI868V1 or [STEVAL-FKI915V1](#) kits depending on the operating band (for further details, see [UM2149](#) on www.st.com).

Figure 16. STEVAL-IDB007V1 platform




6.4.2 Changes to the STEVAL-IDB007V1/2 and STEVAL-IDB008V1/2 boards

To make the STEVAL-IDB007V1/2 or STEVAL-IDB008V1/2 boards compatible with the STEVAL-FKI868V1/ STEVAL-FKI915V1 boards, you have to apply some changes to the board, on the bottom layer:

- Step 1.** Remove R12 resistor.
- Step 2.** Create a short-circuit between pin 8 and pin 7 of CN3 connector.
- Step 3.** Remove R25, R21, R19, R16 resistors.
- Step 4.** Set a short between the internal pad of R21 and R17 resistors.
- Step 5.** Set a short between pin 6 of CN4 connector and the internal pad of R19 resistor.

Figure 17. STEVAL-IDB007V1/2 or STEVAL-IDB008V1/2 hardware modification



6.4.3 BlueNRG-1 SoC connections

After applying the modifications, the STEVAL-IDB007V1 platform pin connection is as described the following table.

Table 9. STEVAL-IDB007V1 platform pin description with board function

Pin name	Pin num.	Function										
		LEDs	S2-LP	Buttons	FKI_E2PROM	Pressure sensor	3D accelerometer and gyroscope	JTAG	Arduino connectors			
									CN1	CN2	CN3	C4
DIO10	1							JTMS-SWTDIO				
DIO9	2							JTCK-SWTK				
DIO8	3				SPI_CS				pin 1 (IO8)		pin 2 (TX)	
DIO7	4	DL2							pin 2 (IO9)			pin 6 (SCL)
DIO6	5	DL1	SDN								pin 7 (IO6)	pin 5 (SDA)
DIO5	7			PUSH2		SDA (PUSH2 button)			pin 9 (SDA)			
DIO4	8					SCL			pin 10 (SCL)			
DIO3	9		SPI_SDO		SPI_SDO		SPI_SDO		pin 5 (MISO)		pin 6 (IO5)	
DIO2	10		SPI_SDA		SPI_SDA		SPI_SDA		pin 4 (MOSI)		pin 5 (IO4)	
DIO1	11						SPI_CS	JTAG-TDO	pin 3 (CS)			
DIO0	12		SPI_SCL		SPI_SCL		SPI_SCL	JTAG-TDI	pin 6 (SCK)		pin 4 (IO3)	
DIO14	13	DL3	SPI_CS									pin 4 (AD3)
RESET	25		RESET	RESET				RESET		pin 3 (NRST)	pin 8 (IO7)	
DIO13	29		GPIO3	PUSH1								pin 3 (AD2)
DIO12	30						INT1					pin 1 (AD0)
DIO11	32										pin 1 (RX) pin 3 (IO2)	pin 2 (AD1)

6.4.4 S2-LP

The [S2-LP](#) is placed in the STEVAL-FKI868/915V1 boards connected to the STEVAL-IDB007V1 through the Arduino connectors (CN1-4) and can be driven by the [BlueNRG-1](#) via SPI.

GPIO3 is connected to the BlueNRG-1 wake-up pin used to notify some events.

The BlueNRG-1 SoC acts as a SPI master and can be used to configure the device through registers and to send/receive data to/from the sub-1GHz channels.

6.4.5 E2PROM

The E2PROM containing the manufacturing data of the S2-LP board can be accessed by the BlueNRG-1 using the SPI bus.

Important:

Since the EEPROM CS signal is shared with the TX signal of the BlueNRG UART port (IO8), UART and EEPROM should be used in an exclusive way.

6.4.6 Hardware setup

- Step 1.** Connect a 2.4 GHz antenna to the STEVAL-IDB007V1 SMA connector.
- Step 2.** Connect an 868/915MHz antenna to the STEVAL-FKI868/915V1 SMA connector.
- Step 3.** Ensure the jumper configuration on the board is as described in [Section 6.4.2 Changes to the STEVAL-IDB007V1/2 and STEVAL-IDB008V1/2 boards](#).
- Step 4.** Connect the motherboard to the PC via a USB cable.
- Step 5.** Verify the PWR LED DL4 light is on.

6.5 Sigfox credentials

Sigfox board information (ID, PAC and KEY) can be stored in the device Flash memory using the SIGFOX_FLASHER tool included with the [STSW-S2LP-SFX-DK](#) package.

Before proceeding, you need to obtain valid credentials from Sigfox (for further details, contact your local reference for Sigfox).

However, you can use the test credentials for test purposes:

- **ID** = 0xFEDBCA98
- **KEY** = 0x0123456789ABCDEF0123456789ABCDEF

The SIGFOX_FLASHER is a tool to setup Sigfox credentials and board information related to Sigfox operations. The output of this tool is a binary file and, optionally, the information stored in the file can be directly flashed to the device.

All the examples included in this package can be programmed to read Sigfox credentials from Flash by simply declaring the USE_FLASH define in the pre-processor defined symbols.

Together with ID, PAC and KEY, other information stored in the Flash memory is related to:

- RCZ
- frequency offset
- RSSI offset

6.5.1 Prerequisites

To save credentials in your device using the tool, ensure you installed the right version of ST-LINK utility, according the device you want to flash (refer to the table below).

Table 10. ST-LINK utility and related devices

Device	ST-LINK UTILITY
STM32	STSW-LINK004
BlueNRG1/2	STSW-BNRG1STLINK

When installed, check the application path with the one listed in the app.cfg file.

Default values for app.cfg are:

```
STM_32=C:\Program Files (x86)\STMicroelectronics\STM32 ST-LINK Utility\ST-LINK Utility\ST-LINK_CLI.exe

BLNRG1=C:\Program Files (x86)\STMicroelectronics\BlueNRG-1_2 ST-Link Utility V 2.0.0\ST-LINK_
Utility\BlueNRG-1_ST-LINK_CLI.exe
```

6.5.2 Usage

After receiving your valid credentials, go to the SfxFlasher folder and open a Windows command window. The SIGFOX_FLASHER tool supports a series of options as listed in the table below.

Table 11. SIGFOX_FLASHER parameters

Parameter	Description
Data	A string in the form of ID;PAC;KEY;RCZ;FrequencyOffset;RSSIOffset
-e	Encryption mode: none, fixed, variable
-k key	16-byte long encryption key when fixed mode selected
-f [file name]	Output file name
-w [address]	Write directly in the Flash memory

Example:

```
> SIGFOX_FLASHER
"FEDBCA98;0102030405060708;0123456789ABCDEF0123456789ABCDEF;1;1740;21" -e fixed
-k 995511775533664400AABBCCDDEEFF00 -f myCredentials.bin -w
```

Note: The values for RC Zone field are:

- 1 = RC1
- 2 = RC2
- 3 = RC3c
- 4 = RC4
- 5 = RC5

The command in the example generates the *myCredentials.bin* file which, through the *-w* option, is automatically flashed at the default location according to the table below.

Table 12. Devices and related default Sigfox board data address

Device	Default Sigfox board data address
STM32L0	0x08007000
STM32L1	0x08000200
STM32F0	0x08006CE0
STM32F4	0x08008000
BlueNRG-1	0x10065800
BlueNRG-2	0x1007D800

6.5.3 Encryption

The Sigfox key can be optionally encrypted using an AES 128 bit encoding algorithm, with a 16-byte long key. There are three ways of handling key encryption:

- no encryption
- fixed encryption
- variable encryption

6.5.3.1 No encryption

With the *-e none* option, the key provided as input will be stored as is, without any encryption or elaboration.

6.5.3.2 ***Fixed encryption***

The term fixed identifies an encryption key used always as is for each board.

When fixed encryption is selected, using the `-e fixed` option, the custom key has to be provided with the `-k` option as in the example above.

6.5.3.3 ***Variable encryption***

The term variable identifies a different encryption key for every board based on its own unique ID.

To enable this type of encryption, type the option `-e variable`.

Revision history

Table 13. Document revision history

Date	Version	Changes
01-Feb-2017	1	Initial release.
07-Sep-2018	2	<p>Updated Introduction, Section 1 Sigfox S2-LP kit content, Section 2.1 Hardware requirements, Table 1. Sigfox radio configuration zone, Figure 6. ST Registration procedure 3/3, Figure 7. Sigfox device page, Figure 8. Sigfox device information, Figure 9. Sigfox device messages, Figure 12. Sigfox DEVICE TYPE tab, Figure 13. Sigfox DEVICE TYPE parameters, Figure 15. Command line function list, Table 2. Available command line functions and Table 3. Macro channel mapping - config_words[0].</p> <p>Added Section 6.1 STEVAL-IDB007V2/STEVAL-IDB008V2 limitations, Section 6 Sigfox CLI demo description, Section 6.2 Sigfox pre-certification tests, Section 6.2.1 Sigfox RCZ values, Section 6.2.2 Sigfox test ID values, Section 6.3 IAR project, Section 6.4 BlueNRG-1/2 support, Section 6.4.1 Hardware requirements, Section 6.4.2 Changes to the STEVAL-IDB007V1/2 and STEVAL-IDB008V1/2 boards, Section 6.4.3 BlueNRG-1 SoC connections, Section 6.4.4 S2-LP, Section 6.4.5 E2PROM, Section 6.4.6 Hardware setup, Section 6.5 Sigfox credentials, Section 6.5.1 Prerequisites, Section 6.5.2 Usage, Section 6.5.3 Encryption, Section 6.5.3.1 No encryption, Section 6.5.3.2 Fixed encryption and Section 6.5.3.3 Variable encryption.</p> <p>Minor text edits.</p>

Contents

1	Sigfox S2-LP kit content	2
2	Requirements	3
2.1	Hardware requirements	3
2.2	Software prerequisites	3
3	Board registration	4
3.1	ST-side registration	4
3.2	Sigfox side registration	8
4	Demo description	10
4.1	Sigfox Demo GUI	10
4.1.1	Sigfox Demo GUI menu items	12
4.2	Demo without connection to a PC	12
4.3	Using the command line	12
4.3.1	Command line function description	13
4.3.2	node_send_frame command description	14
4.3.3	node_set_std_config command description	15
5	Push button demo description	17
5.1	KEIL project	17
5.2	IAR project	17
6	Sigfox CLI demo description	18
6.1	STEVAL-IDB007V2/STEVAL-IDB008V2 limitations	18
6.2	Sigfox pre-certification tests	18
6.2.1	Sigfox RCZ values	18
6.2.2	Sigfox test ID values	18
6.3	IAR project	19
6.4	BlueNRG-1/2 support	19
6.4.1	Hardware requirements	19
6.4.2	Changes to the STEVAL-IDB007V1/2 and STEVAL-IDB008V1/2 boards	19
6.4.3	BlueNRG-1 SoC connections	20
6.4.4	S2-LP	21

6.4.5	E2PROM.	21
6.4.6	Hardware setup.	22
6.5	Sigfox credentials.	22
6.5.1	Prerequisites.	22
6.5.2	Usage.	22
6.5.3	Encryption.	23
Revision history.		25

List of tables

Table 1.	Sigfox radio configuration zone	4
Table 2.	Available command line functions	13
Table 3.	Macro channel mapping - config_words[0].	15
Table 4.	Macro channel mapping - config_words[1].	15
Table 5.	Macro channel mapping - config_words[2].	15
Table 6.	Default STD config.	16
Table 7.	Sigfox RC zones	18
Table 8.	Sigfox suitable test ID values.	18
Table 9.	STEVAL-IDB007V1 platform pin description with board function.	21
Table 10.	ST-LINK utility and related devices.	22
Table 11.	SIGFOX_FLASHER parameters	23
Table 12.	Devices and related default Sigfox board data address	23
Table 13.	Document revision history	25

List of figures

Figure 1.	NUCLEO disk drive	4
Figure 2.	Sigfox Demo GUI main window.	5
Figure 3.	ST Registration procedure 1/3	6
Figure 4.	ST Registration procedure 2/3	7
Figure 5.	Generated mail pop-up	7
Figure 6.	ST Registration procedure 3/3	8
Figure 7.	Sigfox device page	8
Figure 8.	Sigfox device information	9
Figure 9.	Sigfox device messages	9
Figure 10.	JP1 position on STM32 Nucleo board	10
Figure 11.	Sigfox Demo GUI main window.	11
Figure 12.	Sigfox DEVICE TYPE tab.	11
Figure 13.	Sigfox DEVICE TYPE parameters.	12
Figure 14.	Command line terminal box	12
Figure 15.	Command line function list	13
Figure 16.	STEVAL-IDB007V1 platform.	19
Figure 17.	STEVAL-IDB007V1/2 or STEVAL-IDB008V1/2 hardware modification	20

IMPORTANT NOTICE – PLEASE READ CAREFULLY

STMicroelectronics NV and its subsidiaries ("ST") reserve the right to make changes, corrections, enhancements, modifications, and improvements to ST products and/or to this document at any time without notice. Purchasers should obtain the latest relevant information on ST products before placing orders. ST products are sold pursuant to ST's terms and conditions of sale in place at the time of order acknowledgement.

Purchasers are solely responsible for the choice, selection, and use of ST products and ST assumes no liability for application assistance or the design of Purchasers' products.

No license, express or implied, to any intellectual property right is granted by ST herein.

Resale of ST products with provisions different from the information set forth herein shall void any warranty granted by ST for such product.

ST and the ST logo are trademarks of ST. All other product or service names are the property of their respective owners.

Information in this document supersedes and replaces information previously supplied in any prior versions of this document.

© 2018 STMicroelectronics – All rights reserved