


Immediately Ready for Use after Turning the Power on


Turn the power on.




The Home screen appears.




(Ex.) Displaying photos on Memory Stick media



Press **▶** on the remote control, select [Photos] by pressing **⬆** and press **↵** (ENTER).



Select [Memory Stick] by pressing **⬆** on the remote control, and press **↵** (ENTER).



Select the folder including the target photo by pressing **⬆** on the remote control, and press **↵** (ENTER).



Select a photo by pressing **⬆** on the remote control, and press **↵** (ENTER). The photo is displayed.

* An Internet environment and a wireless network connection are required.


SONY

VAIO

Fully enjoy photos, music, and information

VGF-CP1 Quick Reference Guide

The following features are available on the **VGF-CP1**



* An Internet environment and a wireless network connection are required.




Enjoying Full Use of “Frames”

Turn the power on.



The Home screen appears.



By creating various types of frames, you can easily enjoy photos, music and information.*

This unit includes frames of sample images and music as an example to the user.

What are “Frames”?

A Frame is a collection of your favorite photos, music and/or information*.

Created frames are displayed in the Home screen and can be directly selected.

What’s the advantage of using “Frames”?

- (1) Without any complicated operations, your favorite photos, music or information can be directly selected.
- (2) You can combine and enjoy your favorite photos, music and/or information at the same time.

How do I create a “Frame”?

Display photos, music or information that you wish to create as a frame, then press OPTIONS and select [Create new frame].

For further details about frames, see the other side.

* An Internet environment and a wireless network connection are required.

The Benefits of Using “Frames”

Create a frame by pressing OPTIONS while displaying photos.




Enjoy photos and information at the same time

Select the [Photos and Info] frame. You can now display information from Google News UK (for U.K. model)/Google News (for U.S.A. model) or the current time together with your favorite photos.



Creatively combine photos and music

Select the [Photos] frame. You can display your photos in a specified folder one by one with special effects and music.



Check photos from friends at the same time

Select the [Shared] frame*. You can now simultaneously display your photos and those of your friends, uploaded on the Web photo organizer. Up to 4 members can be registered for each Shared frame.



Enjoy photos taken this time some years ago

Select the [Memories] frame. You can now display all your nostalgic photos taken in 'this time some years ago'.

Create your frames by pressing OPTIONS while playing back music.



Enjoy your favorite music

You can create a Music frame. Your favorite music will then be played back directly from the Home screen.

Create your frames by pressing OPTIONS while displaying information*.



Check the latest news

You can create a News frame while displaying Google News UK (for UK model)/Google News (for USA model).



Check your favorite Web info

You can create an RSS frame when displaying RSS feeds for which you have been registered.

* An Internet environment and a wireless network connection are required.