

I


1 Overview

This guide provides phone operating instructions, and features descriptions for the Cisco Unified IP Phone multiline models

Connecting Your Phone

2 Operating Your Phone

This section describes how to operate your Cisco Unified IP phone and includes information on soft keys and phone features.



Place a Call

Hold a Call

To place a call on hold while on the call:

-

2. Place a call to another number.
 3. When the call connects, press **Confm** again to add the new party to the call.
- To establish a conference call between two- and three-partyD0.n

Place a Call from Your Local Directory

To access the local phone directory

Place a Call Using Your Extension Mobility (EM) Profile

Extension Mobility (EM) allows the user to temporarily configure a Cisco Unified IP phone to function as user's own phone. Once the user is logged-in to EM, the phone adopts the user's profile, including the line buttons, features, and established

Mute a Call 8

Americas Headquarters
Cisco Systems, Inc.
170 West Tasman Drive
San Jose, CA 95134-1706
USA
www.cisco.com
Tel: 408 526-4000
800 553-NETS (6387)
Fax: 408 527-0883

