



IBM Systems - iSeries  
Systems management  
Common Information Model

*Version 5 Release 4*







IBM Systems - iSeries  
Systems management  
Common Information Model

*Version 5 Release 4*

**Note**

Before using this information and the product it supports, read the information in “Notices,” on page 137.

**Second Edition (February 2006)**

This edition applies to version 5, release 4, modification 0 of IBM i5/OS (product number 5722-SS1) and to all subsequent releases and modifications until otherwise indicated in new editions. This version does not run on all reduced instruction set computer (RISC) models nor does it run on CISC models.

© Copyright International Business Machines Corporation 2004, 2006. All rights reserved.

US Government Users Restricted Rights – Use, duplication or disclosure restricted by GSA ADP Schedule Contract with IBM Corp.

# Contents

<b>Common Information Model . . . . .</b>	<b>1</b>		
What's new for V5R4 . . . . .	1		
Printable PDF . . . . .	3		
Universal Manageability Enablement CIM . . . . .	4		
Configuring Universal Manageability Enablement CIMOM . . . . .	4		
Repository and configuration migration . . . . .	5		
Ensuring that the system has the required installation requirements . . . . .	6		
Setting the configuration properties. . . . .	6		
Basic startup properties for Universal Manageability Enablement CIMOM. . . . .	8		
Advanced startup properties for Universal Manageability Enablement CIMOM . . . . .	10		
Starting and stopping Universal Manageability Enablement CIMOM . . . . .	17		
Universal Manageability Enablement CIMOM security. . . . .	17		
Authentication on Universal Manageability Enablement CIMOM . . . . .	18		
Authorization on Universal Manageability Enablement CIMOM . . . . .	18		
User authorization on Universal Manageability Enablement CIMOM . . . . .	18		
Command authorization . . . . .	20		
Object authorities . . . . .	21		
Backup and recovery considerations for Universal Manageability Enablement CIMOM. . . . .	24		
Restoring corrupted files . . . . .	25		
Universal Manageability Enablement CIMOM command-line utilities. . . . .	26		
cimconfig usage information. . . . .	26		
cimmofl usage information . . . . .	28		
cimprovider usage information. . . . .	30		
ssltrustmgr usage information . . . . .	31		
Reference information for Universal Manageability Enablement CIM . . . . .	33		
Compatibility to V5R3 and V5R4 operating system CIM providers. . . . .	34		
Providers that are inherited from the operating system . . . . .	35		
Hardware inventory and network management providers . . . . .	48		
		Supported CIM SMI-S HBA and HDR providers . . . . .	77
		i5/OS metrics classes . . . . .	94
		i5/OS support for the CIM indication provider . . . . .	100
		Troubleshooting the Universal Manageability Enablement CIM server . . . . .	101
		Operating system CIM . . . . .	101
		Configuring the operating system CIMOM . . . . .	102
		Ensuring that the system has the required installation options . . . . .	102
		Setting the required configuration parameters	103
		Basic startup options for the cimconfig command . . . . .	103
		Advanced startup options for the cimconfig command . . . . .	104
		Starting the operating system CIMOM job	110
		Operating system CIMOM security . . . . .	111
		Authorizing Pegasus . . . . .	112
		Enabling Kerberos. . . . .	112
		Backup and recovery considerations for operating system CIMOM . . . . .	113
		Restoring corrupted files . . . . .	113
		Operating system CIMOM command-line utilities . . . . .	114
		cimconfig usage information . . . . .	114
		cimmofl usage information . . . . .	116
		cimprovider usage information . . . . .	118
		Reference information for operating system CIM	120
		Supported CIM base operating system classes	120
		i5/OS metrics . . . . .	130
		i5/OS support for the CIM indication provider . . . . .	133
		Troubleshooting the operating system CIM server . . . . .	133
		Related information for Common Information Model. . . . .	135
		<b>Appendix. Notices . . . . .</b>	<b>137</b>
		Programming interface information . . . . .	139
		Trademarks . . . . .	139
		Terms and conditions. . . . .	139



---

## Common Information Model

The Common Information Model (CIM) is a standard developed by Distributed Management Task Force (DMTF). DMTF is a consortium of major hardware and software vendors (including IBM) that is a part of the Web-Based Enterprise Management (WBEM) initiative.

WBEM includes a set of standards and technologies that provide management solutions for a distributed network environment. Interoperability is a major focus of WBEM. WBEM technologies can help you develop a single set of management applications for a diverse set of resources.





CIM is a major component of the WBEM initiative, providing a model for describing and accessing data across an enterprise. CIM comprises both a specification and a schema. The specification defines the details for integration with other management models, whereas the schema provides the actual model descriptions.

CIM includes the following functions:

- Providers instrumentation for server resources on the system. The providers, which are based on a subset of the standardized CIM classes, gather data on a system.
- Common Information Model Object Manager (CIMOM), a central component of the WBEM server that is responsible for the communication between clients and providers. CIMOM also provides several management functions, including security, and a set of commands that provide configuration and management functions to administrators.
- A schema that defines an information model for representing systems management functions.
- An implementation of the standardized formats for communication between clients and CIMOM, called CIM in XML, V2.1 and CIM Operations over HTTP, V1.1. For more information about these standards, see the WBEM Web site.

| CIM has moved out of the operating system and is now part of the IBM® Universal Manageability Enablement for i5/OS® licensed program (5722-UME). It is preferred that you install the Universal Manageability Enablement for i5/OS licensed program and use the CIM function of that licensed program. You can still use the CIM server and providers that are supplied with the operating system; however, if you install the Universal Manageability Enablement for i5/OS licensed program, the CIM server and CIM providers that are supplied with the operating system are disabled.

### Related information

-  [DMTF - Web-Based Enterprise Management \(WBEM\)](#)
-  [Common Information Model: Introduction to CIM](#)
-  [Common Information Model \(CIM\) Standards](#)
-  [The Open Group: OpenPegasus](#)

---

## What's new for V5R4

This topic highlights the changes made to this topic collection for V5R4.

For V5R4, i5/OS supports Pegasus version 2.5. With support for Pegasus version 2.5, i5/OS has configuration enhancements and added CIM base operating system classes.

The `cimconfig` command has new basic and advanced startup options. In addition, the `cimmofl` and `cimprovider` commands have been enhanced with new options.

- “Basic startup options for the `cimconfig` command” on page 103

- “Advanced startup options for the cimconfig command” on page 104
- “cimconfig usage information” on page 114
- “cimmofl usage information” on page 116
- “cimprovider usage information” on page 118

Thirteen new CIM base operating system classes are now supported. Other enhancements include new i5/OS metrics and support for CIM indications.

- “Supported CIM base operating system classes” on page 120
- “i5/OS metrics” on page 130
- “i5/OS support for the CIM indication provider” on page 133

New troubleshooting information and backup and recovery information has been added for V5R4.

- “Backup and recovery considerations for operating system CIMOM” on page 113
- “Restoring corrupted files” on page 25
- “Troubleshooting the operating system CIM server” on page 133

## | **What’s new as of 28 February 2008**

| CIM has moved out of the operating system and is now part of the IBM Universal Manageability Enablement for i5/OS licensed program (5722-UME). The CIM in the Universal Manageability Enablement for i5/OS licensed program includes all functions that the CIM of the operating system supplies. Meanwhile, the licensed program includes enhanced CIM support with new features such as Secure Sockets Layer (SSL) and IPv6 support.

| It is preferred that you install the Universal Manageability Enablement for i5/OS licensed program and use the CIM function of that licensed program. You can still use the CIM server and providers that are supplied with the operating system; however, if you install the Universal Manageability Enablement for i5/OS program, the CIM server and CIM providers that are supplied with the operating system are disabled.

| The Common Information Model Object Manager (CIMOM) server and providers are now included with the IBM Universal Manageability Enablement for i5/OS licensed program. The CIM server of the Universal Manageability Enablement for i5/OS licensed program runs under i5/OS Portable Application Solutions Environment (i5/OS PASE).

| The CIM server and providers that are supplied with the operating system will be obsolete after V5R4.

| The following Universal Manageability Enablement CIM functions are supported:

- The following CIMOM functions are supported in V5R4:
  - | – SSL
  - | – Common Manageability Programming Interface (CMPI)
  - | – Out-of-process providers
  - | – Service Location Protocol (SLP)
  - | – Distributed Management Task Force (DMTF) schema 2.14
  - | – Internet Protocol version 6 (IPv6)
  - | – Server Profile support (Server Profile supported by OpenPegasus 2.6.0)
- The following CIMOM functions were removed:
  - | – Kerberos support
  - | – Obsolete configuration properties
    - | - tempLocalAuthDir



- | - enableHttpLocalconnection
- | - kerberosServiceName
- | • The following CIMOM functions were changed to fixed properties:
  - | - home
  - | - daemon
  - | - slp
  - | - repositoryDir
- | • The -q option is no longer needed for the cimconfig and cimprovider commands in i5/OS PASE. Some new properties were added to the basic startup properties and advanced startup properties for CIMOM. The cimmof and ssltrustmgr commands are available.
  - | - "Basic startup properties for Universal Manageability Enablement CIMOM" on page 8
  - | - "Advanced startup properties for Universal Manageability Enablement CIMOM" on page 10
  - | - "cimmof usage information" on page 28
  - | - "cimconfig usage information" on page 26
  - | - "cimprovider usage information" on page 30
  - | - "ssltrustmgr usage information" on page 31
- | • The following properties were changed to fixed properties, and you cannot change their values:
  - | - daemon
  - | - repositoryDir
- | • The following providers are supported:
  - | - Storage Management Initiative Specification (SMI-S) host bus adapter (HBA) and host discovered resources (HDR) CIM providers
  - | - "Providers that are inherited from the operating system" on page 35
  - | - "Hardware inventory and network management providers" on page 48



## What's new as of 28 February 2006

Because the CIM that is supplied with the operating system does not support Secure Sockets Layer (SSL), most of the references to SSL have been removed from topics related to the operating system CIM.

- | However, the IBM Universal Manageability Enablement for i5/OS licensed program supports SSL. To use SSL for the CIM on your system, you must install this licensed program.

## How to see what's new or changed

To help you see where technical changes have been made, this information uses:

- The  image to mark where new or changed information begins.
- The  image to mark where new or changed information ends.

To find other information about what's new or changed this release, see the Memo to users.

---

## Printable PDF

Use this to view and print a PDF of this information.


To view or download the PDF version of the Common Information Model topic, select Common Information Model (about 490 KB).

## Saving PDF files

To save a PDF on your workstation for viewing or printing:

1. Right-click the PDF in your browser (right-click the link above).
2. Click the option that saves the PDF locally.
3. Navigate to the directory in which you want to save the PDF.
4. Click **Save**.

## Downloading Adobe Reader





- | You need Adobe® Reader installed on your system to view or print these PDFs. You can download a free copy from the Adobe Web site ([www.adobe.com/products/acrobat/readstep.html](http://www.adobe.com/products/acrobat/readstep.html)) .

---

## Universal Manageability Enablement CIM

- | The Common Information Model (CIM) is a function of the Universal Manageability Enablement for i5/OS licensed program.
- | The Common Information Model (CIM) standard provides the ability to develop management application that work with the systems management data that is made available by the CIM providers and included with the i5/OS operating system.
- | The CIM server of the Universal Manageability Enablement for i5/OS licensed program runs under i5/OS Portable Application Solutions Environment (i5/OS PASE). If you install Universal Manageability Enablement for i5/OS, the CIM server (QYCMCIMOM) and CIM providers that are supplied with the operating system are disabled.
- | To work with CIM, developers should have a thorough understanding of the CIM standard defined by the DMTF. For more information about the CIM standard, see CIM Specifications on the DMTF - Web-Based Enterprise Management (WBEM) Web site.

### Related information

- |  [DMTF - Web-Based Enterprise Management \(WBEM\)](#)
- |  [Common Information Model: Introduction to CIM](#)
- |  [Common Information Model \(CIM\) Standards](#)
- |  [The Open Group: OpenPegasus](#)

## Configuring Universal Manageability Enablement CIMOM

- | If you have installed the Universal Manageability Enablement for i5/OS licensed program, use this information to configure the Common Information Model Object Manager (CIMOM).
- | After you install the IBM Universal Manageability Enablement for i5/OS licensed program, start the CIM server before you configure CIMOM. The CIM server starts a repository and configuration migration process. Before the migration is completed, the CIM server is not available to process CIM requests. Do not use any client programs during the migration. For more information about the migration, see “Repository and configuration migration” on page 5.
- | To configure CIMOM, follow these steps:
  1. Ensure that the operating system has the required installation requirements.
  2. Set the configuration properties by using the `cimconfig -s -p` command.

3. Grant users the authorizations required to work with CIMOM. In the operating system, Application Administration controls operations that change the local CIM schema, and object authorities control operations that change the system objects.
4. Start CIMOM.

#### **Related concepts**

“Universal Manageability Enablement CIMOM command-line utilities” on page 26

You can use a set of command-line utilities to control or change the CIMOM environment. The command-line utilities of Universal Manageability Enablement CIMOM include cimconf, cimconfig, cimprovider, and ssltrustmgr.

“cimconfig usage information” on page 26

You can configure the startup properties for Universal Manageability Enablement CIMOM with the cimconfig command.

“i5/OS metrics classes” on page 94

The topic describes metric classes and the user authorization.

### **Repository and configuration migration**

When you start the CIM server for the first time after you install the Universal Manageability Enablement for i5/OS licensed program, a CIM repository and configuration migration process begins. During the migration, symbolic links are also created; therefore, you cannot use the cimconf, cimconfig, and cimprovider commands.

The migration might take some time, depending on the size of the repository, processor speed, and system utilization.

#### **Repository migration**

The Universal Manageability Enablement for i5/OS licensed program provides a repository, which includes a set of files that contain the CIM class definitions, instances of classes, and provider registration instances. The repository is stored in the UserData directory (/QOpenSys/QIBM/UserData/UME/Pegasus).

The CIM repository is migrated from Distributed Management Task Force (DMTF) CIM schema V2.7 or V2.9 to DMTF CIM schema V2.14. During the migration, the CIM server is not available to process CIM requests. If you stop the server job during the migration, loss of data might occur.

The following objects are not migrated:

- CIM provider register information
- Static instances of metric definition in the repository (Providers dynamically collect information and implement the same functions as these metric instances.)

The operating system CIM repository (in directory /QIBM/UserData/OS400/CIM) remains intact after the migration. You can still use the operating system CIM server after you uninstall the Universal Manageability Enablement program.

The CIM server log (by default, located at /QOpenSys/QIBM/UserData/UME/Pegasus/logs) might have the following messages related to the repository migration:

#### **Message PGS10100**

This message is written into the CIM server log when the migration begins.

PGS10100: The CIM server is starting to restore the repository and then migrate the repository from an earlier version. This will take several minutes, during which the server will not be available. Stopping the server job might result in the loss of data.

#### **Message PGS10101**

This message is written into the CIM server log when the migration is completed without errors.

PGS10101: The Common Information Model (CIM) repository has been migrated successfully.

## Configuration migration

The CIM server migrates the configuration file of the operating system CIM server. The configuration properties are migrated and their values are not changed. However, the following configuration properties are not migrated:

- logdir, home, daemon, slp, repositoryDir, tempLocalAuthDir, and kerberosServiceName.
- enableHttpsConnection, sslClientVerificationMode, and httpAuthType if the value of property httpAuthType in the operating system CIM server is Kerberos. Property enableHttpsConnection is set to false after the migration.
- enableHttpLocalConnection.

The migrated configuration properties are not checked for validity. If the configuration properties of the operating system CIM server are not set to function properly, this might prevent the new CIM server from starting and functioning successfully.

## Ensuring that the system has the required installation requirements

Universal Manageability Enablement CIM requires specific installation options and the Universal Manageability Enablement for i5/OS product on the operating system.

You must have the following programs installed on the system:

- IBM i5/OS Portable Application Solutions Environment (IBM i5/OS PASE) (5722-SS1, option 33)
- OpenSSH, OpenSSL, zlib functions, IBM Portable Utilities for i5/OS (5733-SC1, option 1)
- IBM Universal Manageability Enablement for i5/OS (5722-UME)

**Note:** In V5R4, you need to install all the required fixes. Refer to the Information APAR (5722-UME CONSIDERATIONS).

## Setting the configuration properties

Before starting the CIM server, you need to set several configuration properties using the `cimconfig -s -p` command.

## Enabling the CIM server with Secure Sockets Layer

To enable the CIM server to run in Secure Sockets Layer (SSL) mode, a private key and a certificate are required. The administrator can create the private key and certificate by signing it with a certificate authority (CA).

The CIM server checks for its private key and certificate during startup. If either of the files does not exist, the server creates its private key and a self-signed, 365-day certificate. These files are created in the location that is defined by the value of the `sslCertificateFilePath` and `sslKeyFilePath` properties.

The server creates its certificate with the following fields for the distinguished name:

- Country Name: US
- State or Province Name: Minnesota
- Locality: Rochester
- Organization Name: IBM
- Organizational Unit: System i™
- Common Name: *hostname of the system*
- Email Address:

| **Note:** The Common Name is replaced by the hostname of this system, and the Email Address is left blank.

## | **Certificate creation instructions**

| You can use Digital Certificate Manager (DCM) to create a CIM server certificate that is issued by a CA on the operating system, or by an external CA.

| **Note:** CIMOM is not integrated with DCM. All certificates that are created in DCM for CIMOM must be exported to CIMOM. CIMOM only supports the Privacy Enhanced Mail (PEM) format for certificates.

| To create a certificate for CIMOM, use the following steps:

- | 1. Create an application definition in DCM. The recommended application ID is QUME\_CIMOM.
- | 2. Create a certificate for the CIMOM application that is issued by a CA. Remember the subject name that you enter for CIMOM in the certificate.
- | 3. Export the certificate from DCM to CIMOM.
  - | a. In the left frame, choose Manage Certificates and Export Certificates.
  - | b. Click **Server or client** as the type of the certificate.
  - | c. Select the certificate that you created for CIMOM and click **Export**.
  - | d. Click **File** as the export destination.
  - | e. Use the directory that is defined by the `sslCertificateFilePath` property for the export file name, and name the file `pegasuscert.p12`. This file is in PKCS12 (Public Key Cryptography Standards) format.
  - | f. Remember the password that you enter here. The password is used to decrypt the exported certificate.
- | 4. Run the OpenSSL command to convert the certificate from PKCS12 format to PEM format.
  - | a. On the operating system, use the `CALL QP2TERM` command to make the i5/OS Portable Application Solutions Environment (i5/OS PASE) environment available.
  - | b. Change the directory to the location of the exported certificate.
  - | c. Extract the certificate from the PKCS12 file and convert it to the PEM format. Use the OpenSSL command: `openssl pkcs12 -in pegasuscert.p12 -out pegasuscert.pem -nokeys -clcerts`. This command prompts for the password that you entered in the DCM export window.

| The PEM file might contain both the CIMOM certificate and the certificate of the CA that issues the CIMOM certificate. Because CIMOM does not support this type of PEM file, the CA certificate should be removed.
  - | d. Edit the PEM file and remove all the lines except the lines for the CIMOM certificate. The certificate has the CIMOM subject name that you used when creating the certificate in DCM. Keep the lines of the CIMOM certificate starting with Bag Attributes and ending with End Certificate.
  - | e. Extract the private key from the PKCS12 file and convert it to the PEM format. Use the following OpenSSL command: `openssl pkcs12 -in pegasuscert.p12 -out pegasuskey.pem -nocerts -nodes`. This command prompts for the password that you entered in the DCM export window. After you have the certificate and the private key in the PEM format, you can make them available to CIMOM by placing them in the paths that are defined by the `sslCertificateFilePath` and `sslKeyFilePath` properties.

| **Note:** When CIMOM starts, the private key file is created automatically. It is important to keep the private key in a protected directory. By default, the CIMOM private key is put in a directory that is owned by QSYS, with PUBLIC \*EXCLUDE and no private authorities. If the administrator changes the `sslKeyFilePath` property, the new key directory should be protected.

| After the SSL certificates are created, set the following configuration properties to enable the CIM server with SSL and disable the non-SSL port:

- | • enableHttpsConnection: set the value to true
- | • enableHttpConnection: set the value to false

### | **Enabling the CIM server to verify client certificates**

| To enable SSL client certificate verification on the main SSL port, you can use the sslClientVerificationMode property. This property can be set to disable the client certificate verification, to require the client certificate verification, or to verify the client certificate if available and fall back to the httpAuthType property if the certificate is not available. With this property, you can be authenticated through certificate verification or basic authentication. The sslTrustStore property gives the location of the truststore. The exportSSLTrustStore property should have the same value as sslTrustStore; otherwise, the server cannot be started.

| To enable SSL client certificate verification on the export SSL port, you can use the enableSSExportClientVerification property. When the value is set to true, CIMOM requires the exported clients to send certificates. The exportSSLTrustStore property gives the location of the truststore. You need to restart the server to make the properties work after you change the value.

| You can use the cimconfig command to set the current configuration properties or the planned configuration properties of the CIM server. You can change the following configuration properties:

- | • logdir
- | • logLevel
- | • shutdownTimeout
- | • traceComponents
- | • traceFilePath
- | • traceLevel

| When you change the values of these properties, the changes take place immediately without restarting the server. You can update the current configuration properties only when the CIM server is running.

| The properties that are not fixed can be changed in the planned configuration properties, whether the CIM server is running or stopped. If the planned configuration properties are changed, those changes do not take effect until the CIM server is restarted. When the CIM server is restarted, the planned configuration properties become the current configuration properties.

#### | **Related concepts**

| “Troubleshooting the Universal Manageability Enablement CIM server” on page 101

| Use this information if the CIM server does not start or if the CIM server starts, but does not run as expected.

#### | **Related information**

|  [OpenSSL](#)

### | **Basic startup properties for Universal Manageability Enablement CIMOM:**

| You can change basic startup properties for IBM Universal Manageability Enablement CIMOM with the cimconfig command.

| The following list describes the startup properties and default values of Universal Manageability Enablement CIMOM. For these changes to take effect, you must restart the Universal Manageability Enablement CIM server. These changes cannot be made dynamically.

| **enableAuthentication**

| This property determines whether the program performs authentication before any request is allowed into the CIM server over the wbem-http and wbem-https ports.

| If the value is set to true, the program performs authentication before any request is allowed into the CIM server. This does not affect the wbem-exp-https port.

| If the value is set to false, the program allows unauthenticated requests access to the CIM server. If you need to set its value to false, ensure that the server environment is secure.

| The default value is true.

| **enableHttpConnection**

| This property controls whether to allow access through the HTTP port.

| If the value is set to true, you can access through the HTTP port. If you are sure that the server environment is unsecure, set the value to false. To ensure the security for the enableHttpConnection property, set the httpBindAddress property to 127.0.0.1.

| The default value is true.

| **enableHttpsConnection**

| This property enables the HTTPS port to listen for HTTPS requests.

| The default value is true.

| **enableHttpExportConnection**

| This property enables the HttpExport port to listen for HTTP export requests.

| The default value is true.

| **httpAuthType**

| This property determines the authentication to be performed over the HTTP port.

| The default value is Basic.

| **Note:** Only basic authentication is supported. The Kerberos authentication is no longer supported.

| **httpBindAddress**

| This property determines which network interface to bind to for the HTTP port.

| To enable the server to bind to all available interfaces (IP address), set the value to ALL.

| For the value ALL, both IPv6 and IPv4 connections are accepted. If the value of httpBindAddress is a specific IP address, the enableHttpConnection property controls whether the CIM server listens for the specific address for an HTTP connection. If the IP address is set within the IPv6 family, the CIM server can only support an IPv6 connection. If the IP address is set within the IPv4 family, the CIM server can only support an IPv4 connection.

| By default, dual stacks are supported on the operating system. To disable the IPv6 stack, use the following commands: ENDTCP and STRTCP STRIP6(\*NO).

| *Table 1. Values for the httpBindAddress property*

Value	Description
127.0.0.1	The default value
ALL	A correct IPv4 or IPv6 address (for example, 127.0.0.1, ::1)

| **httpExportPort**

| This property specifies the port number of HTTP export requests that the server listens on.

| You should set the value to a valid port number. The default value is 6988.

### | **httpPort**

| This property specifies the port number of HTTP requests that the server listens on.

| You should set the value to a valid port number. It overrides the port number of the wbem-http service in the TCP/IP services table. If the value is not set, the port from the wbem-http service is used. If neither this property nor the wbem-http service port is set, a default value 5988 is used.

| This property only takes effect if the enableHttpConnection property is set to true.

| The default value is "".

### | **httpsBindAddress**

| This property determines which network interface (IP address) to bind to for the HTTPS port.

| The default value is ALL.

### | **httpsPort**

| This property specifies the port number of HTTPS requests that the server listens on.

| You should set the value to a valid port number. It overrides the port number of the wbem-https service in the TCP/IP services table. If the value is not set, the port from the wbem-https service is used. If neither this property nor the wbem-https service port is set, a default value of 5989 is used. This property only takes effect when the enableHttpConnection property is set to true.

| The default value is "".

### | **Related concepts**

| “User authorization on Universal Manageability Enablement CIMOM” on page 18

| *User authorization* is a type of security check that verifies whether you have access to the objects you want to change. Authorization is needed not only for changing operations but sometimes for reading operations as well.

| “Authentication on Universal Manageability Enablement CIMOM” on page 18

| When a user request comes through HTTP or HTTPS, Universal Manageability Enablement CIMOM determines whether this is a legitimate user on the system. If the request does not pass the authentication, the request is rejected. If you set the enableAuthentication property to false, the CIMOM authentication function is disabled.

### | **Related tasks**

| “Authorization on Universal Manageability Enablement CIMOM” on page 18

| Authorization on the Universal Manageability Enablement CIMOM includes user authorization, command authorization, and object authorities.

### | **Advanced startup properties for Universal Manageability Enablement CIMOM:**

| You can change the advanced startup properties for the Universal Manageability Enablement CIM server with the cimconfig command. These properties are intended for use only by advanced CIMOM users.

| The following list describes the advanced startup properties for the cimconfig command, their default values, and whether they can be changed dynamically (meaning that they take effect immediately without restarting the server).

| **Note:** The shutdownTimeout, logdir, logLevel, traceLevel, traceComponents and traceFilePath properties are dynamic. The other properties are not dynamic. For all the other properties, you must use the -p parameter to indicate your changes. You need to restart the CIM server to make the changes take effect.



Table 2. Advanced startup properties

Property	Dynamic	Default value	Description
crlStore	No	ssl/crlstore/	<p>This property describes the path to the directory or file that contains the certificate revocation lists (CRLs).</p> <p>If this property is not set, set to an empty directory or set to an empty file so that no CRLs are loaded.</p> <p>This property only takes effect if the sslClientVerificationMode property is set to required or optional, or if the enableSSEExportClientVerification property is set to true.</p>
enableAssociationTraversal	No	true	<p>This property enables the association traversal.</p> <p>You can set the value to true or false.</p>
enableIndicationService	No	true	<p>This property enables the indication service.</p> <p>You can set the value to true or false.</p>
enableNormalization	No	false	<p>This property controls whether to normalize objects from trusted entities.</p> <p>This property only works in InProcess mode. This means that to make it take effect, you need to set the enableNormalization property to true and the forceProviderProcesses property to false. In OOP mode (the forceProviderProcesses property is set to true), the property does not work.</p> <p>This property has the following values:</p> <p><b>true</b> The program ensures that the objects that are delivered from providers are complete and accurate.</p> <p><b>false</b> The program does not normalize objects from trusted entities (for example, the objects from the repository, control providers, IBM-shipped providers, and certain vendor providers). It normalizes only the objects from the third-party providers that are added to a distribution.</p>
enableSSEExportClientVerification	No	true	<p>This property controls whether to allow exported clients to be connected using HTTPS on the port that is specified by the service name wbem-exp-https. Only CIM export requests are allowed on this port.</p> <p>You can set the value to true or false.</p> <p><b>Note:</b> If the wbem-exp-https port is not defined in the system's TCP/IP services table, an error is recorded and the server does not start. The wbem-exp-https port is defined in the i5/OS services table by default.</p>

Table 2. Advanced startup properties (continued)

Property	Dynamic	Default value	Description
enableSubscriptionsForNonprivilegedUsers	No	false	<p>This property controls whether users need special authorities to create indication subscriptions.</p> <p>You can set the value to true or false. If the value is false, only a user with *IOSYSCFG and *ALLOBJ special authorities is allowed to create indication subscriptions.</p>
excludeModulesFromNormalization	No	""	<p>This property disables normalization for objects from specific provider modules.</p> <p>If the enableNormalization property is set to true, all provider objects are normalized except for those on this exclusion list.</p>
exportSSLTrustStore	No	ssl/truststore/	<p>This property specifies the path to the directory or file that contains the trusted certificates for CIM export requests. The truststore includes CA certificates.</p> <p>You must set this property if the enableSSEExportClientVerificationMode property is set to true.</p> <p>If this property is set to an empty directory or an empty file, no export certificates are trusted.</p> <p>This property only takes effect if the enableSSEExportClientVerification property is set to true.</p> <p><b>Note:</b> The sslTrustStore and exportSSLTrustStore properties should be set to the same value.</p>
forceProviderProcesses	No	true	<p>This property controls how the providers run in processes.</p> <p>If you set the value to true, the providers run in separate processes rather than loading and calling provider libraries directly within the CIM server process.</p>
Logdir	Yes	/QOpenSys/QIBM/ UserData/UME/ Pegasus/logs/	<p>This property specifies the name of the directory that is used for the CIMOM-specific log files.</p> <p><b>Note:</b> Make sure that the server has the authority to write files in the directory if you want to change this property.</p>
logLevel	Yes	INFORMATION	<p>This property sets the level of the data that is logged. The data is saved in the CIMOM log directory.</p> <p>The property has the following values:</p> <ul style="list-style-type: none"> <li>• FATAL</li> <li>• INFORMATION</li> <li>• SEVERE</li> <li>• TRACE</li> <li>• WARNING</li> </ul>
maxProviderProcesses	No	0	<p>This property limits the number of provider processes that run concurrently.</p> <p>A value of 0 indicates that the number of provider agent processes is not limited.</p>

Table 2. Advanced startup properties (continued)

Property	Dynamic	Default value	Description
messageDir	No	/QOpenSys/QIBM/ ProdData/UME/ Pegasus/msg	This property points to the default directory to search for the globalization message bundles. The default value points to the included message bundles.
providerDir	No	/QOpenSys/QIBM/ ProdData/UME/ Pegasus/provider	This property specifies the names of the directories that contain the providers that are running.
repositoryIsDefaultInstanceProvider	No	true	The property enables the repository component of the CIM server to provide CIM object instances by default. If the value is true, no providers service the client request for the CIM instance, and the CIM server repository is used. If the value of the repositoryIsDefaultInstanceProvider property is false, the i5/OS providers that implement CIM metric classes no longer function properly.
socketWriteTimeout	No	20	This property defines the timeout (in seconds) for the socket on the server.
sslCertificateFilePath	No	ssl/keystore/ serverkey.pem	<p>This property indicates the path to the certificate file of the CIM server.</p> <p>You must set this property to a valid certificate if the enableHttpsConnection or enableSslExportClientVerification property is set to true. You can also set the sslCertificateFilePath property to a valid path. If no certificates are in the path, the server creates a certificate after the startup.</p> <p><b>Note:</b> Certificates that are not valid and expired certificates are considered valid when they are loaded by the CIM server. A warning message is logged if the certificate is expired or is not valid.</p> <p>If the sslKeyFilePath property is not specified, the CIM server loads the private key from the certificate file.</p>
sslKeyFilePath	No		<p>This property indicates the path to the CIM server's private key file.</p> <p>If the certificate that is specified in the sslCertificateFilePath property contains the private key, you do not need to set this property.</p> <p>You need to keep this file in a protected directory as the default value.</p>
sslTrustStore	No	ssl/truststore/	<p>This property indicates the path to the directory or file that contains the trusted certificates for CIM operation requests. The truststore includes CA certificates.</p> <p>You must set this property if the sslClientVerificationMode property is set to required.</p> <p>If the sslClientVerificationMode property is set to optional, this property should be set to empty. In this case, no certificates are trusted.</p> <p>If the sslClientVerificationMode is set to disabled, this property is not used.</p>

Table 2. Advanced startup properties (continued)

Property	Dynamic	Default value	Description
sslClientVerificationMode	No	optional	<p>The property sets the mode of SSL client certificate verification.</p> <p>This property is only effective if the enableHttpsConnection property is set to true.</p> <p>You can set the property to the following values.</p> <p><b>required</b> The CIM server requires verification of a client certificate on the HTTPS port and rejects the request if the client certificate is not trusted. The httpAuthType property is not used.</p> <p><b>optional</b> The CIM server verifies a client certificate if available; otherwise, the CIM server uses the httpAuthType setting for client verification.</p> <p><b>disabled</b> The CIM server uses the httpAuthType setting for client verification.</p>
sslTrustStoreUserName	No	""	<p>This property identifies the user name as the user context for the CIM operation request when certificate authentication is used and a user name cannot be associated with a specific certificate file.</p> <p>The user context is the i5/OS user profile under which the provider is called to perform the CIM request.</p> <p>You must set this property to a valid user profile on the operating system.</p> <p>If the sslClientVerificationMode property is set to disabled, this property is not effective.</p> <p>If the sslTrustStore property is set to a directory, this property is not effective.</p> <p>If the sslTrustStore property is set to a single file, this property must be set to a username; otherwise, an error is reported and the CIM server does not start. In this case, all the certificates in the file are assigned to the username that is specified by the sslTrustStoreUserName property.</p>
shutdownTimeout	Yes	10	<p>This property specifies the maximum number of seconds allowed for the CIM server to complete requests before it shuts down. When the ENDTCPSPVR *CIMOM command is issued, the timeout is the maximum number of seconds that are allowed for the CIM server to complete outstanding CIM operation requests before it shuts down. If the specified timeout period expires, the CIM server shuts down, regardless of whether CIM operations are in progress.</p> <p>The minimum value of this property is 2.</p>

Table 2. Advanced startup properties (continued)

Property	Dynamic	Default value	Description
traceFilePath	Yes	/tmp/cimserver.trc	This property indicates the path to the trace file.  The trace of the CIM server is written in /tmp/cimserver.trc. The trace of Well out-of-process providers is written in their own trace files with prefix cimserver.trc and suffix provider module.user (for example, cimserver.trc.TestProviderModule.qycmcimom). <b>Note:</b> Make sure that the server has the authority to write files in the directory if you want to change the property.
traceComponents	Yes	""	This property specifies the components that you want to trace in CIMOM. The valid settings are listed in "Settings for the traceComponents option" on page 109.
traceLevel	Yes	1	This property indicates the level of debug trace.  If the value is 1, the program only traces function exits (the minimum trace). A trace level of 4 is the maximum trace. <b>Note:</b> If the traceLevel property is set to 4 and the traceComponents property is set to ALL, the size of trace file grows quickly and uses large disk spaces.  The range of value is 1 to 4.
idleSessionTimeout	No	0	This property indicates the minimum timeout value for idle client connections.  If the value is 0, idle client connections are not disconnected.

### Related concepts

"User authorization on Universal Manageability Enablement CIMOM" on page 18

*User authorization* is a type of security check that verifies whether you have access to the objects you want to change. Authorization is needed not only for changing operations but sometimes for reading operations as well.

"Authentication on Universal Manageability Enablement CIMOM" on page 18

When a user request comes through HTTP or HTTPS, Universal Manageability Enablement CIMOM determines whether this is a legitimate user on the system. If the request does not pass the authentication, the request is rejected. If you set the enableAuthentication property to false, the CIMOM authentication function is disabled.

### Related tasks

"Authorization on Universal Manageability Enablement CIMOM" on page 18

Authorization on the Universal Manageability Enablement CIMOM includes user authorization, command authorization, and object authorities.

### Settings for the traceComponents property:

You can use the traceComponents property to trace components. This topic lists the valid settings for the traceComponents property of Universal Manageability Enablement CIMOM.

- ALL
- AsyncOpNode
- Authentication
- Authorization

- | • BinaryMessageHandler
- | • Channel
- | • CimData
- | • CIMExportRequestDispatcher
- | • CIMOMHandle
- | • Config
- | • ConfigurationManager
- | • ControlProvider
- | • CQL
- | • DiscardedData
- | • Dispatcher
- | • ExportClient
- | • Http
- | • IndDelivery
- | • IndHandler
- | • IndicationHandlerService
- | • IndicationService
- | • IndicationServiceInternal
- | • IPC
- | • L10N
- | • Listener
- | • Memory
- | • MessageQueueService
- | • MetaDispatcher
- | • ObjectResolution
- | • OsAbstraction
- | • ProviderAgent
- | • ProviderManager
- | • ProvManager
- | • Registration
- | • Repository
- | • Server
- | • Shutdown
- | • SubscriptionService
- | • Thread
- | • UserManager
- | • WQL
- | • XmlIO
- | • XmlParser
- | • XmlReader
- | • XmlWriter

| Tracing is disabled by default and should be used for debugging purposes. You can enable the tracing mechanism by specifying the trace level and the component that you want to trace with the traceLevel property. Possible trace levels follow:

- | **Level 1**
- |       Function entry and exit
- | **Level 2**
- |       Basic flow, trace messages, and low-data detail
- | **Level 3**
- |       Interfunction logic flow, medium-data detail
- | **Level 4**
- |       All information, high-data detail

| The trace data is saved in the file that is specified by the traceFilePath property. By default, the traceFilePath property is set to /tmp/cimserver.trc.

| You can also trace all the components by setting ALL where you specify components in the property. If the traceComponents property is not set to any component, tracing is disabled regardless of the setting of the traceLevel property.

| You can use the cimconfig command to modify the trace configuration parameters when the CIM server is running. For example, to set the trace level to trace all information with high-data detail in the Thread and ProvManager components, open an i5/OS PASE shell and complete these steps:

- | 1. Call qp2term.
- | 2. Type the following commands:
  - | a. **cimconfig -s traceLevel=4**
  - | b. **cimconfig -s traceComponents=Thread, ProvManager**

| Similarly, to disable all tracing, type the following command: **cimconfig -s traceComponents=**

## | **Starting and stopping Universal Manageability Enablement CIMOM**

| After you install the required options and the licensed program, set the configuration properties, and grant users the authorizations, you can start Universal Manageability Enablement CIMOM.

| To start a CIMOM job, follow these steps:

- | 1. From iSeries™ Navigator, select **Network** → **Servers** → **User-Defined**.
- | 2. Select **CIMOM**. You can use this window to start or stop the CIMOM, and to determine whether the CIMOM starts with TCP/IP by default.

### | **Notes:**

- | 1. You can also use the STRTCPSVR \*CIMOM command to start the CIMOM job from the command-line interface.
- | 2. You can use the ENDTCPSVR \*CIMOM command to end the CIMOM job.

## | **Universal Manageability Enablement CIMOM security**

| You have several options to ensure that the CIM server is secure on the i5/OS operating system. In the Common Information Model Object Manager (CIMOM) function of the Universal Manageability Enablement for i5/OS licensed program, two types of security checks are available: authentication and authorization.

### | **Related concepts**

- | “cimconfig usage information” on page 26
- | You can configure the startup properties for Universal Manageability Enablement CIMOM with the cimconfig command.
- | Network authentication service
- | Host name resolutions considerations

## | **Authentication on Universal Manageability Enablement CIMOM**

| When a user request comes through HTTP or HTTPS, Universal Manageability Enablement CIMOM determines whether this is a legitimate user on the system. If the request does not pass the authentication, the request is rejected. If you set the enableAuthentication property to false, the CIMOM authentication function is disabled.

| *Local users* are users on a system who are sending requests to CIMOM on the same system. *Remote users* are users on a system who are sending requests to CIMOM on another system. By default, CIMOM uses Secure Sockets Layer (SSL) for all remote communications, with client-side and server-side certificates that are trusted by the management applications.

### | **Local user authentication**

| For local users, CIMOM uses a local authentication mechanism. CIMOM accepts the authentication that is already done by the system itself so that local requests include only the users' login names without their passwords. HTTP authentication is still used, but because the user is already logged in, no password is needed.

### | **Remote user authentication**

| Remote users are authenticated by HTTP basic authentication or HTTPS SSL peer certificate authentication. Configuration settings for the following properties determine which mechanisms are used:

- | • enableAuthentication
- | • enableHttpConnection
- | • enableHttpsConnection
- | • enableSslExportClientVerification
- | • httpAuthType
- | • sslClientVerificationMode

| For detailed information about the descriptions and default values of these properties, see the information about basic and advanced startup properties.

#### | **Related concepts**

| “Basic startup properties for Universal Manageability Enablement CIMOM” on page 8  
| You can change basic startup properties for IBM Universal Manageability Enablement CIMOM with the cimconfig command.

| “Advanced startup properties for Universal Manageability Enablement CIMOM” on page 10  
| You can change the advanced startup properties for the Universal Manageability Enablement CIM server with the cimconfig command. These properties are intended for use only by advanced CIMOM users.

## | **Authorization on Universal Manageability Enablement CIMOM**

| Authorization on the Universal Manageability Enablement CIMOM includes user authorization, command authorization, and object authorities.

#### | **Related concepts**

| “Basic startup properties for Universal Manageability Enablement CIMOM” on page 8  
| You can change basic startup properties for IBM Universal Manageability Enablement CIMOM with the cimconfig command.

| “Advanced startup properties for Universal Manageability Enablement CIMOM” on page 10  
| You can change the advanced startup properties for the Universal Manageability Enablement CIM server with the cimconfig command. These properties are intended for use only by advanced CIMOM users.

### | **User authorization on Universal Manageability Enablement CIMOM:**



| *User authorization* is a type of security check that verifies whether you have access to the objects you want to change. Authorization is needed not only for changing operations but sometimes for reading operations as well.

| The CIM operations can be divided into two kinds: operations that access the repository files that are owned by the CIM server, and operations that call the provider exit programs to manage system resources.

### | **Authorization to CIM class and qualifier operations**

| CIM class and qualifier operations change the local copy of the CIM schema. You must have the authority to these operations before you can perform these operations with systems management data that is provided by CIM. These operations do not change any i5/OS system objects, but they change the CIM schema. For the i5/OS operating system, Application Administration in iSeries Navigator controls authorization to these operations.

### | **Provider user context**

| Some CIM providers run as exit programs to the server. Providers dynamically load and call the CIM server to perform CIM operations. They are plug-ins and run in i5/OS Portable Application Solutions Environment (i5/OS PASE).

| The CIM server needs to run under QSECOFR authority to switch the user profile under which the providers are running. The providers can be run under the following user profiles:

- | • The profile of the requesting client.
- | • The profile of the CIM server.
- | • A designated profile.
- | • The root authority that is the QUMECIMOM object on the operating system.

| For more information, refer to the `forceProviderProcesses` property in the Advanced startup properties for Universal Manageability Enablement CIMOM topic.

| To set the user profile for the provider, the CIM server creates a new job for the provider, sets the user profile of that job, and runs the provider in that job.

| For security considerations, the CIM server writes an audit journal for security events, such as password check failure and special-authority check failure. An audit journal entry is created for each failure.

### | **Related concepts**

| “Basic startup properties for Universal Manageability Enablement CIMOM” on page 8  
You can change basic startup properties for IBM Universal Manageability Enablement CIMOM with the `cimconfig` command.

| “Advanced startup properties for Universal Manageability Enablement CIMOM” on page 10  
You can change the advanced startup properties for the Universal Manageability Enablement CIM server with the `cimconfig` command. These properties are intended for use only by advanced CIMOM users.

| “Object authorities” on page 21  
IBM Universal Manageability Enablement products are installed in the `UserData` and `ProdData` directories in the integrated file system and QUME library in the library file system. You need certain authorities to access these directories and this library.

| “i5/OS metrics classes” on page 94  
The topic describes metric classes and the user authorization.

### | **Related reference**

| “Backup and recovery considerations for Universal Manageability Enablement CIMOM” on page 24  
| It is important to schedule backups of the repository directories and files. If the repository is moved,  
| is lost, or becomes corrupted, restore the files that you have backed up.

| *Working with authorization for CIM operations:*

| You can use Application Administration to work with the authorization for CIM operations.

| To work with the authorization for CIM operations, follow these steps:

- | 1. From iSeries Navigator, expand *your system* → **Application Administration**.
- | 2. Select **Local Settings**, if available.
- | 3. Select **Host Applications** → **CIMOM server**.
- | 4. Add or remove a user or group’s authorization to the following operations.
  - | • CreateClass
  - | • DeleteClass
  - | • DeleteQualifier
  - | • EnumerateClasses
  - | • EnumerateClassNames
  - | • EnumerateQualifiers
  - | • GetClass
  - | • GetQualifier
  - | • ModifyClass
  - | • SetQualifier

| *Working with authorization for metrics classes of Universal Manageability Enablement CIM:*

| You can use Application Administration to work with the authorization for CIM metrics classes.

| To work with authorization for CIM metrics classes, follow these steps:

- | 1. From iSeries Navigator, expand *your system* → **Application Administration**.
- | 2. Select **Local Settings**, if available.
- | 3. Select **Host Applications** → **CIMOM server** → **System Management Operations** → **Access to the CIM Performance Provider**.
- | 4. Set the default authorization or add or remove a user or group’s authorization.

#### | **Related concepts**

| “i5/OS metrics classes” on page 94  
| The topic describes metric classes and the user authorization.

#### | **Command authorization:**

| You need to use the commands to modify the configuration of the Universal Manageability Enablement  
| CIM server. Command authorization is required.

| External command-line interfaces have PUBLIC \*X (UNIX® 701 permissions) and have a symbolic link in  
| the /QOpenSys/usr/bin directory.

| Most command-line interfaces act as a CIM client and communicate with the server through a local  
| connection. These clients authenticate to the server using the local authentication and then send the CIM  
| operation to the CIM server. The server authorizes the client to perform the CIM operation by checking

| whether the authenticated user has special authorities (for example, \*IOSYSCFG and \*ALLOBJ). For the  
| command-line interfaces that are not CIM clients, the special authority check is done in the command-line  
| interface itself.

| The cimmof command is an exception to this rule. This command uses the CIM client to modify the  
| repository files of the CIM server. Local authentication is used, but the server authorizes the cimmof  
| command caller to modify the repository based on the Application Administration settings. You do not  
| need to add special authority checks for these repository requests in addition to the Application  
| Administration checks.

#### | **Related concepts**

| “Object authorities”

| IBM Universal Manageability Enablement products are installed in the UserData and ProdData  
| directories in the integrated file system and QUME library in the library file system. You need certain  
| authorities to access these directories and this library.

#### | **Object authorities:**

| IBM Universal Manageability Enablement products are installed in the UserData and ProdData directories  
| in the integrated file system and QUME library in the library file system. You need certain authorities to  
| access these directories and this library.

#### | **Protection of the UserData directories**

- | • Base directory: /QOpenSys/QIBM/UserData/UME/Pegasus/
- | • CIM repository:
  - | – /QOpenSys/QIBM/UserData/UME/Pegasus/repository/
  - | – /QOpenSys/QIBM/UserData/UME/Pegasus/repository/root
  - | – /QOpenSys/QIBM/UserData/UME/Pegasus/repository/root#cimv2
  - | – /QOpenSys/QIBM/UserData/UME/Pegasus/repository/root#ibmsd
  - | – /QOpenSys/QIBM/UserData/UME/Pegasus/repository/root#PG\_Internal
  - | – /QOpenSys/QIBM/UserData/UME/Pegasus/repository/root#PG\_InterOp
- | • SSL stores:
  - | – /QOpenSys/QIBM/UserData/UME/Pegasus/ssl/
  - | – /QOpenSys/QIBM/UserData/UME/Pegasus/ssl/crlstore
  - | – /QOpenSys/QIBM/UserData/UME/Pegasus/ssl/exporttruststore
  - | – /QOpenSys/QIBM/UserData/UME/Pegasus/ssl/keystore
  - | – /QOpenSys/QIBM/UserData/UME/Pegasus/ssl/truststore
- | • Director mappings:
  - | – /QOpenSys/QIBM/UserData/UME/Pegasus/Mappings/
  - | – /QOpenSys/QIBM/UserData/UME/Pegasus/Mappings/Events
  - | – /QOpenSys/QIBM/UserData/UME/Pegasus/Mappings/Events/data
  - | – /QOpenSys/QIBM/UserData/UME/Pegasus/Mappings/Events/logs
  - | – /QOpenSys/QIBM/UserData/UME/Pegasus/Mappings/Inventory
  - | – /QOpenSys/QIBM/UserData/UME/Pegasus/Mappings/Inventory/mif
  - | – /QOpenSys/QIBM/UserData/UME/Pegasus/Mappings/Inventory/mif/data
  - | – /QOpenSys/QIBM/UserData/UME/Pegasus/Mappings/Inventory/sql
  - | – /QOpenSys/QIBM/UserData/UME/Pegasus/Mappings/Inventory/sql/data

| The base directory, /QOpenSys/QIBM/UserData/UME/Pegasus, is owned by QSYS; its access mode is  
| PUBLIC \*RX (755). It allows access to these directories and files through the CIMOM command-line  
| interface and CIM request interfaces.

## | Protection of the ProdData directories

- | • Libraries: /QOpenSys/QIBM/ProdData/UME/Pegasus/lib/
- | • Programs: /QOpenSys/QIBM/ProdData/UME/Pegasus/bin/
- | • IBM-supplied providers: /QOpenSys/QIBM/ProdData/UME/Pegasus/provider
- | • Messages:
  - | – /QOpenSys/QIBM/ProdData/UME/Pegasus/msg/pegasus
  - | – /QOpenSys/QIBM/ProdData/UME/Pegasus/msg/provider
  - | – /QOpenSys/QIBM/ProdData/UME/Pegasus/msg/ibm
- | • Schemas:
  - | – /QOpenSys/QIBM/ProdData/UME/Pegasus/Schemas/CIM
  - | – /QOpenSys/QIBM/ProdData/UME/Pegasus/Schemas/Pegasus/Internal
  - | – /QOpenSys/QIBM/ProdData/UME/Pegasus/Schemas/Pegasus/InterOp
  - | – /QOpenSys/QIBM/ProdData/UME/Pegasus/Schemas/Pegasus/ManagedSystem
  - | – /QOpenSys/QIBM/ProdData/UME/Pegasus/Schemas/OS400
- | • Mappings directories:
  - | – /QOpenSys/QIBM/ProdData/UME/Pegasus/Mappings/Events
  - | – /QOpenSys/QIBM/ProdData/UME/Pegasus/Mappings/Events/bin
  - | – /QOpenSys/QIBM/ProdData/UME/Pegasus/Mappings/Events/data
  - | – /QOpenSys/QIBM/ProdData/UME/Pegasus/Mappings/Events/lib
  - | – /QOpenSys/QIBM/ProdData/UME/Pegasus/Mappings/Inventory
  - | – /QOpenSys/QIBM/ProdData/UME/Pegasus/Mappings/Inventory/mib
  - | – /QOpenSys/QIBM/ProdData/UME/Pegasus/Mappings/Inventory/mib/bin
  - | – /QOpenSys/QIBM/ProdData/UME/Pegasus/Mappings/Inventory/mib/data
  - | – /QOpenSys/QIBM/ProdData/UME/Pegasus/Mappings/Inventory/mif
  - | – /QOpenSys/QIBM/ProdData/UME/Pegasus/Mappings/Inventory/mif/bin
  - | – /QOpenSys/QIBM/ProdData/UME/Pegasus/Mappings/Inventory/mif/data
- | • ICU Libraries: /QOpenSys/QIBM/ProdData/UME/ICU/icu-3.4.0/lib/

| All of the directories and files in the directories are owned by the QSYS property; its access mode is PUBLIC \*RX (755).

| Here are the directories that have internal server files:

- | • /QOpenSys/QIBM/ProdData/UME/Pegasus/bin/
- | • /QOpenSys/QIBM/ProdData/UME/Pegasus/lib/
- | • /QOpenSys/QIBM/ProdData/UME/Pegasus/provider/

| The access mode of the /lib/ directory is PUBLIC \*RX. Only the external files have access mode PUBLIC \*X. No files set the setuid bit.

| The access mode of the provider/ directory is PUBLIC \*RX. This directory only contains the IBM-included providers.

| **Note:** You can modify the configuration of the providerDir property to make the CIM server load the providers from the directory that is created by the providers. The created directory should have permission PUBLIC \*RX so that the providers can be loaded and run by any user.

| The access mode of the msg/ directory is PUBLIC \*RX. All files have permission PUBLIC \*R because providers are loading messages under the user authority.

| The Schemas/ directory and all files have permission PUBLIC \*RX. These are source files.

| The Mappings/ directory and all files have permission PUBLIC \*RX.

| **Protection of objects in the QUME library**

| *Table 3. Library objects*

Library objects	Object type	Public authentication	Description
QUME	*LIB	*USE	Principle licensed program (LP) library
QUME/QCIMMSG	*MSGF	*USE	Message file
QUME/QUME0029	*PRDL0D	*USE	Machine readable information (MRI) product load
QUME/QUME0050	*PRDDFN	*USE	Product definition
QUME/QUME0050	*PRDL0D	*USE	Machine readable material (MRM) product load
QUME/QUME2MIB	*PGM	*EXCLUDE	SNMP subagent
QUME/QUMECIMOM	*PGM	*EXCLUDE	Wrapper to start CIMOM
QUME/QUMECIMV2	*FILE	*EXCLUDE	root/cimv2
QUME/QUMECTLCIM	*PGM	*EXCLUDE	CIMOM control program that is called by TOC component during STR/ENDTCPSVR *CIMOM
QUME/QUMEIBMSD	*FILE	*EXCLUDE	root/ibmsd
QUME/QUMEJOB0D	*JOB0D	*EXCLUDE	Job description for server and SNMP subagent
QUME/QUMEMRIPGM	*PGM	*EXCLUDE	MRI installation exit program
QUME/QUMEMRMPGM	*PGM	*EXCLUDE	MRM installation exit program
QUME/QUMEPGINOP	*FILE	*EXCLUDE	root/PG_InterOp
QUME/QUMEPGINTL	*FILE	*EXCLUDE	root/PG_Internal
QUME/QUMEPGROOT	*FILE	*EXCLUDE	root
QUME/QUMEREC0VR	*PGM	*EXCLUDE	Recovery program
QUME/QUMESPSNDR	*SRVPGM	*USE	Check SNMP trap
QUME/QUMESTRSA	*PGM	*USE	Start or stop Simple Network Management Protocol (SNMP) subagent
QUME/QUMEUTIL	*SRVPGM	*USE	Audit log utility, *USE
QUME/QUMEUTILS	*SRVPGM	*EXCLUDE	Platform utilities (used by QUME2MIB and QUMESTRSA)

|  
| **Adopted owner authority**  
| The only objects that adopt owner authority are QUMECTLCIM \*PGM and QUMESTRSA \*PGM. The  
| owner of these programs is the QSYS object. The programs start and stop the CIM server or SNMP  
| subagent.

| QUMECTLCIM is the program that starts and stops the CIM server. This program has PUBLIC  
| \*EXCLUDE authority. QUMECTLCIM starts the server by submitting the QUMECIMOM server job.  
| QUMECTLCIM is called by QTOCSRVR and adopts the QSYS object owner authority to gain access to the  
| job description of the CIM server (QUMEJOBDD). The QUMEJOBDD job description sets the user of the  
| QUMECIMOM server job to QSECOFR.

| Similarly, the QUMESTRSA object is the \*PGM that starts and stops the SNMP subagent. This program  
| has PUBLIC \*USE authority so that it can be called by any user. The QUMESTRSA object starts the  
| subagent by submitting the QUME2MIB job. It adopts the QSYS object owner authority to gain access to  
| the job description of the subagent (QUMEJOBDD). The QUMEJOBDD job description sets the user of the  
| QUME2MIB server job to the QSECOFR object.

| **Related concepts**  
| “User authorization on Universal Manageability Enablement CIMOM” on page 18  
| *User authorization* is a type of security check that verifies whether you have access to the objects you  
| want to change. Authorization is needed not only for changing operations but sometimes for reading  
| operations as well.

| **Related reference**  
| “Command authorization” on page 20  
| You need to use the commands to modify the configuration of the Universal Manageability  
| Enablement CIM server. Command authorization is required.

## | **Backup and recovery considerations for Universal Manageability | Enablement CIMOM**

| It is important to schedule backups of the repository directories and files. If the repository is moved, is  
| lost, or becomes corrupted, restore the files that you have backed up.

| Here are the namespaces that are installed with CIMOM:

| **root** The root namespace conforms to the Distributed Management Task Force (DMTF) specifications.

| **root/cimv2**  
| This is for standard CIM schemas for the shipped providers.

| **root/PG\_InterOp**  
| This is for provider registration. This space is reserved exclusively for providers and all providers  
| must be registered.

| **root/PG\_Internal**  
| This space is reserved and used by CIMOM.

| **root/ibmsd**  
| The namespace is owned and used by IBM Director.


| IBM data and User data are stored in the CIM server UserData/ directory. You need to back up this  
| directory because applications or providers might change the files in the directory. You can run the  
| **backup** command to save the changed files since the last backup.

| Here are more details about the specific files and directories:

- The repository as a whole can be backed up, including any temporary transaction files.
- The server configuration file (current and planned) can be backed up.
- The configuration files are located under the /QOpenSys/QIBM/UserData/UME/Pegasus/ directory.
- The SSL files in the UserData/ directory are not IBM files. These files can be backed up, including the server certificate, the private key, and trust stores. However, the backup location should be secure.
- The mappings files in the UserData/ directory are not IBM files. These files can be backed up.
- The migration marker file is a user file that can be backed up.
- The trace files and log files are user files that can be backed up.

The Universal Manageability Enablement program has product files in its Proddata directory and includes the QUME product library. These files are backed up weekly.

#### Notes:

- It is important that you back up the /QOpenSys/QIBM/UserData/UME/Pegasus/repository directory structure regularly. If these files are deleted, moved, or corrupted, you need to restore them from the backup.
- To back up the SSL certificate files for CIMOM, use the OpenSSL command to create the certificates. For more detailed information about the command, see [OpenSSL](#) .
- If you do not back up the repository, you need to delete the repository and restart the CIM server. This sets the repository to the default state.

In CIMOM, IBM data and user data is intermingled as files or as data in the same directory. The following files contain both IBM and user data:

- All instance index files and instance data files. A typical example is the provider registration that contains both IBM and user data instances. Any providers that are developed by you are registered in the same files as the IBM-supplied providers.
- Instance association and class association files. These files keep track of associated classes or instances. Any associations that are created by you are stored in the same file as the IBM-supplied associations.
- Server configuration files.

If you need to recover the ProdData/ directory of the CIM server, reinstall the QUME product library. If you need to recover the IBM data in the UserData/ directory of the CIM server, reinstall the QUME library or recover these files from the backup media. If you need to recover the user data in the UserData/ directory of the CIM server, recover the destroyed files from the backup media.

#### Related concepts

“User authorization on Universal Manageability Enablement CIMOM” on page 18

*User authorization* is a type of security check that verifies whether you have access to the objects you want to change. Authorization is needed not only for changing operations but sometimes for reading operations as well.

#### Related information

Backing up your system

## Restoring corrupted files

Use this information if the backup copy of your CIM repository files are corrupted.

To recover your files, use the information in the following list:

#### Repository classes and qualifiers (static data)

1. Undo whatever was done to create the class or qualifier. For example, uninstall a client application or take manual steps to undo what was done.

2. Put the class or qualifier back the same way it was before. For example, reinstall a client application. If the problem persists, contact your service provider.

#### Repository instances

1. Undo whatever was done to create the instance. For example, uninstall a client application or take manual steps to undo what was done.
2. Put the class or qualifier back the same way it was before. For example, reinstall a client application. If the problem still exists, contact your service provider.

#### Provider registration data (also instances)

1. Use the cimprovider command to remove the provider registration.
2. Use the cimmof command to recompile and reregister the data. If the problem still exists, contact your service provider.

## Universal Manageability Enablement CIMOM command-line utilities

You can use a set of command-line utilities to control or change the CIMOM environment. The command-line utilities of Universal Manageability Enablement CIMOM include cimmof, cimconfig, cimprovider, and ssltrustmgr.

For the i5/OS implementation, the cimconfig and cimprovider commands require \*IOSYSCFG and \*ALLOBJ special authorities. The ssltrustmgr command requires \*ALLOBJ and \*SECADM special authorities. You do not need special authorities to run the cimmof command.

In CIMOM, you need to comply with the namespaces and with the authority checks that are based on the objects.

Run all of the command-line utilities from a command line or in i5/OS Portable Application Solutions Environment (i5/OS PASE).

#### Related tasks

“Configuring Universal Manageability Enablement CIMOM” on page 4

If you have installed the Universal Manageability Enablement for i5/OS licensed program, use this information to configure the Common Information Model Object Manager (CIMOM).

## cimconfig usage information

You can configure the startup properties for Universal Manageability Enablement CIMOM with the cimconfig command.

You can use this command to update the configuration setting. A symbolic link in the /QOpenSys/usr/bin directory for this command is provided. If you change the configuration properties that are in the planned configuration settings, the changes do not take effect until the CIM server is restarted.

**Name** cimconfig

Get, set, unset, or list CIMOM configuration properties.

#### Synopsis

Usage:

- cimconfig -g name [ -c ] [ -d ] [ -p ]
- cimconfig -s name=value [ -c ] [ -p ]
- cimconfig -l [ -c | -p ]
- cimconfig -u name [ -c ] [ -p ]
- cimconfig -h
- cimconfig --help
- cimconfig --version



## Remarks

The cimconfig command provides a command-line interface to manage CIMOM configuration properties:

- The first form of cimconfig provides the current, planned, and default value of the specified configuration property.
- The second form sets the current value and planned value of the specified configuration property to the specified value.
- The third form lists all the configuration properties.
- The fourth form resets the current and planned values of the specified configuration property to its default value.

## Options

The cimconfig command recognizes the following options:

### **-h, --help**

This option displays command help information.

### **--version**

This option displays the CIMOM version.

### **-g name**

This option gets the current value of the specified configuration property. It returns an error when CIMOM is not running.

### **-g name -c**

This option gets the current value of the specified configuration property. It returns an error when CIMOM is not running.

### **-g name -p**

This option gets the planned value of the specified configuration property.

### **-g name -d**

This option gets the default value of the specified configuration property. It returns an error when CIMOM is not running.

### **-s name=value**

This option indicates that a configuration property is added or updated by setting its current value to the specified value. It returns an error when CIMOM is not running or when the specified property cannot be updated dynamically.

### **-s name=value -c**

This option indicates that a configuration property is added or updated by setting its current value to the specified value. It returns an error when CIMOM is not running or when the specified property cannot be updated dynamically.

### **-s name=value -p**

This option indicates that a configuration property is added or updated by setting its planned value to the specified value.

### **-u name**

This option indicates that the current value of the specified configuration property is reset to the default value. It returns an error when CIMOM is not running or when the specified property cannot be updated dynamically.

### **-u name -c**

This option indicates that the current value of the specified configuration property is reset to the default value. It returns an error when CIMOM is not running or when the specified property cannot be updated dynamically.

- | **-u name -p** This option indicates that the planned value of the specified configuration property is reset to the default value.
- | **-l** This option displays the name of all the configuration properties. It returns an error when CIMOM is not running.
- | **-l -c** This option displays the name-and-value pair of all the current configuration properties. It returns an error when CIMOM is not running.
- | **-l -p** This option displays the name-and-value pair of all the planned configuration properties.

| **Note:** You can use the `cimconfig` command to set the current or planned configuration properties of CIMOM. You can update the current configuration properties only when CIMOM is running. All of the properties can be changed in the planned configuration properties whether or not CIMOM is running. If the planned configuration properties are changed, those changes do not take effect until CIMOM is restarted. When CIMOM is started, the planned configuration properties become the current configuration properties.

| **Related concepts**

| “Universal Manageability Enablement CIMOM security” on page 17

| You have several options to ensure that the CIM server is secure on the i5/OS operating system. In the Common Information Model Object Manager (CIMOM) function of the Universal Manageability Enablement for i5/OS licensed program, two types of security checks are available: authentication and authorization.

| **Related tasks**

| “Configuring Universal Manageability Enablement CIMOM” on page 4

| If you have installed the Universal Manageability Enablement for i5/OS licensed program, use this information to configure the Common Information Model Object Manager (CIMOM).

| **cimmof usage information**

| You can use this command to compile Managed Object Format (MOF) files. A symbolic link in the `/QOpenSys/usr/bin` directory for this command is provided.

| **Name** `cimmof`

| This command compiles CIM class description (using the MOF language) files into a class schema that is stored in a repository through the CIM server. This command only works when the CIM server is running.

| **Synopsis**

| Usage:

| `cimmof -h | --help`

| `cimmof --version`

| `cimmof [ -w ] [ -E ] [ -uc ] [ -aE | -aV | -aEV ] [ -I path ] [ -n namespace ]`  
 | `[--namespace namespace] [--xml][--trace] [mof_file ...]`

| **Description**

| The `cimmof` command is the command line interface to the MOF compiler. The MOF compiler is a utility that compiles MOF files into CIM classes and instances that are stored in the CIM repository. You can use this command to compile MOF files at any time after installation. If no input file is specified, standard input is used. You need to provide the MOF file name in the message that is shown.

| The MOF compiler requires that the input MOF files exist in the current directory or that a fully qualified path be given. To simplify the specification of multiple MOF files in the `cimmof` command line, the MOF compiler allows compiling from files that contain a list of MOF files using the following include pragmas:

- #pragma include (application.mof)
- #pragma include (server.mof)

MOF files that use the include pragma must be in the current directory or in a directory specified by the -I command line option. The -n option can be used to specify an R namespace in which the CIM classes and instances are compiled. If this option is not specified, the default R namespace is root/cimv2.

## Options

### **-h, --help**

This option displays command usage information.

### **--version**

This option displays CIM server version.

**-E** This option performs a syntax check on the input. This option does not update the repository.

**-w** This option suppresses warning messages. If the CIM elements (such as classes, instances, properties, or methods) that are defined in the MOF files exist in the CIM repository, the cimmo command returns warning messages.

**-uc** This option allows the update of an existing class definition. This option enables you to update a leaf class. It does not allow updates of superclasses or classes that have subclasses.

**-aE** This option allows experimental schema changes.

**-aV** This option updates a class that results in a version change. This option allows the major version of the class to be changed, allows the version to be degraded or allows the version to be removed. The version must be specified in a valid format. The format is *m.n.u* where *m* is a major version, *n* is a minor release, and *u* is an update. For example, 2.7.0 is a valid format for CIM schema 2.7.0. If the input class has the same version as the class in the repository, the class is not updated.

**-aEV** This option allows both experimental and version schema changes.

### **-I <path>**

This option specifies the path to include MOF files. This path might be relative or absolute.

**-n** This option overrides the default CIM repository namespace. The namespace that is specified must be a valid CIM namespace name. For provider registration schemas, the namespace that is specified must be root/PG\_InterOp.

### **--namespace**

This option overrides the default CIM repository namespace. The namespace that is specified must be a valid CIM namespace name. For provider registration schemas, the namespace that is specified must be root/PG\_InterOp.

**--xml** This option generates Extensible Markup Language (XML) to a standard output format. This option does not update the repository.

**--trace** This option writes the trace information to a file. The output destination is a standard output format.

## EXIT STATUS

The cimmo command returns one of the following values:

- 0** Success
- 1** Error

## Examples

### **cimmof processInfo.mof**

It compiles an MOF file into the default namespace in the CIM repository and issues the cimmof command with no options.

### **cimmof -n root/application test1.mof test2.mof**

It compiles the MOF files into the root/application namespace.

### **cimmof -w -I. /MOF MOF/CIMSchema25.mof**

It compiles the MOF file that is defined in the . /MOF directory with the name CIM-Schema25.mof and that contains include pragmas for other MOF files also in the . /MOF directory.

### **cimmof -h**

It displays usage information for the cimmof command.

## cimprovider usage information

You can use this command to enable or disable a registered provider. A symbolic link in the /QOpenSys/usr/bin directory for this command is provided. You need to ensure that Universal Manageability Enablement CIMOM is running when you use this command.

**Name** cimprovider

Disable, enable, remove, or list registered CIM providers or one CIM provider module and module status.

### Synopsis

Usage:

- cimprovider -d -m module
- cimprovider -e -m module
- cimprovider -r -m module [ -p provider ]
- cimprovider -l [ -s | -m module ]
- cimprovider -h
- cimprovider --help

### Limitations

This command disables, enables, or removes only one CIM provider module or CIM provider at a time.

### Description

If a CIM provider is disabled, CIMOM rejects any requests to the provider. If a CIM provider is enabled, CIMOM forwards requests to the provider. If a CIM provider is unregistered, CIMOM no longer has any information about the provider:

- The first form of the cimprovider command disables the specified provider module. When a specified provider module is in the disabled state, any new requests to the providers that are contained in the specified provider module are rejected.
- The second form enables the providers that are contained in the specified provider module. The providers are now ready to accept new requests.
- The third form removes the specified provider module and all of its providers, or removes the specified provider in the specified provider module.
- The fourth form lists all the registered provider modules and module status, or lists the providers in the specified provider module.

### Options

**-h, --help**

The option displays command help information.

|       **--version**  
|           The option displays the CIMOM version.

|       **-d**     The option disables the specified CIM provider module. If the module is already  
|           disabled, an error message is returned.

|       **-e**     The option enables the specified CIM provider module. If the module is already enabled  
|           or is currently being disabled, an error message is returned.

|       **-r**     The option removes the specified provider module and all of its contained providers. If a  
|           provider is specified, it removes the specified provider in the specified provider module  
|           without affecting any other providers in that module.

|       **-l**     The option displays all the registered provider modules.

|       **-m Module**  
|           The option specifies the provider module for the operation.

|       **-p Provider**  
|           The option specifies the provider for the operation.

|       **-s**     The option displays the status of provider modules.

## | **Examples**

| **cimprovider -d -m myProviderModule**  
|       It disables provider module myProviderModule and all of its contained providers (placing them in  
|       a stopped state).

| **cimprovider -e -m myProviderModule**  
|       It enables provider module myProviderModule and all of its contained providers (placing them in  
|       an OK state).

| **cimprovider -r -m myProviderModule**  
|       It removes (unregisters) the myProviderModule provider module and all of its contained providers.

| **cimprovider -r -m myProviderModule -p MyProvider**  
|       It removes the MyProvider provider that is contained in the myProviderModule provider module.

| **cimprovider -l**  
|       It lists the registered provider modules.

| **cimprovider -l -s**  
|       It lists the registered provider modules and their status (such as OK, Stopping, Stopped).

| **cimprovider -l -m myProvider**  
|       It lists the registered providers that are in the myProviderModule provider module.

## | **ssltrustmgr usage information**

| The ssltrustmgr command provides a command-line interface to manage X.509 certificates in a truststore  
| or in a certificate revocation list (CRL).

| To run the ssltrustmgr command from an i5/OS PASE command line, you must install the i5/OS Portable  
| Application Solutions Environment (i5/OS PASE) feature on the system. Make sure that the CIM server is  
| running when you run this command from the /QOpenSys/usr/bin directory.

| **Name** ssltrustmgr

|       This command requires \*ALLOBJ and \*SECADM authorities to display or change the SSL  
|       truststores.

### | **Synopsis**

|       Usage:

|       ssltrustmgr -a -c certuser -f certfile

```

|      ssltrustmgr -a -f certfile
|      ssltrustmgr -a -R -f crlfile
|      ssltrustmgr -h | --help
|      ssltrustmgr -l [-i issuername [-n serialnumber]]
|      ssltrustmgr -l -R [-i issuername]
|      ssltrustmgr -r -i issuername -n serialnumber
|      ssltrustmgr -r -R -i issuername
|      ssltrustmgr -v | --version

```

## | Description

| If the truststore or the CRL store does not exist, or if they are not in a directory format, the command exits with errors.

## | Options

```

|      -a      This option adds the specified certificate to a target truststore, a trustpath, or a CRL store.
|      -r      This option removes the certificate that matches the serial number that is issued by the
|              issuer name from the target truststore or trustpath.
|      -l      This option displays the X.509 certificates in the target truststore or trustpath.
|      -R      This option indicates that the requested add, remove, or list operation is performed on
|              the CRL store.
|
|      -f certfile/crlfile
|              This option specifies a Privacy Enhanced Mail (PEM) format file that contains an X.509
|              certificate or a CRL.
|
|      -c certuser
|              This option specifies a user name to be associated with the specified certificate. The user
|              name that is specified should be a valid system user on the target system.
|
|      -i issuername
|              This option specifies a certificate or a CRL issuer name.
|
|      -n serialnumber
|              This option specifies a certificate serial number.
|
|      -h | --help
|              This option displays the command help message.
|
|      -v | --version
|              This option displays the CIMOM number.

```

## | EXIT STATUS

| When an error occurs, an error message is written to a standard error format, and an error value of 1 is returned.

```

|      0      Success
|      1      Error

```

## | Examples

```

|      ssltrustmgr -a -c john -f cert.pem
|      It adds the X.509 certificate in the cert.pem file to the truststore on CIMOM, and associates the
|      user tag with the certificate.

```

```

| ssltrustmgr -a -R -f class1crl.pem or ssltrustmgr -aR -f class1crl.pem
|     It adds the CRL in class1crl.pem to the CRL on CIMOM.
|
| ssltrustmgr -r -i "/C=US/ST=California/L=Cupertino/O=Smart & Secure/OU=Secure Software
| Division/CN=dev.admin.ss.com" -n 01
|     It removes the certificate that matches the specified issuer name and serial number from the
|     cim_trust trust store.
|
| ssltrustmgr -l
|     It lists all the X.509 certificates in the trust store.
|
| ssltrustmgr -lR -i "/C=US/ST=California/L=Cupertino/O=Smart & Secure/OU=Secure Software
| Division/CN=dev.admin.ss.com"
|     It lists the CRL that is issued by the issuer name: /C=US/ST=California/L=Cupertino/O=Smart
|     & Secure/OU=Secure Software Division/CN=dev.admin.ss.com

```

## Reference information for Universal Manageability Enablement CIM

This topic lists the functions supported by the Common Information Model Object Manager (CIMOM) function of the IBM Universal Manageability Enablement for i5/OS licensed program and provides details about various CIM providers and classes.

The following CIMOM functions are supported:

- **Large address-space models**

The Universal Manageability Enablement program can use a maximum of 8 segments or 2 GB memory.

- **Secure Sockets Layer support**

Secure Sockets Layer (SSL) is supported both for the connections with a CIM export client and for external connections over SSL-secured ports for CIM client connections. CIMOM supports the following ports:

- wbem-https port (5989 by default)
- wbem-exp-https port (5990 by default)

**Note:** The original wbem-http port (5988 by default) is also supported.

In addition to the support for SSL-secured data transmission, i5/OS Portable Application Solutions Environment (i5/OS PASE) also supports SSL certificate-based client authentication on CIM requests from CIM clients and supports the CIM exports carrying indication data. You can configure SSL certificate-based client authentication as follows:

- When the exclusive type of authentication mechanism is used (basic authentication is not used), only SSL certificate-based authentication is allowed. SSL data encryption is used.
- The client is requested to provide a certificate; if one is not provided, the httpAuthType setting is used for basic authentication. SSL data encryption is still used.
- SSL certificate-based client authentication can be disabled. It means that only the httpAuthType setting (basic authentication) is used.

With these options, SSL can be used for both authentication and data encryption, or just for data encryption.

- **Common Manageability Programming Interface support**

*Common Manageability Programming Interface (CMPI)* defines a common C-based resource extension interface. Resource extensions can be reused in any management server environment supporting this interface. CMPI is implemented such that the provider can run with any CIM server, not just with Pegasus. The providers use CMPI instead of the Pegasus C/C++ interface. Currently, CMPI supports instance, method, association, and indication providers.

- **Out-of-process provider support**

*Out-of-process (OOP)* isolates the providers from the main CIM server by running them in a separate process. All providers are OOP providers for reliability, performance, and security reasons. With OOP,

| the CIM server does not crash due to a provider crash. Also, the CIM server has granular security control over providers. If one process crashes, it does not cause the crash of other processes and can recover when the next request for that given provider module comes in.

| • **DMTF schema 2.14**

| Schema 2.14 contains both experimental and final builds of the schema. This provides you with early access to experimental parts of the model that do not have sufficient implementation experience to be included in the final schema. Experimental elements might change in a backward-incompatible way.

| • **SNMP support**

| The Universal Manageability Enablement program provides an SNMP subagent as a bridge between CIMOM and the SNMP server.

| To start the SNMP subagent, use the `call qume/qumestrsa` command.

| To stop the SNMP subagent, use the `call qume/qumestrsa stop` command.

| When the SNMP subagent starts up, it registers itself to the SNMP server. The SNMP server forwards the request from the SNMP client to the subagent. After the subagent receives the SNMP request, the subagent can translate it to the CIM operation. Then the SNMP subagent is connected to the CIM server through the CIM client and sends the CIM operation.

| • **SLP support**

| The CIM server supports self-registration with the SLP service agent. Both the IPv4 and IPv6 wildcard addresses are available on the CIM server. The server binds to more than one network interface, so the registrations in the Service Agent contain multiple entries. The registration contains a URL that locates the CIM server.

| IPv4 example

| URL: `service:wbem:https://9.186.110.61:5989`

| ATTR: `(template-url-syntax=service:wbem:https://9.186.110.61:5989)`

| IPv6 example

| URL: `service:wbem:https://[3FFE:1::130]:5989`

| ATTR: `(template-url-syntax=service:wbem:https://[3FFE:1::130]:5989)`

| **Related information**

|  [Common Information Model \(CIM\) Standards](#)

|  [The Open Group: OpenPegasus](#)

|  [CIM Schema: Version 2.14](#)

| **Compatibility to V5R3 and V5R4 operating system CIM providers**

| Classes that are supplied with the IBM Universal Manageability Enablement for i5/OS licensed program are registered into namespace `root/cimv2`. Some Universal Manageability Enablement CIM providers that are ported from V5R3 and V5R4 operating system CIM providers are also registered into namespace `root/ibmsd` with a different class name.

| These LP-supplied CIM classes that are registered in namespace `root/ibmsd` have the same parent class and the same properties, and they share the same implementation as classes that are registered in namespace `root/cimv2`. Only the prefixes of class name are different. This makes these CIM providers that are supplied with the Universal Manageability Enablement for i5/OS licensed program compatible to V5R3 and V5R4 operation system CIM providers. In i5/OS V5R3 and V5R4, the operating system CIM classes are registered into namespace `root/ibmsd`.

| The following table shows the class map in namespace `root/ibmsd` and `root/cimv2`.

| *Table 4. Class map in root/ibmsd and root/cimv2*

Class names in root/ibmsd	Class names in root/cimv2
IBMP5G_BaseBoard	IBM_BaseBoard



Table 4. Class map in root/ibmsd and root/cimv2 (continued)

Class names in root/ibmsd	Class names in root/cimv2
IBMPDG_Chassis	IBM_Chassis
IBMPDG_ComputerSystem	IBMOS400_ComputerSystem
IBMPDG_ComputerSystemDetails	IBM_ComputerSystemDetails
IBMPDG_DirectorAgent	IBM_DirectorAgent
IBMPDG_FRU	IBM_FRU
IBMPDG_Group	IBM_Group
IBMPDG_Lease	IBM_Lease
IBMPDG_NetworkAdapterConfiguration	IBM_NetworkAdapterConfiguration
IBMPDG_NetworkID	IBM_NetworkID
IBMPDG_OperatingSystem	IBMOS400_OperatingSystem
IBMPDG_PhysicalDisk	IBM_PhysicalDisk
IBMPDG_PhysicalMemory	IBM_PhysicalMemory
IBMPDG_PhysicalNetworkAdapter	IBM_PhysicalNetworkAdapter
IBMPDG_Port	IBM_Port
IBMPDG_Processor	IBM_Processor
IBMPDG_SerialNumberInformation	IBM_SerialNumberInformation
IBMPDG_SNMPConfiguration	IBM_SNMPConfiguration
IBMPDG_UserAccount	IBM_UserAccount
IBMPDG_Warranty	IBM_Warranty

### Providers that are inherited from the operating system

Providers are moved out of the operating system to be ported to i5/OS Portable Application Solutions Environment (i5/OS PASE). This topic describes the implemented CIM class, provider types, and categories for these providers. It also introduces properties, property descriptions, and values of each provider.

Table 5. Providers that are inherited from the operating system

Provider name	Implements CIM class	Provider type	Category
QUME_BootOSFromFSProvider	IBM_BootOSFromFS	Instance and association	OSBase
QUME_ChassisProvider	IBMPDG_Chassis	Instance	Hardware
QUME_ColSrvMetricDefinitionProvider	IBMOS400_ColSrvMetricDefinition IBMOS400_ColSrvMetricDefForME	Instance and association	csMetric
QUME_ColSrvMetricValueProvider	IBMOS400_ColSrvMetricValue IBMOS400_ColSrvMetricInstance IBMOS400_ColSrvMetricForME CIM_InstModification	Instance, association, and indication	csMetric
QUME_ComputerSystemDetailsProvider	IBMPDG_ComputerSystemDetails	Instance	Config
QUME_ComputerSystemProvider	IBMOS400_ComputerSystem IBMPDG_ComputerSystem	Instance	OSBase

Table 5. Providers that are inherited from the operating system (continued)

Provider name	Implements CIM class	Provider type	Category
QUME_CSBaseBoardProvider	IBM_CSBaseBoard	Instance and association	OSBase
QUME_CSNetworkPortProvider	IBM_CSNetworkPort	Instance and association	Network
QUME_CSVirtualProcessorProvider	IBMOS400_CSVirtualProcessor	Instance and association	OSBase
QUME_DirectorAgentProvider	IBMPSG_DirectorAgent	Instance	Software
QUME_DirectorConsumer	/	Consumer	Consumer
QUME_DirectorGroupProvider	IBMPSG_Group	Instance and method	User
QUME_DirectorLeaseEventProvider	IBMPSG_LeaseExpirationEvent	Indication	Event
QUME_DirectorLeaseProvider	IBMPSG_Lease	Instance	Config
QUME_DirectorNetAdaptCfgProvider	IBMPSG_NetworkAdapterConfiguration	Instance and method	Network
QUME_DirectorNetworkIDProvider	IBMPSG_NetworkID	Instance and method	Network
QUME_DirectorUserProvider	IBMPSG_UserAccount	Instance and method	User
QUME_DirectorWarrantyEventProvider	IBMPSG_WarrantyExpirationEvent	Indication	Event
QUME_DirectorWarrantyProvider	IBMPSG_Warranty	Instance	Config
QUME_DiskDriveProvider	IBMPSG_PhysicalDisk	Instance	Hardware
QUME_EthernetPortProvider	IBM_EthernetPort	Instance	Network
QUME_HealthConsumer	IBMPSG_ComponentHealth	Consumer	Consumer
QUME_HostedFileSystemProvider	IBM_HostedFileSystem	Instance and association	OSBase
QUME_IPProtocolEndpointProvider	IBM_IPProtocolEndpoint	Instance	Network
QUME_LocalFileSystemProvider	IBM_LocalFileSystem	Instance	OSBase
QUME_LogConsumer	/	Consumer	Consumer
QUME_NetworkEventProvider	IBMPSG_NetworkAdapterFailedEvent IBMPSG_NetworkAdapterOfflineEvent IBMPSG_NetworkAdapterOnlineEvent	Indication	Event
QUME_NetworkFileSystemProvider	IBM_NFS	Instance	OSBase
QUME_NetworkPortProvider	IBMOS400_NetworkPort	Instance	Network
QUME_NWPortImplProtocolEpProvider	IBM_NWPortImplementsIPEndpoint	Instance and association	Network

Table 5. Providers that are inherited from the operating system (continued)

Provider name	Implements CIM class	Provider type	Category
QUME_OperatingSystemProvider	IBMOS400_OperatingSystem IBMPSG_OperatingSystem	Instance and method	OSBase
QUME_OSProcessProvider	IBMOS400_OSProcess	Instance and association	OSBase
QUME_PhysicalMemoryProvider	IBMPSG_PhysicalMemory	Instance	Hardware
QUME_PhysicalNetworkAdapterProvider	IBMPSG_PhysicalNetworkAdapter	Instance	Hardware
QUME_PhysicalPortProvider	IBMPSG_Port	Instance	Hardware
QUME_ProcessorProvider	IBMPSG_Processor	Instance	Hardware
QUME_ProcessProvider	IBMOS400_Process	Instance	OSBase
QUME_RemoteFileSystemProvider	IBM_RemoteFileSystem	Instance	OSBase
QUME_ReplacementFRUProvider	IBMPSG_FRU	Instance	Hardware
QUME_RunningOSProvider	IBMOS400_RunningOS	Instance and association	OSBase
QUME_SerialNumberProvider	IBMPSG_SerialNumberInformation	Instance	Hardware
QUME_SNMPConfigurationProvider	IBMPSG_SNMPConfiguration	Instance	Config
QUME_SnmpConsumer	/	Consumer	Consumer
QUME_StorageEventProvider	IBMPSG_StorageEvent	Indication	Event
QUME_SystemPackageProvider	IBM_BaseBoard IBMPSG_BaseBoard	Instance	OSBase
QUME_TecConsumer	/	Consumer	Consumer
QUME-TokenRingPortProvider	IBM-TokenRingPort	Instance	Network
QUME_VirtualProcessorProvider	IBMOS400_VirtualProcessor	Instance	OSBase

## IBMPSG\_ComputerSystem

This provider makes available basic information about the computer system, such as computer name and status information.

Table 6. IBMPSG\_ComputerSystem

Property	Property value and data source
string OtherIdentifyingInfo[]	This property returns the following system information: <ul style="list-style-type: none"> <li>Type</li> <li>Serial number</li> <li>Model</li> <li>Partition identifier</li> </ul>
Name	The system name based on the first entry in the TCP/IP host table.

## IBMPSG\_BaseBoard

The provider looks up a resource based on the physical resource name that is provided as the key under the Tag property, and returns instances of all backplanes that are available on the system.

Table 7. IBMPSG\_BaseBoard

Property name	Property description	Value or value location
boolean HostingBoard	A property that indicates that this card is a system board, or more generically, a baseboard in a chassis.	TRUE
boolean PoweredOn	A property that indicates whether the physical element is powered on.	
boolean Removable	A property that indicates whether a physical package is removable.  A physical package is removable if it can be taken in and out of the physical container without impairing the function of the overall packaging.	TRUE
boolean Replaceable	A property that indicates whether a physical package is replaceable.  A physical package is replaceable if the element can be replaced with a physically different one.	TRUE
string Caption (64)	A short textual description of the object.	Baseboard <i>ElementName</i>
string CreationClassName (key) (256)	The name of the class or the subclass that is used in the creation of an instance.	IBMPSG_BaseBoard
string Description	A class that is derived from the card to deliver the system's baseboard hardware information.	Baseboard information for <i>ElementName</i>
string ElementName	A user-friendly name of the object.	<i>Name</i>
string Model (256)	The name by which the physical element is generally known.	
string Name (1024)	The label by which the object is known.	
string PartNumber (256)	The part number assigned by the organization that is responsible for producing or manufacturing the physical element.	
string Product	The baseboard part number.	Manufacturer IBM
string SerialNumber (256)	A manufacturer-allocated number that is used to identify the physical element.	
string StatusDescriptions[]	Various OperationalStatus array values.	
string Tag (key) (256)	An arbitrary string that uniquely identifies the physical element and serves as the element's key.	IBM: <i>Model:SerialNumber</i>
uint16 OperationalStatus[]	The current status of the element.	

## IBMPSG\_Chassis

The provider looks up a resource based on the physical resource name that is provided as the key under the Tag property, and returns instances of all frames that are available on the system.

Table 8. IBMPSG\_Chassis

Property name	Property description	Value or value location
boolean AudibleAlarm	A property that indicates whether the frame is equipped with an audible alarm.	FALSE
boolean CanBeFRUed	A property that indicates whether this physical element is a field replaceable unit (TRUE) or not (FALSE).	
boolean IsLocked	A property that indicates whether the frame is currently locked.	FALSE
boolean LockPresent	A property that indicates whether the frame is protected with a lock.	FALSE
boolean PoweredOn	A property that indicates whether the physical element is powered on.	
boolean Removable	A property that indicates whether a physical package is removable.  A physical package is removable if it can be taken in and out of the physical container without impairing the function of the overall packaging.	TRUE
boolean Replaceable	A property that indicates whether a physical package is replaceable.  A physical package is replaceable if the element can be replaced with a physically different one.	TRUE
boolean VisibleAlarm	A property that indicates whether the equipment includes a visible alarm.	FALSE
string Caption (64)	A short textual description of the object.	Chassis <i>ElementName</i>
string CreationClassName (key) (256)	The name of the class or the subclass that is used in the creation of an instance.	IBMPSG_Chassis
string Description	A textual description of the object.	Chassis information for <i>ElementName</i>
string ElementName	A user-friendly name of the object.	<i>Name</i>
string Model (256)	The name by which the physical element is generally known.	
string Name (1024)	The label by which the object is known.	
string PartNumber (256)	The part number assigned by the organization that is responsible for producing or manufacturing the physical element.	
string SerialNumber (256)	A manufacturer-allocated number that is used to identify the physical element.	
string StatusDescriptions[]	Various OperationalStatus array values.	

Table 8. IBMPSG\_Chassis (continued)

Property name	Property description	Value or value location
string Tag (key) (256)	An arbitrary string that uniquely identifies the physical element and serves as the element's key.	Name
uint16 HealthState	The current health of the element.	
uint16 OperationalStatus[]	The current status of the element.	
uint16 PackageType	The type of the physical package.	9 Module or Card
uint16 SecurityBreach	An enumerated, integer-valued property that indicates that a physical breach of the frame was attempted but unsuccessful (value=4) or attempted and successful (value=5).	2 (Unknown)

## IBMPSG\_FRU

The provider looks up a resource based on the physical resource name that is provided as the key under the Name property, and returns instances of physical resources with FRU numbers that are available on the system.

Table 9. IBMPSG\_FRU

Property name	Property description	Value or value location
string Caption (64)	A short textual description of the object.	Field replaceable unit <i>ElementName</i>
string Description	A textual description of the object.	Field replaceable unit information for <i>ElementName</i>
string ElementName	A user-friendly name for the object.	Name
string FRUNumber (key) (64)	FRU ordering information.	
string IdentifyingNumber (key) (64)	FRU identification, such as a serial number on software or a die number on a hardware chip.	
string Name (256)	FRU name.	
string Vendor (key) (256)	The name of the FRU's supplier.	IBM

## IBMPSG\_PhysicalDisk

The provider looks up a resource based on the logical resource name that is provided as the key under the DeviceID property, and returns instances of logical disk units that are available on the system.

Table 10. IBMPSG\_PhysicalDisk

Property name	Property description	Value or value location
boolean MediaIsLocked	A property that indicates whether the media is locked in the device and cannot be ejected.  For devices that cannot be removed, this value should be TRUE.	TRUE

Table 10. IBMPSG\_PhysicalDisk (continued)

Property name	Property description	Value or value location
int16 Security	An enumeration that indicates the operational security that is defined for the media access device.  For example, information that the device is Read-only (value=4) or information about Boot Bypass (value=6) can be described in this property.	2 (Unknown)
string Caption (64)	A short textual description of the object.	Disk <i>ElementName</i>
string CreationClassName (key) (256)	The name of the class or the subclass that is used in the creation of an instance.	IBMPSG_PhysicalDisk
string Description	A textual description of the object.	Disk information for <i>ElementName</i>
string DeviceID (key) (64)	An address or other identifying information to uniquely name the logical device.	<i>Name</i>
string ElementName	A user-friendly name of the object.	<i>Name</i>
string Name (1024)	The label by which the object is known.	
string OtherEnabledState	A string that describes the element's enabled or disabled state when the EnabledState property is set to 1.	Powered off or not connected
string StatusDescriptions[]	Various OperationalStatus array values.	
string SystemCreationClassName (key) (256)	The scoping system's CreationClassName.	IBMPSG_ComputerSystem
string SystemName (key) (256)	The scoping system's name.	
uint16 Availability	The primary availability and status of the device.	
uint16 EnabledDefault	An enumerated value that indicates an administrator's default configuration for an element's EnabledState.	7 (No Default)
uint16 EnabledState	An integer enumeration that indicates the enabled or disabled states of an element.	
uint16 HealthState	The current health of the element.	
uint16 OperationalStatus[]	The current status of the element.	
uint16 RequestedState	An integer enumeration that indicates the last requested or desired state for the element.	5 (No change)
uint64 DefaultBlockSize	The default block size (in bytes) for this device.	
uint64 MaxBlockSize	The maximum block size (in bytes) for media that are accessed by this device.	

Table 10. IBMPSG\_PhysicalDisk (continued)

Property name	Property description	Value or value location
uint64 MaxMediaSize	The maximum size (in KB) of media that are supported by this device.	

## IBMPSG\_PhysicalMemory

The provider looks up a resource based on the physical resource name that is provided as the key under the Tag property, and returns instances of all physical memory resources that are available on the system.

Table 11. IBMPSG\_PhysicalMemory

Property name	Property description	Value or value location
boolean CanBeFRUed	A property that indicates whether this physical element is a field replaceable unit (TRUE) or not (FALSE).	
boolean HasError	A property that indicates whether the memory currently has an error condition.	
boolean IsActive	A property that indicates whether the memory is currently active.	
boolean PoweredOn	A property that indicates whether the physical element is powered on.	
boolean Removable	A property that indicates whether a physical component is removable.  A physical component is removable if it can be taken in and out of the physical container without impairing the function of the overall packaging.	TRUE
boolean Replaceable	A property that indicates whether a physical component is replaceable.  A physical component is replaceable if the element can be replaced with a physically different one.	TRUE
string Caption (64)	A short textual description of the object.	Physical memory <i>ElementName</i>
string CreationClassName (key) (256)	The name of the class or the subclass that is used in the creation of an instance.	IBMPSG_PhysicalMemory
string Description	A textual description of the object.	Physical memory information for <i>ElementName</i>
string ElementName	A user-friendly name of the object.	<i>Name</i>
string Model (256)	The name by which the physical element is generally known.	
string Name (1024)	The label by which the object is known.	
string PartNumber (256)	The part number assigned by the organization that is responsible for producing or manufacturing the physical element.	



Table 11. IBMPSG\_PhysicalMemory (continued)

Property name	Property description	Value or value location
string SerialNumber (256)	A manufacturer-allocated number that is used to identify the physical element.	
string StatusDescriptions[]	Various OperationalStatus array values.	
string Tag (key) (256)	An arbitrary string that uniquely identifies the physical element and serves as the element's key.	<i>Name</i>
uint16 HealthState	The current health of the element.	
uint16 MemoryType	The type of physical memory.	
uint16 OperationalStatus[]	The current status of the element.	
uint32 PositionInRow	The position of the physical memory in a row.	
uint64 Capacity	The total capacity of this physical memory (in bytes).	

## IBMPSG\_PhysicalNetworkAdapter

The provider looks up a resource based on the physical resource name that is provided as the key under the Tag property, and returns instances of all physical network adapter resources that are available on the system.

Table 12. IBMPSG\_PhysicalNetworkAdapter

Property name	Property description	Value or value location
boolean CanBeFRUed	A property that indicates whether this physical element is a field replaceable unit (TRUE) or not (FALSE).	
boolean HostingBoard	A property that indicates whether this card is a motherboard, or, more generically, a baseboard in a chassis.	FALSE
boolean PoweredOn	A property that indicates whether the physical element is powered on.	
boolean Removable	A property that indicates whether a physical package is removable.  A physical package is removable if it can be taken in and out of the physical container without impairing the function of the overall packaging.	TRUE

Table 12. IBMPSG\_PhysicalNetworkAdapter (continued)

Property name	Property description	Value or value location
boolean Replaceable	A property that indicates whether a physical package is replaceable.  A physical package is replaceable if the element can be replaced with a physically different one.	TRUE
string Caption (64)	A short textual description of the object.	Physical network adapter <i>ElementName</i>
string CreationClassName (key) (256)	The name of the class or the subclass that is used in the creation of an instance.	IBMPSG_PhysicalNetworkAdapter
string Description	A textual description of the object.	Physical network adapter information for <i>ElementName</i>
string ElementName	A user-friendly name of the objects	<i>Name</i>
string Model (256)	The name by which the physical element is generally known.	
string Name (1024)	The label by which the object is known.	
string PartNumber (256)	The part number assigned by the organization that is responsible for producing or manufacturing the physical element.	
string SerialNumber (256)	A manufacturer-allocated number that is used to identify the physical element.	
string StatusDescriptions[]	Various OperationalStatus array values.	
string Tag (key) (256)	An arbitrary string that uniquely identifies the physical element and serves as the element's key.	<i>Name</i>
uint16 HealthState	The current health of the element.	
uint16 OperationalStatus[]	The current status of the element.	

## IBMPSG\_Port

The provider looks up a resource based on the physical resource name that is provided as the key under the Tag property, and returns instances of all physical ports that are available on the system.

Table 13. IBMPSG\_Port

Property name	Property description	Value or value location
boolean CanBeFRUed	A property that indicates whether this physical element is a field replaceable unit (TRUE) or not (FALSE).	
boolean HotSwappable	A physical component is HotSwappable if it can be replaced by another component within the same model. The component is inserted in a main board that is powered on.	FALSE
boolean PoweredOn	A property that indicates whether the physical element is powered on.	
boolean Removable	A property that indicates whether a physical component is removable.  A physical component is removable if it can be taken in and out of the physical container without impairing the function of the overall packaging.	FALSE
boolean Replaceable	A property that indicates whether a physical package is replaceable.  A physical component is replaceable if it can be replaced with a physically different one.	FALSE
string Caption (64)	A short textual description of the object	Port connector <i>ElementName</i>
String CreationClassName (key) (256)	The name of the class or the subclass that is used in the creation of an instance.	IBMPSG_Port
string Description	A textual description of the object.	Port connector information for <i>ElementName</i>
string ElementName	A user-friendly name of the object.	<i>Name</i>
string Model (256)	The name by which the physical element is generally known.	
string Name (1024)	The Name property that defines the label by which the object is known.	
string PartNumber (256)	The part number assigned by the organization that is responsible for producing or manufacturing the physical element.	
string SerialNumber (256)	A manufacturer-allocated number that is used to identify the physical element.	
String StatusDescriptions[]	Various OperationalStatus array values.	

Table 13. IBMPSTG\_Port (continued)

Property name	Property description	Value or value location
string Tag (key) (256)	An arbitrary string that uniquely identifies the physical element and serves as the element's key.	<i>Name</i>
uint16 HealthState	The current health of the element.	
uint16 OperationalStatus[]	The current status of the element.	
uint16 PortType	The type of the port that is presented.	

## IBMPSTG\_Processor

The provider looks up a resource based on the logical resource name that is provided as the key under the DeviceID property, and returns instances of all processors that are available on the system.

Table 14. IBMPSTG\_Processor

Property name	Property description	Value or value location
string Caption (64)	A short textual description of the object.	Processor <i>ElementName</i>
string CreationClassName (key) (256)	The name of the class or the subclass that is used in the creation of an instance.	IBMPSTG_Processor
string Description	A textual description of the object.	Processor information for <i>ElementName</i>
string DeviceID (key) (64)	An address or other identifying information to uniquely name the logical device.	<i>Name</i>
string ElementName	A user-friendly name of the object.	
string Identifying Descriptions[]	An array of freeform strings that provides explanations and details behind the entries in the OtherIdentifyingInfo array.	The resource name for the logical processor as identified by the Hardware Resource Manager. The processor part number. The processor type number. The processor model number. The processor serial number.
string Model	The model of the processor.	
string Name (1024)	The label by which the object is known.	
string OtherEnabledState	A string that describes the element's enabled or disabled state when the EnabledState property is set to 1.	powered off or not connected
string OtherFamilyDescription	The processor family type.	PowerPC®
string OtherIdentifyingInfo (256)	Additional data, beyond DeviceID information, that can be used to identify a logical device.	
string Role	The role of the processor.	Central Processor
string StatusDescriptions[]	Various OperationalStatus array values.	
string SystemCreationClassName (key) (256)	The scoping system's CreationClassName.	IBMPSTG_ComputerSystem
string SystemName (key) (256)	The scoping system's name.	

Table 14. IBMP5G\_Processor (continued)

Property name	Property description	Value or value location
string Type	The type of the processor.	
string Version	The version of the processor.	
uint16 AddressWidth	The processor address width in bits.	64 bits
uint16 Availability	The primary availability and status of the device.	
uint16 CPUStatus	The current status of the processor.	
uint16 DataWidth	The processor data width in bits.	64 bits
uint16 EnabledDefault	An enumerated value that indicates an administrator's default configuration for an element's enabled state.	7 (No Default)
uint16 EnabledState	An integer enumeration that indicates the enabled or disabled states of an element.	
uint16 Family	The processor family type.	1 (Other)
uint16 HealthState	The current health of the element.	
uint16 OperationalStatus[]	The current status of the element.	
uint16 RequestedState	An integer enumeration that indicates the last requested or desired state for the element.	Default value of 5 (No change)
uint16 UpgradeMethod	CPU socket information including data on how this processor can be upgraded (if upgrades are supported).	6 (None)

### IBMP5G\_SerialNumberInformation

This provider returns instances of physical resources of all implemented physical resource classes in this provider that have a serial number associated with them.

Table 15. IBMP5G\_SerialNumberInformation

Property name	Property description	Value or value location
string Caption (64)	A short textual description of the object.	Serial number for <i>ElementName</i>
string Description	A textual description of the object.	Serial number information for <i>ElementName</i>
string ElementName	A user-friendly name of the object.	System or <i>Hardware ElementName</i>
string Identifier (key)	The identifier by which the asset information object is known.	System or <i>ResourceName</i>
string Model	The name of the category by which this element is generally known.	
string Name	The name by which the element that has the given serial number is known.	System or <i>Hardware ElementName</i>
string OtherIdentifyingInformation	Additional data, beyond the identifier, that can be used to identify the element.	

Table 15. IBMPSG\_SerialNumberInformation (continued)

Property name	Property description	Value or value location
string SerialNumber	A manufacturer-allocated number that is used to identify the physical element.	
string SettingId (256)	The identifier by which the instance's setting is known.	System or <i>ResourceName</i>

## Hardware inventory and network management providers

These providers provide information about hardware inventory and network management. The tables in the topic indicate which properties are supported and provide property descriptions and values.

### Supported providers

The following table lists the implemented CIM class, provider types, and categories for the providers.

Table 16. Supported providers

Provider name	Implements CIM class	Provider type	Category
QUME_AssociatedMemoryProvider	IBM_AssociatedMemory	Instance and association	Logical hardware
QUME_BindsToLANEndpointProvider	IBM_BindsToLANEndpoint	Instance and association	Network
QUME_BIOSElementProvider	IBM_BIOSElement	Instance	Firmware
QUME_CardOnCardProvider	IBM_CardOnCard	Instance and association	Physical hardware
QUME_CardProvider	IBM_Card	Instance	Physical hardware
QUME_CDROMDriveProvider	IBM_CDROMDrive	Instance	Logical hardware
QUME_ChassisProvider	IBM_Chassis	Instance	Physical hardware
QUME_ChipProvider	IBM_Chip	Instance	Physical hardware
QUME_ComputerSystemPackageProvider	IBM_ComputerSystemPackage	Instance and association	Physical hardware
QUME_ControlledByProvider	IBM_ControlledBy	Instance and association	Logical hardware
QUME_DeviceSAPImplementationProvider	IBM_DeviceSAPImplementation	Instance and association	Network
QUME_DiskDriveProvider	IBM_DiskDrive	Instance	Logical hardware
QUME_DNSGeneralSettingDataProvider	IBM_DNSGeneralSettingData	Instance	Network
QUME_DNSSettingDataProvider	IBM_DNSSettingData	Instance	Network
QUME_DVDDriveProvider	IBM_DVDDrive	Instance	Logical hardware
QUME_ElementFRUProvider	IBM_ElementFRU	Instance and association	Physical hardware
QUME_ElementSettingDataProvider	IBM_ElementSettingData	Instance and association	Network

Table 16. Supported providers (continued)

Provider name	Implements CIM class	Provider type	Category
QUME_EthernetPortProvider	IBM_EthernetPort	Instance	Network
QUME_HostedAccessPointProvider	IBM_HostedAccessPoint	Instance and association	Network
QUME_InstalledOSProvider	IBM_InstalledOS	Instance and association	System
QUME_LANEndpointProvider	IBM_LANEndpoint	Instance	Network
QUME_MemoryProvider	IBM_Memory	Instance	Logical hardware
QUME_PackagedComponentProvider	IBM_PackagedComponent	Instance and association	Physical hardware
QUME_PackageInChassisProvider	IBM_PackageInChassis	Instance and association	Physical hardware
QUME_PCControllerProvider	IBM_PCController	Instance	Logical hardware
QUME_PCDeviceProvider	IBM_PCDevice	Instance	Logical hardware
QUME_PhysicalMediaProvider	IBM_PhysicalMedia	Instance	Physical hardware
QUME_PhysicalMemoryProvider	IBM_PhysicalMemory	Instance	Physical hardware
QUME_PortControllerProvider	IBM_PortController	Instance	Logical hardware
QUME_PortImplementsEndpointProvider	IBM_PortImplementsEndpoint	Instance and association	Network
QUME_ProcessorProvider	IBM_Processor	Instance	Logical hardware
QUME_ProductPhysicalComponentProvider	IBM_ProductPhysicalComponent	Instance and association	Physical hardware
QUME_ProductProvider	IBM_Product	Instance	Physical hardware
QUME_RealizesProvider	IBM_Realizes	Instance and association	Logical hardware
QUME_ReplacementFRUProvider	IBM_ReplacementFRU	Instance	Physical hardware
QUME_SNMPCommunityStringProvider	IBM_SNMPCommunityString	Instance	Network
QUME_SNMPTrapTargetProvider	IBM_SNMPTrapTarget	Instance	Network
QUME_StaticIPAssignmentSettingDataProvider	IBM_StaticIPAssignmentSettingData	Instance	Network
QUME_SystemDeviceProvider	IBM_SystemDevice	Instance and association	Logical hardware
QUME_SystemPackagingProvider	IBM_SystemPackaging	Instance and association	Physical hardware
QUME_TapeDriveProvider	IBMOS400_TapeDrive	Instance	Logical hardware
QUME_TCIPProtocolEndpointProvider	IBM_TCIPProtocolEndpoint	Instance	Network
QUME_TimeZoneSettingDataProvider	IBM_TimeZoneSettingData	Instance	System
QUME-TokenRingPortProvider	IBM-TokenRingPort	Instance	Network

Table 16. Supported providers (continued)

Provider name	Implements CIM class	Provider type	Category
QUME_WirelessLANEndpointProvider	IBM_WirelessLANEndpoint	Instance	Network
QUME_WirelessPortProvider	IBM_WirelessPort	Instance	Network

## IBM\_AssociatedMemory

This provider returns the association between a logical element and the memory that is installed on the logical element.

Table 17. IBM\_AssociatedMemory

Property name	Property value and data source	Instance mapping rule
IBM_Memory REF Dependent	Returns a reference to the IBM_Memory that is installed or associated with the logical device.	This should be a one-to- <i>n</i> association between logical device and memory. It associates each CPU to all main storage. Because it is nonuniform memory access (NUMA) model, the processor can access any main storage on system.
IBM_Processor REF Antecedent	Returns a reference to the IBM_Processor, representing a logical processor.	

## IBM\_BindsToLANEndpoint

This provider returns association between a service access point (SAP) or ProtocolEndpoint and an underlying LANEndpoint on the same system.

Table 18. IBM\_BindsToLANEndpoint

Property name	Property value and data source	Instance mapping rule
CIM_ServiceAccessPoint REF Dependent	Returns a reference to the CIM_ServiceAccessPoint representing the AccessPoint or ProtocolEndpoint that is dependent on the LANEndpoint property.	This should be a one-to-one association between CIM_IPProtocolEndpoint (which is a subclass of CIM_ServiceAccessPoint) and IBM_LANEndpoint.
IBM_LANEndpoint REF Antecedent	Returns a reference to the IBM_LANEndpoint representing the underlying LANEndpoint property that is depended on.	

## IBM\_BIOSElement

BIOSElement represents the low-level software that is loaded into nonvolatile storage, and used to start and configure a ComputerSystem. There are three levels of firmware: memory, T-side, and P-side. This provider returns one instance of the active firmware in the memory when an enumerated list of instances is asked for.

Table 19. IBM\_BIOSElement

Property name	Property description	Value or value location
string Caption(64)	A short textual description of the object.	BIOS element <i>ElementName</i>
string Description	A textual description of the object.	BIOS element information for <i>ElementName</i>



Table 19. IBM\_BIOSElement (continued)

Property name	Property description	Value or value location
string ElementName	A user-friendly name of the object.	Name
string Manufacturer	CIM_BIOSElement.	IBM
string Name(key)(256)	The name that identifies this software element.	
string SoftwareElementID(256)	An identifier for the software element. The identifier is used with other keys to create a unique representation of the element.	
string Version	Software version. It should be in the form <Major>.<Minor>.<Revision> or <Major>.<Minor><Letter><Revision>.	
uint16 SoftwareElementState(key)(64)	A property that identifies various states of the life cycle of a software element.	3(running)
uint16 TargetOperatingSystem(Key)	A property that specifies the element's operating system environment.	i5/OS

## IBM\_CardOnCard

This provider returns the association between a card and another card or motherboard on which the card is mounted.

Table 20. IBM\_CardOnCard

Property name	Property value and data source	Instance mapping rule
IBM_Card REF GroupComponent	Returns a reference to the IBM_Card, representing a card that can hold another card.	This should be a one-to-one association between two cards.
IBM_Card REF PartComponent	Returns a reference to the IBM_Card, representing a card.	
string LocationWithinContainer	Location code.	

## IBM\_Card

This provider returns instances of all cards that are available on the system when an enumerated list of instances is asked for, or looks up a resource based on the packaging resource name provided as the key under the ElementName property.

Table 21. IBM\_Card

Property name	Property description	Value or value location
boolean CanBeFRUed	A property that indicates whether a FRU can be applied to this physical element. Its values are TRUE or FALSE.	
boolean HostingBoard	A property that indicates that this card is a motherboard, or more generically, a baseboard in a chassis.	
boolean PoweredOn	A property that indicates whether the physical element is powered on.	

Table 21. IBM\_Card (continued)

Property name	Property description	Value or value location
boolean RequiresDaughterBoard	A property that indicates that at least one board or auxiliary card is required to function properly.	
string Caption (64)	A short textual description of the object.	Card <i>ElementName</i>
string CreationClassName (key) (256)	The name of the class or the subclass that is used in the creation of an instance.	IBM_Card
string Description	A textual description of the object.	Card information for <i>ElementName</i>
string ElementName	A user-friendly name of the object.	<i>Name</i>
string Model (256)	The name by which the physical element is generally known.	
string Name (1024)	The label by which the object is known.	
string PartNumber (256)	The part number assigned by the organization that produces the physical element.	
string SerialNumber (256)	A manufacturer-allocated number that is used to identify the physical element.	
string SlotLayout	A free-form string that describes the slot positioning, typical usage, restrictions, individual slot spacings, or any other pertinent information for the slots on a card.	
string StatusDescriptions[]	The various OperationalStatus array values.	
string Tag (key) (256)	An arbitrary string that uniquely identifies the physical element and serves as the element's key.	Name
uint16 HealthState	The current health of the element.	
uint16 OperationalStatus[]	The current status of the element.	
uint16 PackageType	The type of the physical package.	9 Module or Card

## IBM\_CDROMDrive

This provider returns instances of all CD-ROM drives that are available on the system when an enumerated list of instances is asked for, or looks up a resource based on the logical resource name provided as the key under the DeviceID property.

Table 22. IBM\_CDROMDrive

Property name	Property description	Value or value location
boolean MediaIsLocked	A property that indicates whether the media are locked and cannot be ejected.	TRUE
string Caption (64)	A short textual description of the object.	CDROM <i>ElementName</i>

Table 22. IBM\_CDROMDrive (continued)

Property name	Property description	Value or value location
string CreationClassName(Key) (256)	The name of the class or the subclass that is used in the creation of an instance.	IBM_CDROMDrive
string Description	A textual description of the object.	CDROM information for <i>ElementName</i>
string DeviceID(Key) (64)	An address or other identifying information to uniquely name the logical device.	<i>Name</i>
string ElementName	A user-friendly name of the object.	<i>Name</i>
string Name (1024)	The label by which the object is known.	
string OtherEnabledState	A string that describes the enabled or disabled state of the element when the EnabledState property is set to 1.	powered off or not connected
string StatusDescriptions[]	The various OperationalStatus array values.	
string SystemCreationClassName(Key) (256)	The scoping system's CreationClassName.	IBMOS400_ComputerSystem
string SystemName(Key) (256)	The scoping System's name.	
uint16 Availability	The primary availability and status of the device.	
uint16 EnabledDefault = 2	An enumerated value that indicates an administrator's default or startup configuration for the EnabledState of an element.	7
uint16 EnabledState = 5	An integer enumeration that indicates the enabled and disabled states of an element.	
uint16 HealthState	The current health of the element.	
uint16 OperationalStatus[]	The current status of the element.	
uint16 RequestedState = 12	An integer enumeration that indicates the last requested or desired state for the element.	5
uint16 Security	An enumeration that indicates the operational security defined for the media access device.	2 (Unknown)

### IBM\_Chassis

Refer to the IBMPSG\_Chassis class in the "Providers that are inherited from the operating system" on page 35 topic.

### IBM\_Chip

This provider returns instances of all chips that are available on the system when an enumerated list of instances is asked for, or looks up a resource based on the packaging resource name provided as the key under the ElementName property.

Table 23. IBM\_Chip

Property name	Property description	Value or value location
boolean CanBeFRUed	A property that indicates whether a FRU can be applied to this physical element. Its values are TRUE or FALSE.	
boolean PoweredOn	A property that indicates whether the physical element is powered on.	
string Caption (64)	A short textual description of the object.	Chip <i>ElementName</i>
string CreationClassName (key) (256)	The name of the class or the subclass that is used in the creation of an instance.	IBM_Chip
string Description	A textual description of the object.	Chip information for <i>ElementName</i>
string ElementName	A user-friendly name of the object.	<i>Name</i>
string Model (256)	The name by which the physical element is generally known.	
string Name (1024)	The label by which the object is known.	
string PartNumber (256)	The part number assigned by the organization that produces the physical element.	
string SerialNumber (256)	A manufacturer-allocated number that is used to identify the Physical Element.	
string StatusDescriptions[]	The various OperationalStatus array values.	
string Tag (key) (256)	An arbitrary string that uniquely identifies the physical element and serves as the element's key.	<i>Name</i>
uint16 HealthState	The current health of the element.	
uint16 OperationalStatus[]	The current status of the element.	

## IBM\_ComputerSystemPackage

This provider returns the association between a computer system and the physical hardware package that is installed on the system.

Table 24. IBM\_ComputerSystemPackage

Property name	Property value and data source	Instance mapping rule
CIM_PhysicalPackage REF Antecedent	Returns a reference to the IBM_PhysicalPackage, representing the physical package that is installed on the system.	This should be a one-to- <i>n</i> association between the computer system and the physical package. Enumerate all IBM_PhysicalPackage instances on the system.
IBM_ComputerSystem REF Dependent	Returns a reference to the IBM_ComputerSystem, representing a computer system.	
string PlatformGUID	Physical package's serial number.	

## IBM\_ControlledBy

This provider returns the association between device and controller.

Table 25. IBM\_ControlledBy

Property name	Property value and data source	Instance mapping rule
CIM_Controller REF Antecedent	Returns a reference to the CIM_Controller, representing a controller.	This should be a one-to-one association between a device and a controller.
CIM_LogicalDevice REF Dependent	Returns a reference to the CIM_LogicalDevice, representing a logical port.	
uint16 AccessState		

## IBM\_DeviceSAPImplementation

This provider returns the association between a service access point (SAP) and how it is implemented.

Table 26. IBM\_DeviceSAPImplementation

Property name	Property value and data source	Instance mapping rule
CIM_LogicalDevice REF Antecedent	Returns a reference to the CIM_LogicalDevice, representing the LogicalDevice.	This should be a one-to- <i>n</i> association between CIM_NetworkPort (a subclass of CIM_LogicalDevice) and CIM_IPProtocolEndpoint (a subclass of CIM_ServiceAccessPoint). The QtocLstNetIFc API returns the line description (that maps to an instance of CIM_NetworkPort) for each network interface (that maps to an instance of CIM_IPProtocolEndpoint).
CIM_ServiceAccessPoint REF Dependent	Returns a reference to the CIM_ServiceAccessPoint, representing the ServiceAccessPoint implemented using the LogicalDevice.	

## IBM\_DiskDrive

This provider returns instances of all logical disk units that are available on the system when an enumerated list of instances is asked for, or looks up a resource based on the logical resource name provided as the key under the DeviceID property.

Table 27. IBM\_DiskDrive

Property name	Property description	Value or value location
boolean MediaIsLocked	A property that indicates whether the media are locked in the device and cannot be ejected.	TRUE
string Caption (64)	A short textual description of the object.	Disk Drive <i>ElementName</i>
string CreationClassName (Key)(256)	The name of the class or the subclass used in the creation of an instance.	IBM_DiskDrive
string Description	A textual description of the object.	Disk Drive information for <i>ElementName</i>
string DeviceID (Key)(64)	An address that uniquely names the logical device.	<i>Name</i>
string ElementName	A user-friendly name of the object.	<i>Name</i>

Table 27. IBM\_DiskDrive (continued)

Property name	Property description	Value or value location
string Name (1024)	The label by which the object is known.	
string OtherEnabledState	A string that describes the enabled or disabled state of the element when the EnabledState property is set to 1.	powered off or not connected
string StatusDescriptions[]	The various OperationalStatus array values.	
string SystemCreationClassName (Key)(256)	The scoping system's CreationClassName.	IBMOS400_ComputerSystem
string SystemName (Key)(256)	The scoping system's name.	
uint16 Availability	The primary availability and status of the device.	
uint16 EnabledDefault = 2	An enumerated value that indicates an administrator's default or startup configuration for the Enabled State of an element.	7
uint16 EnabledState = 5	An integer enumeration that indicates the enabled and disabled states of an element.	
uint16 HealthState	The current health of the element.	
uint16 OperationalStatus[]	The current status of the element.	
uint16 RequestedState = 12	An integer enumeration that indicates the last requested or desired state for the element.	5
uint16 Security	An enumeration that indicates the operational security that is defined for the media access device.	2 (Unknown)
uint64 DefaultBlockSize	The default block size for this device (in bytes).	
uint64 MaxBlockSize	The maximum block size for media that are accessed by this device (in bytes).	
uint64 MaxMediaSize	The maximum size of media that are supported by this device (in KB).	

### IBM\_DNSGeneralSettingData

This provider returns one instance of this class, which represents the system-wide configuration options for the Domain Name System (DNS) client.

Table 28. IBM\_DNSGeneralSettingData

Property name	Property description	Value or value location
string InstanceID(key)	Within the scope of the instantiating namespace, the property that identifies an instance of this class.	IBM_DNSGeneralSettingData
string Caption (64)	A short textual description of the object.	DNSGeneralSettingData
string Description	A textual description of the object.	DNSGeneralSettingData information

Table 28. IBM\_DNSGeneralSettingData (continued)

Property name	Property description	Value or value location
string DNSSuffixesToAppend [ ]	A property that appends DNS suffixes to resolve a hostname.	
string ElementName	The user-friendly name for this instance of SettingData.	IBM_DNSGeneralSettingData
uint16 AddressOrigin = 2	A property that identifies the method by which the IP address, subnet mask, and gateway are assigned to the IP protocol endpoint.	2

## IBM\_DNSSettingData

This provider represents the DNS configuration setting for each TCP/IP interface.

Table 29. IBM\_DNSSettingData

Property name	Property description	Value or value location
string Caption (64)	A short textual description of the object.	DNSSettingData
string Description	A textual description of the object.	DNSSettingData information
string DNSServerAddresses [ ]	The DNS servers to be contacted.	
string DomainName	The domain that is used for this client connection.	
string ElementName	The user-friendly name of this instance of SettingData.	IBM_DNSSettingData
string InstanceID(key)	Within the scope of the instantiating namespace, the property that identifies an instance of this class.	IBM_DNSSettingData
string RequestedHostname	The hostname that is requested for this client connection.	
uint16 AddressOrigin = 2	A property that identifies the method by which the IP address, subnet mask, and gateway are assigned to the IP protocol endpoint.	2

## IBM\_DVDDrive

This provider returns instances of all DVD drives that are available on the system when an enumerated list of instances is asked for, or looks up a resource based on the logical resource name provided as the key under the DeviceID property.

Table 30. IBM\_DVDDrive

Property name	Property description	Value or value location
boolean MediaIsLocked	A property that indicates whether the media are locked in the device and cannot be ejected.	TRUE
string Caption (64)	A short textual description of the object.	DVD Drive <i>ElementName</i>

Table 30. IBM\_DVDDrive (continued)

Property name	Property description	Value or value location
string CreationClassName(Key) (256)	The name of the class or the subclass that is used in the creation of an instance.	IBM_DVDDrive
string Description	A textual description of the object.	DVD Drive information for <i>ElementName</i>
string DeviceID(Key) (64)	An address that names the logical device.	<i>Name</i>
string ElementName	A user-friendly name of the object.	<i>Name</i>
string Name (1024)	The label by which the object is known.	
string OtherEnabledState	A string that describes the enabled or disabled state of the element when the EnabledState property is set to 1.	powered off or not connected
string StatusDescriptions[]	The various OperationalStatus array values.	
string SystemCreationClassName(Key) (256)	The scoping system's CreationClassName.	IBMOS400_ComputerSystem
string SystemName(Key) (256)	The scoping system's name.	
uint16 Availability	The primary availability and status of the device.	
uint16 EnabledDefault = 2	An enumerated value that indicates an administrator's default or startup configuration for the EnabledState of an element.	7
uint16 EnabledState = 5	An integer enumeration that indicates the enabled and disabled states of an element.	
uint16 HealthState	The current health of the element.	
uint16 OperationalStatus[]	The current status of the element.	
uint16 RequestedState = 12	An integer enumeration that indicates the last requested or desired state for the element.	5
uint16 Security	An enumeration that indicates the operational security that is defined for the media access device.	2 (Unknown)

## IBM\_ElementFRU

This provider returns the association between a physical element and its possible replacement parts.

Table 31. IBM\_ElementFRU

Property name	Property value and data source	Instance mapping rule
CIM_PhysicalElement REF ReplaceableElement	Returns a reference to the IBM_PhysicalElement, representing a physical element.	This should be a one-to- <i>n</i> association between a physical element and a FRU.
IBM_ReplacementFRU REF ReplacementElement	Returns a reference to the IBM_ReplacementFRU, representing a FRU part.	



## IBM\_ElementSettingData

This provider returns the association between a LogicalPort and one or more ProtocolEndpoints that are implemented on it.

Table 32. IBM\_ElementSettingData

Property name	Property value and data source	Instance mapping rule
CIM_ManagedElement REF ManagedElement	Returns a reference to the CIM_ManagedElement, representing the managed element.	This should be a one-to-one association between CIM_IPProtocolEndpoint (a subclass of CIM_ManagedElement) and IBM_StaticIPAssignmentSettingData (a subclass of CIM_SettingData). For each instance of CIM_IPProtocolEndpoint, enumerate IBM_StaticIPAssignmentSettingData, and if the InstanceID (IPv4 address) of an instance of IBM_StaticIPAssignmentSettingData equals the name of the instance of CIM_IPProtocolEndpoint, use this association to associate these two instances.
CIM_SettingData REF SettingData	Returns a reference to the CIM_SettingData, representing the SettingData object that is associated with the element.	

## IBM\_EthernetPort

This provider returns instances of all Ethernet line descriptions that are available on the system when an enumerated list of instances is asked for, or looks up a resource based on the line description name provided as the key under the DeviceID property.

Table 33. IBM\_EthernetPort

Property name	Property description	Value or value location
boolean AutoSense	A property that indicates whether the network port is capable of automatically determining the speed or other communications characteristics of the attached network media.	
boolean FullDuplex	A property that indicates whether the port is operating in full-duplex mode.	
string Caption (64)	A short textual description of the object.	Ethernet port <i>ElementName</i>
string CreationClassName (Key) (256)	The name of the class or the subclass that is used in the creation of an instance.	IBM_EthernetPort
string Description	A textual description of the object.	Ethernet port information for <i>ElementName</i>
string DeviceID (Key) (64)	An address that names the logical device.	<i>Name</i>
string ElementName	A user-friendly name of the object.	<i>Name</i>
string Name (1024)	The label by which the object is known.	
string NetworkAddresses [ ] (64)	An array of strings that indicates the network addresses for the port.	

Table 33. IBM\_EthernetPort (continued)

Property name	Property description	Value or value location
string PermanentAddress (64)	The network address that is hardcoded into a port.	
string StatusDescriptions[]	The various OperationalStatus array values.	
string SystemCreationClassName (Key) (256)	The scoping system's CreationClassName.	IBMOS400_ComputerSystem
string SystemName (Key)(256)	The scoping system's name.	
uint16 Availability	The primary availability and status of the device.	
uint16 EnabledDefault = 2	An enumerated value that indicates an administrator's default or startup configuration for the EnabledState of an element.	
uint16 EnabledState = 5	An integer enumeration that indicates the enabled and disabled states of an element.	
uint16 LinkTechnology	An enumeration of the types of links.	2 Ethernet
uint16 OperationalStatus[]	The current status of the element.	
uint16 PortNumber	The network port number.  Network ports are often numbered relative to either a logical module or a network element.	
uint16 RequestedState = 12	An integer enumeration that indicates the last requested or desired state for the element.	
uint32 MaxDataSize	The maximum size of the INFO (non-MAC) field that is received or transmitted.	
uint64 ActiveMaximumTransmissionUnit	The active or negotiated maximum transmission unit (MTU) that can be supported.	
uint64 MaxSpeed	The maximum bandwidth of the port in bits per second.	
uint64 RequestedSpeed	The requested bandwidth of the port in bits per second.	<i>Speed</i>
uint64 Speed	The bandwidth of the port in bits per second.	
uint64 SupportedMaximumTransmissionUnit	The maximum transmission unit (MTU) that can be supported.	

### IBM\_HostedAccessPoint

This provider returns the association between a service AccessPoint and the system on which it is provided.

Table 34. IBM\_HostedAccessPoint

Property name	Property value and data source	Instance mapping rule
CIM_ServiceAccessPoint REF Dependent	Returns a reference to the CIM_ServiceAccessPoint, representing the SAPs that are hosted on this system.	This should be a one-to- <i>n</i> association between IBM_ComputerSystem and CIM_ServiceAccessPoint. Enumerate all CIM_ServiceAccessPoint properties on the system.
IBM_ComputerSystem REF Antecedent	Returns a reference to the IBM_ComputerSystem, representing the hosting system.	

## IBM\_InstalledOS

This provider returns the association between the ComputerSystem and the OperatingSystem operating systems installed or loaded on it.

Table 35. IBM\_InstalledOS

Property name	Property value and data source	Instance mapping rule
IBM_ComputerSystem REF GroupComponent	Returns a reference to the IBM_ComputerSystem, representing the ComputerSystem.	This should be a one-to- <i>n</i> association between IBM_ComputerSystem and IBM_OperatingSystem. Enumerate all IBM_OperatingSystem properties on the system
IBM_OperatingSystem REF PartComponent	Returns a reference to the IBM_OperatingSystem, representing the OperatingSystem installed on the ComputerSystem.	

## IBM\_LANEndpoint

This provider returns instances of all line descriptions on the system when an enumerated list of instances is asked for, or looks up a resource based on the line description name provided as the key under the ElementName property

Table 36. IBM\_LANEndpoint

Property name	Property description	Value or value location
string Caption (64)	A short textual description of the object.	LANEndpoint <i>ElementName</i>
string CreationClassName(Key)(256)	The name of the class or the subclass that is used in the creation of an instance.	IBM_LANEndpoint
string Description	A textual description of the object.	LANEndpoint information for <i>ElementName</i>
string ElementName	A user-friendly name of the object.	<i>Name</i>
string GroupAddresses [ ]	The multicast addresses to which the LANEndpoint listens.	
string MACAddress(12)	The principal unicast address that is used in communication with the LANEndpoint.	
string Name(256)	A string that identifies this protocol endpoint with either a port or an interface on a device.	
string NameFormat (256)	The name that ensures that the value of the name property is unique.	LineName_MACAddress

Table 36. IBM\_LANEndpoint (continued)

Property name	Property description	Value or value location
string StatusDescriptions[]	The various OperationalStatus array values.	
string SystemCreationClassName(Key)(256)	The CreationClassName of the scoping system.	IBMOS400_ComputerSystem
string SystemName(Key)(256)	The name of the scoping System.	
uint16 EnabledDefault = 2	An enumerated value that indicates an administrator's default or startup configuration for the EnabledState of an element.	
uint16 EnabledState	An integer enumeration that indicates the enabled and disabled states of an element.	
uint16 OperationalStatus[]	The current status of the element.	
uint16 ProtocolIFType	Enumeration is limited to layer 2 values that are related and reserved for this subclass of protocol endpoint.	
uint16 RequestedState = 12	An integer enumeration that indicates the last requested or desired state for the element.	
uint32 MaxDataSize	The largest information field that can be sent or received by the LANEndpoint.	

## IBM\_Memory

This provider returns instances of all memory-related logical devices available on the system when an enumerated list of instances is asked for, or looks up a resource based on the logical resource name provided as the key under the DeviceID property.

Table 37. IBM\_Memory

Property name	Property description	Value or value location
boolean Volatile	A property that indicates whether this memory is volatile.	TRUE
string Caption (64)	A short textual description of the object.	Cache Memory <i>ElementName</i>
string CreationClassName (Key) (256)	The name of the class or the subclass that is used in the creation of an instance.	IBM_Memory
string Description	A textual description of the object.	Cache Memory information for <i>ElementName</i>
string DeviceID (Key) (64)	An address that names the logical device.	<i>ElementName</i>
string ElementName	A user-friendly name of the object.	<i>Name</i>
string Name (1024)	The label by which the object is known.	<i>ElementName</i>
string OtherEnabledState	A string that describes the enabled or disabled state of the element when the EnabledState property is set to 1.	powered off or not connected

Table 37. IBM\_Memory (continued)

Property name	Property description	Value or value location
string StatusDescriptions[]	The various OperationalStatus array values.	
string SystemCreationClassName (Key) (256)	The scoping system's CreationClassName.	IBMOS400_ComputerSystem
string SystemName (Key) (256)	The scoping system's name.	
uint16 Access	A property that indicates whether the media are readable, writable, or both.	1 Read 2 Write 3 Read and write
uint16 Availability	The primary availability and status of the device.	
uint16 EnabledDefault = 2	An enumerated value that indicates an administrator's default or startup configuration for the enabled state of an element.	7 (No default)
uint16 EnabledState = 5	An integer enumeration that indicates the enabled and disabled states of an element.	
uint16 HealthState	The current health of the element.	
uint16 OperationalStatus[]	The current status of the element.	
uint16 RequestedState = 12	An integer enumeration that indicates the last requested or desired state for the element.	5 (No change)

### IBM\_PackagedComponent

This provider returns the association between a physical component and a physical package that the component belongs to.

Table 38. IBM\_PackagedComponent

Property name	Property value and data source	Instance mapping rule
CIM_PhysicalPackage REF GroupComponent	Returns all instances of CIM_PhysicalPackage.	This should be a one-to-one association between a component and a package.
CIM_PhysicalComponent REF PartComponent	Returns all instances of CIM_PhysicalComponent.	
string LocationWithinContainer	Location code.	

### IBM\_PackageInChassis

This provider returns the association between a physical package and a chassis that the package belongs to.

Table 39. IBM\_PackageInChassis

Property name	Property value and data source	Instance mapping rule
IBM_Chassis REF GroupComponent	Returns all instances of IBM_Chassis.	This should be a one-to-one association between a package and a chassis.
CIM_PhysicalPackage REF PartComponent	Returns all instances of CIM_PhysicalPackage.	
string LocationWithinContainer	Location code.	

## IBM\_PCIController

This provider returns instances of all PCI controllers that are available on the system when an enumerated list of instances is asked for, or looks up the resource based on the logical resource name provided as the key under the DeviceID property.

Table 40. IBM\_PCIController

Property name	Property description	Value or value location
string Caption (64)	A short textual description of the object.	PCI Controller <i>ElementName</i>
string CreationClassName (Key) (256)	The name of the class or the subclass that is used in the creation of an instance.	IBM_PCIController
string Description	A textual description of the object.	PCI Controller information for <i>ElementName</i>
string DeviceID (Key) (64)	An address that names the logical device.	<i>Name</i>
string ElementName	A user-friendly name of the object.	<i>Name</i>
string Name (1024)	The label by which the object is known.	
string OtherEnabledState	A string that describes the enabled or disabled state of the element when the EnabledState property is set to 1.	powered off or not connected
string StatusDescriptions[]	The various OperationalStatus array values.	
string SystemCreationClassName (Key) (256)	The scoping system's CreationClassName.	IBMOS400_ComputerSystem
string SystemName (Key) (256)	The scoping system's name.	
uint16 Availability	The primary availability and status of the device.	
uint16 EnabledDefault = 2	An enumerated value that indicates an administrator's default or startup configuration for the EnabledState of an element.	7
uint16 EnabledState = 5	An integer enumeration that indicates the enabled and disabled states of an element.	
uint16 HealthState	The current health of the element.	
uint16 OperationalStatus[]	The current status of the element.	
uint16 RequestedState = 12	An integer enumeration that indicates the last requested or desired state for the element.	5

## IBM\_PCIDevice

This provider returns instances of all PCI Devices available on the system when an enumerated list of instances is asked for, or looks up a resource based on the Logical Resource Name provided as the key under the DeviceID property.

Table 41. IBM\_PCIDevice

Property name	Property description	Value or value location
string Caption (64)	A short textual description of the object.	PCI Device <i>ElementName</i>
string CreationClassName (Key) (256)	The name of the class or the subclass that is used in the creation of an instance.	IBM_PCIDevice
string Description	A textual description of the object.	PCI Device information for <i>ElementName</i>
string DeviceID (Key) (64)	An address or other identifying information to uniquely name the logical device.	<i>Name</i>
string ElementName	A user-friendly name of the object.	<i>Name</i>
string Name (1024)	The label by which the object is known.	
string OtherEnabledState	A string that describes the enabled or disabled state of the element when the EnabledState property is set to 1.	powered off or not connected
string StatusDescriptions[]	The various OperationalStatus array values.	
string SystemCreationClassName (Key) (256)	The scoping system's CreationClassName.	IBMOS400_ComputerSystem
string SystemName (Key) (256)	The scoping system's name.	
uint16 Availability	The primary availability and status of the device.	
uint16 EnabledDefault = 2	An enumerated value that indicates an administrator's default or startup configuration for the EnabledState of an element.	7
uint16 EnabledState = 5	An integer enumeration that indicates the enabled and disabled states of an element.	
uint16 HealthState	The current health of the element.	
uint16 OperationalStatus[]	The current status of the element.	
uint16 RequestedState = 12	An integer enumeration that indicates the last requested or desired state for the element.	5

## IBM\_PhysicalMedia

This provider returns instances of all physical media that is available on the system when an enumerated list of instances is asked for, or looks up a resource based on the packaging resource name provided as the key under the ElementName property.

Table 42. IBM\_PhysicalMedia

Property name	Property description	Value or value location
boolean CanBeFRUed	A property that indicates whether a FRU can be applied to this physical element. Its values are TRUE and FALSE.	
boolean PoweredOn	A property that indicates whether the physical element is powered on.	
real32 MediaSize	The size of the media in inches.	
string Caption (64)	A short textual description of the object.	Physical Media <i>ElementName</i>
string CreationClassName (key) (256)	The name of the class or the subclass that is used in the creation of an instance.	IBM_PhysicalMedia
string Description	A textual description of the object.	Physical Media information for <i>ElementName</i>
string ElementName	A user-friendly name of the object.	<i>Name</i>
string Model (256)	The name by which the physical element is generally known.	
string Name (1024)	The label by which the object is known.	
string PartNumber (256)	The part number assigned by the organization that produces the physical element.	
string SerialNumber (256)	A manufacturer-allocated number that identifies the physical element.	
string StatusDescriptions[]	The various OperationalStatus array values.	
string Tag (key) (256)	An arbitrary string that uniquely identifies the physical element and serves as the element's key.	<i>Name</i>
uint16 HealthState	The current health of the element.	
uint16 MediaType	The type of the physical media as an enumerated integer.	
uint16 OperationalStatus[]	The current status of the element.	
uint64 Capacity	The number of bytes that can be read from or written to the medium.	

## IBM\_PhysicalMemory

This provider returns instances of all physical memory that is available on the system when an enumerated list of instances is asked for, or looks up a resource based on the packaging resource name provided as the key under the ElementName property.

Refer to the IBMPSTG\_PhysicalMemory class in the "Providers that are inherited from the operating system" on page 35 topic.



## IBM\_PortController

This provider returns instances of all port controllers that are available on the system when an enumerated list of instances is asked for, or looks up a resource based on the logical resource name provided as the key under the DeviceID property.

Table 43. IBM\_PortController

Property name	Property description	Value or value location
string Caption (64)	A short textual description of the object.	Port Controller <i>ElementName</i>
string CreationClassName (Key) (256)	The name of the class or the subclass that is used in the creation of an instance.	IBM_PortController
string Description	A textual description of the object.	Port Controller information for <i>ElementName</i>
string DeviceID (Key) (64)	An address that names the logical device.	<i>Name</i>
string ElementName	A user-friendly name of the object.	<i>Name</i>
string Name (1024)	The label by which the object is known.	
string OtherEnabledState	A string that describes the enabled or disabled state of the element when the EnabledState property is set to 1.	powered off or not connected
string SystemCreationClassName (Key) (256)	The scoping system's CreationClassName.	IBMOS400_ComputerSystem
string SystemName (Key) (256)	The scoping system's name.	
uint16 Availability	The primary availability and status of the device.	
uint16 ControllerType	The type or model of the port controller.	
uint16 EnabledDefault = 2	An enumerated value that indicates an administrator's default or startup configuration for the Enabled State of an element.	7
uint16 EnabledState = 5	An integer enumeration that indicates the enabled and disabled states of an element.	
uint16 HealthState	The current health of the element.	
uint16 OperationalStatus[]	The current status of the element.	
uint16 RequestedState = 12	An integer enumeration that indicates the last requested or desired state for the element.	5

## IBM\_PortImplementsEndpoint

This provider returns the association between a LogicalPort and one or more ProtocolEndpoints that are implemented on it

Table 44. IBM\_PortImplementsEndpoint

Property name	Property value and data source	Instance mapping rule
CIM_LogicalPort REF Antecedent	Returns a reference to the CIM_LogicalPort, representing the device behind the ProtocolEndpoint.	This should be a one-to- <i>n</i> association between CIM_NetworkPort (a subclass of CIM_LogicalPort) and CIM_IPProtocolEndpoint (a subclass of CIM_ProtocolEndpoint).
CIM_ProtocolEndpoint REF Dependent	Returns a reference to the CIM_ProtocolEndpoint, representing the ProtocolEndpoint that is implemented on the LogicalPort.	

## IBM\_Processor

Refer to the IBMPSPG\_Processor class in the Providers that are inherited from the base operating system topic.

## IBM\_ProductPhysicalComponent

This provider returns the association between a physical element and the product that it belongs to.

Table 45. IBM\_ProductPhysicalComponent

Property name	Property value and data source	Instance mapping rule
CIM_PhysicalElement REF PartComponent	Returns a reference to the IBM_PhysicalElement, representing a physical element.	This should be a one-to-one association between physical element and a product. Enumerate all CIM_PhysicalElement instances and map to IBM_Product.
IBM_Product REF GroupComponent	Returns a reference to the IBM_Product, representing a product that contains the physical element.	

## IBM\_Product

This provider returns instances of all products available on the system when an enumerated list of instances is asked for, or looks up a resource based on the packaging resource name provided as the key under the ElementName property.

Table 46. IBM\_Product

Property name	Property description	Value or value location
string Caption (64)	A short textual description of the object.	Product <i>Name</i>
string Description	A textual description of the object.	Product information for <i>Name</i>
string ElementName	A user-friendly name of the object.	
string IdentifyingNumber (key)(64)	Product identification, such as the serial number on software, the die number on a hardware chip, or a project number.	
string Name (Key)(256)	Commonly used product name.	
string Vendor (Key)(256)	The name of the product's supplier.	""
string Version (Key)(64)	Product version information.	

## IBM\_Realizes

This provider returns the association between logical devices and physical elements that implement them.

Table 47. IBM\_Realizes

Property name	Property value and data source	Instance mapping rule
CIM_LogicalDevice REF Dependent	Returns all instances of CIM_LogicalDevice.	This should be a one-to- <i>n</i> association between CIM_LogicalDevice and CIM_PhysicalElement.
CIM_PhysicalElement REF Antecedent	Returns all instances of CIM_PhysicalElement.	

## IBM\_ReplacementFRU

This provider returns instances of all replacement FRUs available on the system when an enumerated list of instances is asked for, or looks up a resource based on the packaging resource name provided as the key under the InstanceID property.

Table 48. IBM\_ReplacementFRU

Property name	Property description	Value or value location
boolean CustomerReplaceable	Indicates whether this replacement part is considered customer replaceable (TRUE) or not (FALSE).	
string Caption (64)	A short textual description of the object.	Field replaceable unit <i>ElementName</i>
string Description	A textual description of the object.	Field replaceable unit information for <i>ElementName</i>
string ElementName	A user-friendly name of the object.	<i>Name</i>
string InstanceID (Key)	Within the scope of the instantiating Namespace, the property that identifies an instance of this class.	<i>ElementName</i>

## IBM\_SNMPCommunityString

This provider contains the controlling information of accessing SNMP Service.

Table 49. IBM\_SNMPCommunityString

Property name	Property description	Value or value location
string Caption (64)	A short textual description of the object.	SNMP Community String
string CommunityString;	The SNMP community string or password that is used for read access or read-and-write access to the agent's data.	
string CreationClassName	The name of the class or the subclass that is used in the creation of an instance.	IBM_SNMPCommunityString
string Description	A textual description of the object.	SNMP Community string information for <i>SystemName</i>
string ElementName	A user-friendly name of the object.	<i>TrapTargetIP</i>
string SystemCreationClassName	The CreationClassName of the scoping system.	IBMOS400_ComputerSystem

Table 49. IBM\_SNMPCommunityString (continued)

Property name	Property description	Value or value location
string SystemName	The name of the scoping system.	
uint16 TypeOfAccess	An enumerated integer that describes whether read access or read-and-write access is granted, or whether this information is unknown.	
string Name	The uniquely identified ServiceAccessPoint.	TrapTargetIP

## IBM\_SNMPTrapTarget

This provider contains information that describes a remote system to which Informs and Traps are sent.

Table 50. IBM\_SNMPTrapTarget

Property name	Property description	Value or value location
String AccessInfo	The host address.	
string Caption (64)	A short textual description of the object.	SNMP Trap Target
string CommunityString;	The SNMP community string or password that is used for read access, or read-and-write access to the agent's data.	
string CreationClassName	The name of the class or the subclass that is used in the creation of an instance.	IBM_SNMPTrapTarget
string Description	A textual description of the object.	SNMP Trap Target information for SystemName
string ElementName	A user-friendly name of the object.	AccessInfo
string Name	A property that identifies the service access point.	AccessInfo
string SystemCreationClassName	The CreationClassName of the scoping system.	IBMOS400_ComputerSystem
string SystemName	The name of the scoping system.	
uint16 SNMPVersion	A property that indicates whether read access or read-and-write access is granted, or whether this information is unknown.	

## IBM\_StaticIPAssignmentSettingData

This provider returns instances of all static IP AssignmentSettingData available on the system when an enumerated list of instances is asked for, or looks up a resource based on the IPv4 address provided as the key under the InstanceID property.

Table 51. IBM\_StaticIPAssignmentSettingData

Property name	Property description	Value or value location
string Caption (64)	A short textual description of the object.	Static IP Assignment Setting Data ElementName

Table 51. IBM\_StaticIPAssignmentSettingData (continued)

Property name	Property description	Value or value location
string Description	A textual description of the object.	Static IP Assignment Setting Data information for <i>ElementName</i>
string ElementName	The user-friendly name of this instance of SettingData.	<i>IPv4Address</i>
string GatewayIPv4Address[]	The IPv4 addresses of the default gateway.	
string InstanceID(key)	Within the scope of the instantiating namespace, the property that identifies an instance of this class.	<i>IPv4Address</i>
string IPv4Address	The IPv4 address that is assigned to the protocol endpoint.	
string SubnetMask	The subnet mask for the IPv4 address of this protocol endpoint.	
uint16 AddressOrigin = 3	The method by which the IP address, subnet mask, and gateway are assigned to the IP protocol endpoint.	3

## IBM\_SystemDevice

This provider returns the association between a ComputerSystem and all LogicalDevice instances on it.

Table 52. IBM\_SystemDevice

Property name	Property value and data source	Instance mapping rule
CIM_LogicalDevice REF PartComponent	Returns all instances of CIM_LogicalDevice.	This should be a one-to- <i>n</i> association between IBM_ComputerSystem and CIM_LogicalDevice. Enumerate all CIM_LogicalDevice properties on the computer system.
IBM_ComputerSystem REF GroupComponent	Returns an instance of IBM_ComputerSystem.	

## IBM\_SystemPackaging

This provider returns the association between a computer system and all physical packages on it.

Table 53. IBM\_SystemPackaging

Property name	Property value and data source	Instance mapping rule
CIM_PhysicalElement REF Antecedent	Returns all instances of CIM_PhysicalElement	This should be a one-to- <i>n</i> association between IBM_ComputerSystem and CIM_LogicalDevice. Enumerate all CIM_PhysicalElement properties on the computer system.
IBM_ComputerSystem REF Dependent	Returns an instance of IBM_ComputerSystem.	

## IBM\_TCIPProtocolEndpoint

This provider returns instances of all TCP connections on the system when an enumerated list of instances is asked for, or looks up a resource based on the local address and port number provided as the key under the name property.

Table 54. IBM\_TCPProtocolEndpoint

Property name	Property description	Value or value location
string Caption (64)	A short textual description of the object.	TCP Protocol Endpoint <i>ElementName</i>
string CreationClassName(Key) (256)	The name of the class or the subclass that is used in the creation of an instance.	IBM_TCPProtocolEndpoint
string Description	A textual description of the object.	TCP Protocol Endpoint information for <i>ElementName</i>
string ElementName	A user-friendly name of the object.	<i>Name</i>
string Name(256)	A string that identifies this protocol endpoint with either a port or an interface on a device.	
string NameFormat (256)	The name that ensures that the value of the name property is unique.	Local Address_Local Port
string SystemCreationClassName (Key)(256)	The CreationClassName of the scoping system.	IBMOS400_ComputerSystem
string SystemName(Key)(256)	The name of the scoping system.	
uint16 ProtocolIFType	Enumeration is limited to TCP and reserved values for this subclass of ProtocolEndpoint.	4111
uint32 PortNumber	The TCP port number.	

## IBM\_TimeZoneSettingData

This provider returns instances of all time zone settings when an enumerated list of instances is asked for, or looks up a resource based on the time zone description name provided as the key under the InstanceID property.

Table 55. IBM\_TimeZoneSettingData

Property name	Property description	Value or value location
sint32 DaylightOffset	The number of minutes by which this daylight saving time differs from UTC.	
sint32 StandardOffset	The number of minutes by which this standard time differs from UTC.	
string Caption (64)	A short textual description of the object.	Time Zone Setting Data for <i>ElementName</i>
string DaylightName	The full name of the daylight time zone.	
string Description	A textual description of the object.	Time Zone Setting Data information for <i>ElementName</i>
string ElementName	A user-friendly name of the object.	
string InstanceID(key)	Within the scope of the instantiating namespace, this property identifies an instance of this class.	<i>ElementName</i>
string StandardName	The full name of the standard time zone.	

## IBM\_TokenRingPort

This provider returns instances of all TokenRing line descriptions that are available on the system when an enumerated list of instances is asked for, or looks up a resource based on the line description name provided as the key under the DeviceID property.

Table 56. IBM\_TokenRingPort

Property name	Property description	Value or value location
boolean AutoSense	A property that indicates whether the network port is capable of automatically determining the speed or other communications characteristics of the attached network media.	
boolean FullDuplex	A property that indicates whether the port is operating in full-duplex mode.	
string Caption (64)	A short textual description of the object.	TokenRing port <i>ElementName</i>
string CreationClassName (Key) (256)	The name of the class or the subclass that is used in the creation of an instance.	IBM_TokenRingPort
string Description	A textual description of the object.	TokenRing port information for <i>ElementName</i>
string DeviceID (Key) (64)	An address that names the logical device.	<i>Name</i>
string ElementName	A user-friendly name of the object.	<i>Name</i>
string Name (1024)	The label by which the object is known.	
string NetworkAddresses [ ] (64)	An array of strings that indicates the network addresses for the port.	
string PermanentAddress (64)	The network address that is hardcoded into a port.	
string StatusDescriptions[]	The various OperationalStatus array values.	
string SystemCreationClassName (Key) (256)	The scoping system's CreationClassName.	IBMOS400_ComputerSystem
string SystemName (Key) (256)	The scoping system's name.	
uint16 Availability	The primary availability and status of the device.	
uint16 EnabledDefault = 2	An enumerated value that indicates an administrator's default or startup configuration for the EnabledState of an element.	
uint16 EnabledState = 5	An integer enumeration that indicates the enabled and disabled states of an element.	
uint16 LinkTechnology	An enumeration of the types of links.	7 Token Ring
uint16 OperationalStatus[]	The current status of the element.	

Table 56. IBM\_TokenRingPort (continued)

Property name	Property description	Value or value location
uint16 PortNumber	The network port number.  Network ports are often numbered relative to either a logical module or a network element.	
uint16 RequestedState = 12	An integer enumeration that indicates the last requested or desired state for the element.	
uint16 RingSpeed	The bandwidth of the ring.	
uint32 MaxDataSize	The maximum size of the INFO (non-MAC) field that is received or transmitted.	
uint64 ActiveMaximumTransmissionUnit	The active or negotiated MTU that can be supported.	
uint64 MaxSpeed	The maximum bandwidth of the port in bits per second.	
uint64 RequestedSpeed	The requested bandwidth of the port in bits per second.	<i>Speed</i>
uint64 Speed	The bandwidth of the port in bits per second.	
uint64 SupportedMaximumTransmissionUnit	The MTU that can be supported.	

## IBM\_WirelessLANEndpoint

This provider returns instances of all wireless line descriptions on the system when an enumerated list of instances is asked for, or looks up a resource based on the line description name provided as the key under the Elementname property

Table 57. IBM\_WirelessLANEndpoint

Property name	Property description	Value or value location
string Caption (64)	A short textual description of the object.	Wireless LAN Endpoint <i>ElementName</i>
string CreationClassName(Key)(256)	The name of the class or the subclass used in the creation of an instance.	IBM_WirelessLANEndpoint
string Description	A textual description of the object.	Wireless LAN Endpoint information for <i>ElementName</i>
string ElementName	A user-friendly name of the object.	<i>Name</i>
string Name	The MAC address of the wireless endpoint.	
string NameFormat (256)	The name that ensures that the value of the name property is unique.	LineName_MACAddress
string StatusDescriptions[]	The various OperationalStatus array values.	
string SystemCreationClassName(Key)(256)	The CreationClassName of the scoping system.	IBMOS400_ComputerSystem
string SystemName(Key)(256)	The name of the scoping system.	



Table 57. IBM\_WirelessLANEndpoint (continued)

Property name	Property description	Value or value location
uint16 EnabledDefault = 2	An enumerated value that indicates an administrator's default or startup configuration for the EnabledState of an element.	
uint16 EnabledState	An integer enumeration that indicates the enabled and disabled states of an element.	
uint16 OperationalStatus[]	The current status of the element.	
uint16 ProtocolIFType	Enumeration is limited to layer 2 values that are related and reserved for this subclass of ProtocolEndpoint.	71
uint16 RequestedState = 12	An integer enumeration that indicates the last requested or desired state for the element.	

## IBM\_WirelessPort

This provider returns instances of all wireless ports available on the system when an enumerated list of instances is asked for, or looks up a resource based on the logical resource name provided as the key under the DeviceID property.

Table 58. IBM\_WirelessPort

Property name	Property description	Value or value location
string Caption (64)	A short textual description of the object.	Wireless port <i>ElementName</i>
string CreationClassName (Key) (256)	The name of the class or the subclass that is used in the creation of an instance.	IBM_WirelessPort
string Description	A textual description of the object.	Wireless port information for <i>ElementName</i>
string DeviceID (Key) (64)	An address that names the logical device.	<i>Name</i>
string ElementName	A user-friendly name of the object.	<i>Name</i>
string Name (1024)	The label by which the object is known.	
string NetworkAddresses [ ] (64)	An array of strings that indicates the network addresses for the port.	
string OtherEnabledState	A string that describes the enabled or disabled state of the element when the EnabledState property is set to 1.	powered off or not connected
string PermanentAddress (64)	The network address that is hardcoded into a port.	
string StatusDescriptions[]	The various OperationalStatus array values.	
string SystemCreationClassName (Key) (256)	The scoping system's CreationClassName.	IBMOS400_ComputerSystem
string SystemName (Key)(256)	The scoping system's name.	

Table 58. IBM\_WirelessPort (continued)

Property name	Property description	Value or value location
uint16 Availability	The primary availability and status of the device.	
uint16 EnabledDefault = 2	An enumerated value that indicates an administrator's default or startup configuration for the EnabledState of an element.	7
uint16 EnabledState = 5	An integer enumeration that indicates the enabled and disabled states of an element.	
uint16 LinkTechnology	An enumeration of the types of links.	Wireless LAN 11
uint16 OperationalStatus[]	The current status of the element.	
uint16 PortNumber	Network port number  Network ports are often numbered relative to either a logical module or a network element.	
uint16 RequestedState = 12	An integer enumeration that indicates the last requested or desired state for the element.	5

## IBMOS400\_TapeDrive

This provider returns instances of all tape drives available on the system when an enumerated list of instances is asked for, or looks up a resource based on the Logical Resource Name provided as the key under the DeviceID property.

Table 59. IBMOS400\_TapeDrive

Property name	Property description	Value or value location
real32 MediaSize	The size of media in inches.	
string Caption (64)	A short textual description of the object.	Tape <i>ElementName</i>
string CreationClassName (Key) (256)	The name of the class or the subclass that is used in the creation of an instance.	IBMOS400_TapeDrive
string Description	A textual description of the object.	Tape information for <i>ElementName</i>
string DeviceID (Key) (64)	An address that names the logical device.	<i>Name</i>
string ElementName	A user-friendly name of the object.	<i>Name</i>
string Name (1024)	The label by which the object is known.	
string OtherEnabledState	The enabled or disabled state of the element when the EnabledState property is set to 1.	powered off or not connected
string StatusDescriptions[]	The various OperationalStatus array values.	
string SystemCreationClassName (Key) (256)	The scoping system's CreationClassName.	IBMOS400_ComputerSystem
string SystemName (Key) (256)	The scoping system's name.	

Table 59. IBMOS400\_TapeDrive (continued)

Property name	Property description	Value or value location
uint16 Availability	The primary availability and status of the device.	
uint16 EnabledDefault = 2	An enumerated value that indicates an administrator's default or startup configuration for the EnabledState of an element.	7
uint16 EnabledState = 5	An integer enumeration that indicates the enabled and disabled states of an element.	
uint16 HealthState	The current health of the element.	
uint16 MediaType	An enumerated integer that specifies the type of physical media.	
uint16 OperationalStatus[]	The current status of the element.	
uint16 RequestedState = 12	An integer enumeration that indicates the last requested or desired state for the element.	5
uint16 Security	An enumeration that indicates the operational security defined for the media access device.	2 (unknown)

### Supported CIM SMI-S HBA and HDR providers

In the IBM Universal Manageability Enablement program, Common Information Model Object Manager (CIMOM) uses profiles host bus adapter (HBA) and host discovered resources (HDR). This topic describes the IBM-supplied Storage Management Initiative Specification (SMI-S) HBA and HDR providers.

SMI-S is a standard management interface that allows interoperability of different storage area network (SAN) resources that are provided by different vendors. SMI-S is based on the Common Information Model (CIM) and Web-Based Enterprise Management (WBEM) standards that are originated from the Distributed Management Task Force (DMTF). The SMI-S Server Profile is mandatory for all compliant SMI-S servers.

SAN is a dedicated network that is separated from a local area network (LAN) and a wide area network (WAN). SAN generally refers to interconnected storage-related resources that are connected to one or more servers. It is characterized by high-data transmission rates between the computer system and member storage elements.

Figures 1 through 5 outline elements and their association for HBA, HDR, and registered profiles.




Figure 1. HBA profile

The HBA profile describes behavior of Fibre Channel (FC) host adapters supporting the SCSI (FC SCSI Protocol (FCP)) command set. An FC adapter that is used in a host system is called an HBA. An HBA is a physical device that contains one or more FC ports. A single system contains one or more HBAs.




Figure 2. HDR profile

The HDR profile provides information about the discovered hardware resources that include the connectivity and corresponding IDs.

HDR profiles are extended to model i5/OS auxiliary storage pools (ASPs), mirroring, and multiple paths. Figure 3 and figure 4 show the modelling of i5/OS ASPs, mirroring, and multiple paths.




Figure 3. CIM representation of a nonmirrored ASP




Figure 4. CIM representation of a mirrored ASP




Figure 5. Registered profile

Registered profile models the profiles that are registered in the object manager and the associations between registration classes and the domain classes implementing the profile.

**Note:** The green lines and the red lines in the preceding figures represent two types of associations:

- The green lines represent the aggregation association.
- The red lines represent the nonaggregation association.

#### CIM instance providers

The following CIM classes have been implemented as IBM-supplied providers to discover HBA card and storage resources on the host:

- IBM\_Card: subclass of CIM\_Card
- IBM\_CompositeExtent: subclass of CIM\_CompositeExtent
- IBM\_ComputerSystem: subclass of CIM\_Computer\_System
- IBM\_FCPort: subclass of CIM\_FCPort
- IBM\_FCPortStatistics: subclass of CIM\_FCPortStatistics
- IBM\_PortController: subclass of CIM\_PortController
- IBM\_Product: subclass of CIM\_Product
- IBM\_RegisteredProfile: subclass of CIM\_RegisteredProfile
- IBM\_RegisteredSubProfile: subclass of CIM\_RegisteredSubProfile
- IBM\_SoftwareIdentity: subclass of CIM\_SoftwareIdentity
- IBM\_SCSIProtocolEndPoint: subclass of CIM\_SCSIProtocolEndPoint
- IBM\_StorageExtent: subclass of CIM\_StorageExtent

#### CIM association providers

The following CIM classes have been implemented as IBM supplied providers to provide association information for discovered HBA card and storage resources on the host.

- IBM\_ASPSystemDevice: subclass of CIM\_SystemDevice
- IBM\_CompositeExtentBasedOn: subclass of CIM\_CompositeExtentBasedOn
- IBM\_ElementConformsToProfile: subclass of CIM\_ElementConformsToProfile
- IBM\_FCControlledBy: subclass of CIM\_ControlledBy
- IBM\_FCDeviceSAPImplementation (Optional): subclass of CIM\_DeviceSAPImplementation
- IBM\_FCElementSoftwareIdentity: subclass of CIM\_ElementSoftwareIdentity
- IBM\_FCElementStatisticalData: subclass of CIM\_ElementStatisticalData
- IBM\_FCHostedAccessPoint : subclass of CIM\_HostedAccessPoint

- IBM\_FCProductPhysicalComponent: subclass of CIM\_ProductPhysicalComponent
- IBM\_FCRealizes: subclass of CIM\_Realizes
- IBM\_FCSystemDevice: subclass of CIM\_SystemDevice
- IBM\_SCSIInitiatorTargetLogicalUnitPath: subclass of CIM\_SCSIInitiatorTargetLogicalUnitPath
- IBM\_StorageSynchronized: subclass of CIM\_StorageSynchronized
- IBM\_SubProfileRequiresProfile: subclass of CIM\_SubProfileRequiresProfile

## SMI-S HBA CIM providers

### IBM\_Card

The IBM\_Card provider returns the HBA physical card instance on the system.

Table 60. IBM\_Card

Property name	Property description	Value or value location
boolean PoweredOn	This property indicates whether the physical element is powered on (TRUE) or is powered off (FALSE).	
boolean RequiresDaughterBoard	This property indicates that at least one daughter board or auxiliary card is required to function properly.	
string Caption (64)	A short textual description of the object.	FC Card <i>ElementName</i>
string CreationClassName (key) (256)	The name of the class or the subclass used in the creation of an instance.	IBM_Card
string Description	A textual description of the object.	FC Card Information <i>ElementName</i>
string ElementName	A user-friendly name of the object.	Resource name
string Manufacturer (256)	The name of the organization that produces the physical element.	IBM
string Model (256)	The name by which the physical element is generally known.	Type-Model
string Name (1024)	The label by which the object is known.	Resource name
string SerialNumber (256)	A manufacturer-allocated number that identifies the physical element.	
String SlotLayout	A freeform string that describes slot positioning, typical usage, restrictions, individual slot spacings, or any other pertinent information for the slots on a card.	
String StatusDescriptions	The various OperationalStatus array values.	
string Tag (key) (256)	An arbitrary string that identifies the physical element and serves as the key of the element.	Manufacturer_Type-Model-SerialNumber
uint16 OperationalStatus	The current status of the element.	
uint16 PackageType	An enumeration that defines the type of the physical package.	9 Module or Card

## | IBM\_ComputerSystem

| Refer to the IBM\_ComputerSystem provider in the “Providers that are inherited from the operating system” on page 35 topic for more information.

## | IBM\_FCPort

| IBM\_FCPort provider returns instances of all the FC ports on the system.

| **Note:** The HBA profile does not cover the internal storage controller and virtual HBA.

| *Table 61. IBM\_FCPort*

Property name	Property description	Value or value location
string Description	A textual description of the object.	FC Port information <i>DeviceID</i>
string Caption (64)	A short textual description of the object.	IBM_FCPort
string CreationClassName (key) (256)	The name of the class or the subclass that is used in the creation of an instance.	IBM_FCPort
string DeviceID (key) (64)	An address that names the logical device.	
string Name (1024)	The label by which the object is known.	
string PermanentAddress (64)	The network address that is hardcoded into a port.	
string SystemCreationClassName (key) (256)	The CreationClassName of the scoping system.	IBM_ComputerSystem
string SystemName (key) (256)	The system name of the scoping system.	
uint16 LinkTechnology	An enumeration of the types of links.	4 FC
uint16 OperationalStatus	The current status of the element.	
uint16 PortType	The specific mode that is currently enabled for the port.	10 N
uint16 SupportedFC4Types	An array of integers that indicates the Fibre Channel (FC)-4 protocols supported.	8 SCSI-FCP
uint16 UsageRestriction	A logical port is identifiable as a front-end or back-end port.	3 Back-end only
uint16[] ActiveFC4Types	A textual description of the object.	8 SCSI - FCP
uint64 MaxSpeed	The maximum bandwidth of the port in bits per second.	0
uint64 Speed	The current bandwidth of the port in bits per second.	0



## IBM\_FCControlledBy

The IBM\_ControlledBy provider returns the association between a device and a controller.

Table 62. IBM\_FCControlledBy

Property name	Property value and data source	Instance mapping rule
IBM_FCPort REF Dependent	The provider returns a reference to the CIM_LogicalDevice. This reference represents a logical port.	This should be a one-to- <i>n</i> association between the controller and FCPort.
IBM_PortController REF Antecedent	The provider returns a reference to the CIM_Controller. This reference represents a controller.	

## IBM\_FCDeviceSAPImplementation

This provider is an association between a service access point (SAP) and how it is implemented.

Table 63. IBM\_FCDeviceSAPImplementation

Property name	Property value and data source	Instance mapping rule
IBM_FCPort REF Antecedent	The logical device.	This should be a one-to-one association between IBM_FCPort and "initiator" IBM_SCSIProtocolEndpoint.
IBM_SCSIProtocolEndpoint REF Dependent	The SAP that is implemented using the logical device.	

## IBM\_FCElementSoftwareIdentity

This provider allows a managed element to report its software-related asset information (firmware, drivers, configuration software, and so forth).

Table 64. IBM\_FCElementSoftwareIdentity

Property name	Property value and data source	Instance mapping rule
IBM_PortController REF Dependent	The managed element that requires or uses the software.	This should be a one-to- <i>n</i> association between the controller and SoftwareIdentity.
IBM_SoftwareIdentity REF Antecedent	The software asset of a logical element.	

## IBM\_FCElementStatisticalData

This provider is an association that relates a managed element to its statistical data.

Table 65. IBM\_FCElementStatisticalData

Property name	Property value and data source	Instance mapping rule
IBM_FCPortREF ManagedElement	The managed element for which statistical or metric data is defined.	This should be a one-to-one association between FCPort and FCPortStatistics.
IBM_FCPortStatistics REF Stats	The statistic information (object).	

## IBM\_FCPortStatistics

This provider returns statistical data of all Fibre Channel (FC) ports on the system.

Table 66. IBM\_FCPortStatistics

Property name	Property description	Value or value location
string Caption (64)	A short textual description of the object.	IBM HBA Port Statistics
string Description	A textual description of the object.	This class represents instances of the statistics for HBA Ports.
string ElementName	A user-friendly name of the object.	
string InstanceID (key)	Within the scope of the instantiating namespace, InstanceID identifies an instance of this class.	
uint64 BytesReceived	The total number of bytes that are received, including framing characters.	0
uint64 BytesTransmitted	The total number of bytes that are transmitted, including framing characters.	0
uint64 CRCErrors	The number of times that the cyclic redundancy check (CRC) in a frame does not match the CRC that is computed by the receiver.	0
uint64 InvalidTransmissionWords	The number of transmission words with characters that are not valid.	0
uint64 LinkFailures	The number of times that a link error has occurred.	0
uint64 LossOfSignalCounter	The number of times that the signal is lost on the port since the last reset of the device.	0
uint64 LossOfSyncCounter	The number of times that synchronization is lost on the port since the last reset of the device.	0
uint64 PacketsReceived	The total number of packets that are received.	0
uint64 PacketsTransmitted	The total number of packets that are transmitted.	0
uint64 PrimitiveSeqProtocolErrCount	The count of primitive sequence protocol errors that are detected at this port.	0

## IBM\_FCProductPhysicalComponent

This provider returns an association between a physical element and the product that it belongs to.

Table 67. IBM\_FCProductPhysicalComponent

Property name	Property value and data source	Instance mapping rule
IBM_Card REF PartComponent	The provider returns a reference to the IBM_PhysicalElement. The reference represents a physical element.	This should be a one-to-one association between physical element and the product. Enumerate all CIM_PhysicalElement instances and map to IBM_Product.
IBM_Product REF GroupComponent	The provider returns a reference to the IBM_Product. The reference represents a product that contains the physical element.	

## IBM\_FCRealizes

This provider returns an association between logical devices and physical elements that implement them.

Table 68. IBM\_FCRealizes

Property name	Property value and data source	Instance mapping rule
IBM_Card REF Antecedent	The provider returns all instances of CIM_PhysicalElement.	This should be a one-to- <i>n</i> association between CIM_LogicalDevice and CIM_PhysicalElement.
IBM_PortController REF Dependent	The provider returns all instances of CIM_LogicalDevice.	

## IBM\_FCSystemDevice

This provider returns an association between a computer system and all logical devices on it.

Table 69. IBM\_FCSystemDevice

Property name	Property value and data source	Instance mapping rule
IBM_ComputerSystem REF GroupComponent	The provider returns an instance of CIM_System.	This should be a one-to- <i>n</i> association between IBM_ComputerSystem and IBM_FCPort.
IBM_FCPort REF PartComponent	The provider returns all instances of CIM_LogicalDevice.	

## IBM\_FCHostedAccessPoint

This provider is an association between an SAP and the system on which it is provided.

Table 70. IBM\_FCHostedAccessPoint

Property name	Property value and data source	Instance mapping rule
IBM_ComputerSystem REF Antecedent	The hosting system.	This should be a one-to- <i>n</i> association between IBM_ComputerSystem and initiator SCSIProtocolEndpoint.
IBM_SCSIProtocolEndpoint REF Dependent	The SAPs that are hosted on this system.	

## IBM\_PortController

This provider returns instances of all port controllers available on the system when an enumerated list of instances is asked for, or it looks up a resource based on the logical resource name that is provided as the key under the DeviceID property.

Table 71. IBM\_PortController

Property name	Header	Header
string Caption (64)	A short textual description of the object.	Port Controller <i>ElementName</i>
string CreationClassName (key) (256)	The name of the class or the subclass that is used in the creation of an instance.	IBM_PortController
String Description	A textual description of the object.	Port Controller information for <i>ElementName</i>
string DeviceID (key) (64)	An address that names the logical device.	
string ElementName	A user-friendly name of the object.	Resource name
string Name (1024)	The label by which the object is known.	
string OtherEnabledState	This property describes the enabled or disabled state of the element when the EnabledState property is set to 1.	not connected if EnabledState is 1; "" if EnabledState is not 1.
string StatusDescriptions	The various OperationalStatus array values.	
string SystemCreationClassName (key) (256)	The CreationClassName of the scoping system.	IBM_ComputerSystem
string SystemName (key) (256)	The system name of the scoping system.	HostName of the System
uint16 ControllerType	The type or model of the port controller.	4 FC
uint16 EnabledDefault	An enumerated value that indicates an administrator's default or startup configuration for the Enabled State of an element.	7 (No Default)
uint16 EnabledState	An integer enumeration that indicates the enabled and disabled states of an element.	
uint16 OperationalStatus	The current status of the element.	
uint16 RequestedState	An integer enumeration that indicates the last requested or desired state for the element.	5 (no change)

## IBM\_Product

This provider returns instances of all products available on the system when an enumerated list of instances is asked for, or it looks up the resource based on the packaging resource name that is provided as the key under the ElementName property.

Table 72. IBM\_Product

Property name	Property description	Value or value location
string Caption (64)	A short textual description of the object.	Product <i>ElementName</i>
string Description	A textual description of the object.	Product information for <i>ElementName</i>
string ElementName	A user-friendly name of the object.	Vendor_Type-Model
string IdentifyingNumber (key) (64)	Product identification, such as a serial number on software, a die number on a hardware chip, or a project number.	Serial Number
string Name (key) (256)	Commonly used product name.	Storage IOA
string Vendor (key) (256)	The name of the product supplier.	IBM
string Version (key) (64)	Product version information.	Type-Model

### IBM\_SCSIProtocolEndPoint

This provider returns the Small Computer System Interface (SCSI) protocol supported by the HBA card on the system.

Table 73. IBM\_SCSIProtocolEndPoint

Property name	Property description	Value or value location
string Caption (64)	A short textual description of the object.	IBM FC SCSI Protocol EndPoint
string CreationClassName (key) (256)	The name of the class or the subclass that is used in the creation of an instance.	IBM_SCSIProtocolEndpoint
string Description	A textual description of the object.	This class represents instances of available SCSI protocol over an FC port.
string Name (256)	The label by which the object is known.	
string OtherTypeDescription (64)	The type of ProtocolEndpoint when the Type property of this class (or any of its subclasses) is set to 1 (Other).	
string SystemCreationClassName (key) (256)	The CreationClassName of the scoping system.	IBM_ComputerSystem
string SystemName (key) (256)	The system name of the scoping system.	HostName of the System
uint16 ConnectionType	The supported connection type for this endpoint.	2 Fibre Channel
uint16 ProtocolIFType	An enumeration that is synchronized with the IANA ifType MIB.	56 Fibre Channel
uint16 Role	For iSCSI, each SCSI protocol endpoint must act as either a target or an initiator endpoint.	2 Initiator

## IBM\_SoftwareIdentity

This provider returns the device driver and device firmware instance on the system.

Table 74. IBM\_SoftwareIdentity firmware

Property name	Property description	Value or value location
string Caption (64)	A short textual description of the object.	IBM FC Adapter Software Identity
string Description	A textual description of the object.	This class represents instances of available fibre channel adapter software entities.
string InstanceID (key)	Within the scope of the instantiating namespace, InstanceID identifies an instance of this class.	SLIC_5722999
string Manufacturer	The manufacturer of this software.	IBM
string VersionString	A string that represents the complete software version information.	SLIC VRM
uint16 []Classifications	An array of enumerated integers that classifies this software.	2 Driver

Table 75. IBM\_SoftwareIdentity driver

Property name	Property description	Value or value location
string Caption (64)	A short textual description of the object.	IBM FC Adapter Software Identity
string Description	A textual description of the object.	This class represents instances of available fibre channel adapter software entities.
string InstanceID (key)	Within the scope of the instantiating namespace, InstanceID opaquely and uniquely identifies an instance of this class.	
string Manufacturer	The manufacturer of this software.	IBM
string VersionString	A string that represents the complete software version information.	LID
uint16 []Classifications	An array of enumerated integers that classifies this software.	10 Firmware

## SMI-S HDR CIM classes

### IBM\_ASPSystemDevice

This provider represents the association between a computer system and the auxiliary storage pool (ASP).

Table 76. IBM\_ASPSystemDevice

Property name	Property value and data source	Instance mapping rule
IBM_CompositeExtent REF PartComponent	This property returns all instances of CIM_LogicalDevice.	This should be a one-to- <i>n</i> association between CIM_System and CIM_LogicalDevice. Enumerate all CIM_LogicalDevice instances on the system.
IBM_ComputerSystem REF GroupComponent	This property returns an instance of CIM_System.	

## IBM\_CompositeExtent

This provider is used to model the distribution of user data across one or more underlying StorageExtents, which might be protected by some redundancy mechanism.

Table 77. IBM\_CompositeExtent

Property name	Property description	Value or value location
boolean IsBasedOnUnderlyingRedundancy	This property indicates that the underlying StorageExtents participate in a StorageRedundancy group.	Geographical mirroring
boolean NoSinglePointOfFailure	This property indicates whether any single point of failure exists.	Mirrored level of protection
string Caption	A short textual description of the object.	ASP <i>ElementName</i>
string CreationClassName	The name of the class or the subclass that is used in the creation of an instance.	IBM_CompositeExtent
string Description	A textual description of the object.	ASP information for <i>ElementName</i>
string DeviceID	An address that names the logical device.	ASP <i>ASP number</i>
string ElementName	A user-friendly name for the object.	ASP name
string Name(Experimental)	A unique identifier for the extent.	ASP <i>ASP number</i>
string SystemCreationClassName	The CreationClassName of the scoping system.	IBM_ComputerSystem
string SystemName	The system name of the scoping system.	HostName of the System
string[] IdentifyingDescriptions	An array of freeform strings that provides explanations and details behind the entries in the OtherIdentifyingInfo array.	Auxiliary Storage Pool
string[] OtherIdentifyingInfo	This property captures data.	ASP
uint8 DeltaReservation	The current value for delta reservation.	Tracking Space/StorageCapacity × 100
uint16 DataRedundancy	The number of complete copies of data that is currently maintained.	Geographical Mirroring (either 1 or 2)
uint16 NameFormat(Experimental)	This property requires that logical disk names must use the operating system device name format.	12
uint16 NameNamespace(Experimental)	This property requires that logical disk names must use the operating system device namespace.	8

Table 77. IBM\_CompositeExtent (continued)

Property name	Property description	Value or value location
uint16 PackageRedundancy	This property indicates how many physical packages can currently fail without data loss.	0
uint16[] OperationalStatus	The current status of the element.	ASP - OK, IASP - OK (Varied On), Stopped (Varied Off)
uint64 BlockSize	The size (in bytes) of the blocks that form this StorageExtent.	Block Size of a StorageExtent in the ASP
uint64 ConsumableBlocks	The maximum number of blocks that are available for consumption when layering StorageExtents using the BasedOn association.	Capacity - Must be converted from Number of Pages
uint64 NumberOfBlocks	The total number of logically contiguous blocks that form this extent.	Capacity - Must be converted from Number of Pages

### IBM\_CompositeExtentBasedOn

This class indicates that two storage objects are replicated at the specified point in time.

Table 78. IBM\_CompositeExtentBasedOn

Property name	Property value and data source	Instance mapping rule
CIM_CompositeExtent REF Dependent	The CompositeExtent that is built on the StorageExtent.	
CIM_StorageExtent REF Antecedent	The underlying StorageExtent.	

### IBM\_SCSIInitiatorTargetLogicalUnitPath

This provider is an association that models a host driver path to a SCSI logical unit. Each permutation of initiator, target protocol endpoints, and logical units is considered a separate path. This provider describes end-to-end path behavior, such as properties and operations that are commonly used in multipath management.

Table 79. IBM\_SCSIInitiatorTargetLogicalUnitPath

Property name	Property value and data source	Instance mapping rule
CIM_LogicalDevice REF LogicalUnit	A subclass of a logical device that represents a SCSI logical unit.	
IBM_SCSIProtocolEndpoint REF Initiator	An initiator endpoint.	
IBM_SCSIProtocolEndpoint REF Target	A target endpoint.	



## IBM\_SCSIProtocolEndPoint

This provider returns the SCSI protocol endpoint for the disk unit on the system.

Table 80. IBM\_SCSIProtocolEndPoint

Property name	Property description	Value or value location
string Caption (64)	A short textual description of the object.	IBM FC SCSI Protocol EndPoint
string CreationClassName (key) (256)	The name of the class or the subclass that is used in the creation of an instance.	IBM_SCSIProtocolEndPoint
string Description	A textual description of the object.	This class represents instances of available SCSI protocol over an FC port.
string Name (256)	The label by which the object is known.	Worldwide unique logical unit identifier.
string OtherTypeDescription (64)	The type of protocol endpoint when the Type property of this class (or any of its subclasses) is set to 1 (Other).	
string SystemCreationClassName (key) (256)	The CreationClassName of the scoping system.	IBM_ComputerSystem
string SystemName (key) (256)	The system name of the scoping system.	HostName of the System
uint16 ConnectionType	The supported connection type for this endpoint.	2 Fibre Channel
uint16 ProtocolIFType	An enumeration that is synchronized with the IANA ifType MIB.	56 Fibre Channel
uint16 Role	For iSCSI, each SCSIProtocolEndPoint must act as either a target or an initiator endpoint.	3 Target

## IBM\_StorageExtent

This provider describes the capabilities and management of the various media that exist to store data and allow data retrieval.

Table 81. IBM\_StorageExtent

Property name	Property description	Value or value location
Boolean IsBasedOnUnderlyingRedundancy	If the value is set to true, the property indicates that the underlying StorageExtents participate in a StorageRedundancy group.	Mirroring and Redundant Array of Independent Disks (RAID) are true; otherwise, this is false.
boolean NoSinglePointOfFailure	This property indicates whether any single point of failure exists.	Mirrored level of protection is true if the level of protection is bus.
string Description	A textual description of the object.	
string Caption (64)	A short textual description of the object.	IBM Storage Extent
string CreationClassName (key) (256)	The name of the class or the subclass used in the creation of an instance.	IBM_StorageExtent

Table 81. IBM\_StorageExtent (continued)

Property name	Property description	Value or value location
string DeviceID (key) (64)	An address that names the logical device.	Serial Number
string ElementName	A user-friendly name of the object.	Resource name, or concatenating all the resource names of multipathed disk units, separated by commas.
string Name(Experimental)	A unique identifier of the extent.	Resource Name
string SystemCreationClassName (key) (256)	The CreationClassName of the scoping system.	IBM_ComputerSystem
string SystemName (key) (256)	The system name of the scoping system.	HostName of the System
string[] IdentifyingDescriptions	An array of freeform strings that provides explanations and details behind the entries in the OtherIdentifyingInfo array.	Resource Name
string[] OtherIdentifyingInfo (256)	This property captures data besides the device ID information that can be used to identify a logical device.	
uint8 DeltaReservation	The current value for delta reservation.	0
uint16 DataRedundancy	The number of complete copies of data that is currently maintained.	Mirroring equals 2, otherwise 1.
uint16 ExtentStatus	This property indicates that StorageExtents have additional status information beyond what is captured in the OperationalStatus and other properties that are inherited from ManagedSystemElement.	
uint16 NameFormat(Experimental)	This property requires that logical disk names must use the operating system device name format.	12 (OS Device Name)
uint16 NameNamespace(Experimental)	This property requires that logical disk names must use the operating system device namespace.	8 (OS Device Namespace)
uint16 PackageRedundancy	This property indicates how many physical packages can currently fail without data loss.	Mirroring equals 1, RAID 5 equals 1, RAID 6 equals 2.
uint16[] OperationalStatus	The current statuses of the element.	
uint64 BlockSize	The size (in bytes) of the blocks that form this StorageExtent.	Block Size
uint64 ConsumableBlocks	The maximum number of blocks that are available for consumption when layering StorageExtents using the BasedOn association.	Size in Sectors
uint64 NumberOfBlocks	The total number of logically contiguous blocks that form this Extent.	Size in Sectors

## IBM\_StorageSynchronized

This provider indicates that two storage objects were replicated at the specified point in time.

Table 82. IBM\_StorageSynchronized

Property name	Property value and data source	Instance mapping rule
IBM_StorageExtent REF SystemElement	The source of the replication.	The mirrored disk unit has the same unit number in i5/OS.
IBM_StorageExtent REF SystemElement	The target of the replication.	

## SMI-S Registered Profile CIM classes

### IBM\_ElementConformsToProfile

This association defines the RegisteredProfiles to which the referenced ManagedElement conforms.

Table 83. IBM\_ElementConformsToProfile

Property name	Property value and data source	Instance mapping rule
IBM_ComputerSystem REF ManagedElement	The ManagedElement that conforms to the RegisteredProfile.	RegisteredProfile FC HBA associates to ComputerSystem; RegisteredProfile Host Discovered Resources associates to ComputerSystem.
CIM_RegisteredProfile REF ConformantStandard	The RegisteredProfile to which the ManagedElement conforms.	

### IBM\_RegisteredProfile

This provider returns instances of all RegisteredProfiles of HBA and HDR.

Table 84. IBM\_RegisteredProfile

Property name	Property description	Value or value location
string Caption	A short textual description (one-line string) of the object.	<i>RegisteredName</i>
string Description	Provides a textual description of the object.	Registered Profile information: + <i>RegisteredName</i>
string ElementName	A user-friendly name for the object.	<i>RegisteredName</i>
string InstanceID	Within the scope of the instantiating namespace, the InstanceID that identifies an instance of this class.	IBMOS400: + <i>RegisteredName</i>
string RegisteredName	The name of this registered profile.	FC HBA or Host Discovered Resources
string RegisteredVersion	The version of this profile.	1.1.0
uint16 AdvertiseTypes [ ]	This property signifies the advertisement for the profile information.	3 SLP
uint16 RegisteredOrganization	The organization that defines this profile.	11 SNIA

## IBM\_RegisteredSubProfile

This provider returns instances of all SubProfiles that are supported by HBA and HDR profiles.

Table 85. IBM\_RegisteredSubProfile

Property name	Property description	Value or value location
string Caption	A short textual description (one-line string) of the object.	<i>RegisteredName</i>
string Description	A textual description of the object.	Registered Sub Profile information: + <i>RegisteredName</i>
string ElementName	A user-friendly name of the object.	<i>RegisteredName</i>
string InstanceID	Within the scope of the instantiating namespace, the InstanceID that identifies an instance of this class.	IBMOS400: + <i>RegisteredName</i>
string RegisteredName	The name of this registered profile.	FC Initiator Ports Subprofile
string RegisteredVersion	The version of this profile.	1.1.0
uint16 AdvertiseTypes [ ]	This property signifies the advertisement for the profile information.	3 SLP
uint16 RegisteredOrganization	The organization that defines this profile.	11 SNIA

## IBM\_SubProfileRequiresProfile

This provider is an association between the RegisteredProfile and its subprofiles.

Table 86. IBM\_SubProfileRequiresProfile

Property name	Property value and data source	Instance mapping rule
IBM_RegisteredProfile REF Antecedent	The RegisteredProfile that is referenced or required by the subprofile.	RegisteredProfile FC HBA supports FC Initiator Ports Subprofile.
IBM_RegisteredSubProfile REF Dependent	A RegisteredSubProfile that requires a scoping profile for context.	

## i5/OS metrics classes

The topic describes metric classes and the user authorization.

The following CIM classes have been implemented as IBM-supplied providers to provide performance information:

- IBMOS400\_ColSrvMetricDefinition: a subclass of CIM\_BaseMetricDefinition
- IBMOS400\_ColSrvMetricValue: a subclass of CIM\_BaseMetricValue
- IBMOS400\_ColSrvMetricInstance: a subclass of CIM\_MetricInstance that associates between metric definition and metric value.
- IBMOS400\_ColSrvMetricDefForME: a subclass of CIM\_MetricDefForME that associates between a managed element (resource) and metric definition.
- IBMOS400\_ColSrvMetricForME: a subclass of CIM\_MetricForME that associates between a managed element (resource) and metric value.

**Note:** All instances of IBMOS400\_ColSrvMetricValue return volatile data, and only current data is supported. Historical data is not supported.

The following figure illustrates CIM standard schemas classes, metric providers association resources classes, and i5/OS extended metric classes.




Figure 6. CIM metrics classes

**Notes:**

- The white class diagrams are CIM standard schemas classes.
- The yellow class diagrams are metric provider association resources class.
- The green class diagrams are i5/OS extended metric classes.

The operating system supports the following CIM metrics.

Table 87. CIM metrics

Resource/Base CIM class	Metric
IBM_StorageExtent	<p><b>ActiveTimePercentage</b> Percentage of time that the disk unit was actively processing some request, id:MDDS0E</p> <p><b>AvailableSpace</b> Free capacity on the disk unit, id:MDDS05</p> <p><b>AverageDeviceUtilization</b> Average device utilization (not normalized to 100% for parallel I/O activity), id:MDDS0D</p> <p><b>Capacity</b> Capacity of the disk unit, id:MDDS04</p> <p><b>FastWriteOperations</b> Number of fast write operations (stored first in nonvolatile memory), id:MDDS08</p> <p><b>FastWritePercentage</b> Percentage of write operations processed as fast write operations, id:MDDS09</p> <p><b>IOIntensity</b> I/O utilization indicator, id:MDDS10</p> <p><b>QueueDepth</b> Average number of I/O requests currently in queue (OS view), id:MDDS11</p> <p><b>ReadCacheHitPercentage</b> Percentage of read requests that did not need access to disk units, id:MDDS03</p> <p><b>ReadOperations</b> Number of read operations against the disk unit, id:MDDS06</p> <p><b>ReadThroughput</b> Bytes per second read, id:MDDS0A</p> <p><b>RequestRate</b> Number of I/O requests per second for the associated device, id:MDDS0F</p> <p><b>ResponseTime</b> Response time associated with a disk unit, id:MDDS01</p> <p><b>TransferredThroughput</b> Bytes per second transferred, id:MDDS0C</p> <p><b>WaitTime</b> Wait time associated with a disk unit, id:MDDS02</p> <p><b>WriteOperations</b> Number of write operations, id:MDDS07</p> <p><b>WriteThroughput</b> Bytes per second written, id:MDDS0B</p>

Table 87. CIM metrics (continued)

Resource/Base CIM class	Metric
IBMOS400_ComputerSystem	<p><b>ActiveVirtualProcessors</b> Average number of virtual processors active, id: MDCS21</p> <p><b>PctPartitionDefinedCapacityUsed</b> System CPU time used as a percentage of configured capacity (the amount of CPU the logical partition is configured to use), id: MDCS01</p> <p><b>UnusedGlobalCPUCapacity</b> CPU time in milliseconds not used on global server level, id: MDCS23</p> <p><b>UnusedPartitionCPUCapacity</b> Reserved but unused capacity for this operating system container, id: MDCS22</p>
IBMOS400_NetworkPort , IBM_EthernetPort, IBM_TokenRingPort	<p><b>BytesReceived</b> The total number of bytes received, including framing characters, id: MDNP02</p> <p><b>BytesTransmitted</b> The total number of bytes transmitted, including framing characters, id: MDNP01</p> <p><b>ErrorRate</b> Number of network errors per second, id: MDNP03</p> <p><b>Percentage of capacity actually used</b> Id: MDNP04</p>

Table 87. CIM metrics (continued)

Resource/Base CIM class	Metric
IBMOS400_OperatingSystem	<p><b>CPUConsumptionIndex</b> CPU time used divided by CPU time that might have been used by this operating system, id: MDOS25</p> <p><b>ExternalViewKernelModePercentage</b> i5/OS always returns 0, id: MDOS2C</p> <p><b>ExternalViewTotalCPUPercentage</b> External view CPU percentage, id: MDOS2A</p> <p><b>ExternalViewUserModePercentage</b> External view user mode percentage, id: MDOS2B</p> <p><b>FreePhysicalMemory</b> i5/OS always returns 0, id: MDOS04</p> <p><b>FreeSpaceInPagingFiles</b> Free space in system ASP, id: MDOS05</p> <p><b>FreeVirtualMemory</b> Free space in system auxiliary storage pool (ASP), id: MDOS03</p> <p><b>InternalViewIdlePercentage</b> Idle percentage as seen from within the operating system, id: MDOS24</p> <p><b>InternalViewKernelModePercentage</b> i5/OS always returns 0, id: MDOS21</p> <p><b>InternalViewTotalCPUPercentage</b> User mode percentage as seen from within the operating system, id: MDOS23</p> <p><b>InternalViewUserModePercentage</b> i5/OS always returns 0, id: MDOS22</p> <p><b>KernelModeTime</b> i5/OS always returns 0, id: MDOS09</p> <p><b>NumberOfProcesses</b> Number of jobs active during the sample interval, id: MDOS02</p> <p><b>NumberOfUsers</b> Number of interactive jobs active during the sample interval, id: MDOS01</p> <p><b>OperationalStatus</b> i5/OS always returns 0K, id: MDOS08</p> <p><b>PageInRate</b> Number of pages that are paged in per second in all pools, id: MDOS06</p> <p><b>TotalCPUTime</b> Same as UserModeTime, id: MDOS0B</p> <p><b>UserModeTime</b> Total system CPU time used, id: MDOS0A</p>



Table 87. CIM metrics (continued)

Resource/Base CIM class	Metric
IBMOS400_Process	<p><b>AccumulatedKernelModeTime</b> i5/OS always returns 0, id: MDPR29</p> <p><b>AccumulatedTotalCPUTime</b> CPU time spent for this process since process creation, id: MDPR2B</p> <p><b>AccumulatedUserModeTime</b> CPU time in user mode spent for this process since process creation, id: MDPR2A</p> <p><b>ExternalViewTotalCPUPercentage</b> External view total CPU percentage, id: MDPR26</p> <p><b>ExternalViewKernelModePercentage</b> i5/OS always returns 0, id: MDPR28</p> <p><b>ExternalViewUserModePercentage</b> External view user mode percentage, id: MDPR27</p> <p><b>InternalViewKernelModePercentage</b> i5/OS always returns 0, id: MDPR23</p> <p><b>InternalViewTotalCPUPercentage</b> Percentage value related to TotalCPUTime, id: MDPR25</p> <p><b>InternalViewUserModePercentage</b> Percentage value related to UserModeTime, the percentage the system CPUs were used for this process in user mode during the measurement interval, id: MDPR24</p> <p><b>KernelModeTime</b> i5/OS always returns 0, id: MDPR01</p> <p><b>TotalCPUTime</b> Same as UserModeTime, id: MDPR03</p> <p><b>UserModeTime</b> The CPU time used by the job (including all secondary threads), id: MDPR02</p>
IBMOS400_VirtualProcessor	<p><b>TotalCPUTimePercentage</b> The time a virtual processor was used as a percentage of the elapsed interval time, id: MDPC01</p>

### Metrics definition instance provider

The Metrics definition data is no longer stored in the CIM repository, but an explicit instance provider capability is added to the metrics definition provider.

**id** This property of a metric definition class must be generated and be unique for every instance of metric definition.

**Note:** The id value is added in the preceding table.

### Metrics authorization

Metrics providers need to run with QSECOFR authority so that collection services and the performance database work properly. For the nonrequestor providers, Application Administration is used instead of authorizing users to each object that they access. The advantage of Application Administration is that authorization failures are automatically audited by the system.

The user function registration APIs manage the registration and usage information for functions. To help manage systems, the user function registration APIs provide a mechanism for registering functions and controlling which users are allowed to use those functions. The control of user functions, however, is not a replacement for securing resources. Users who are not allowed to use a particular function are not prevented from accessing a resource through another interface. See User Function Registration APIs for more information.

A metrics value provider (including its instance and association capabilities) uses application administration to authorize users to every CIM operation using single registration entry. When operations are routed to the metric value providers, application administration determines whether the user is authorized to that operation. If not authorized, an access denied exception is thrown and a message is returned to tell the user why access is denied. If authorized, the user is permitted to access the metric values.

**Note:** If a user disables the authentication of the CIM server (set `enableAuthentication` as false), the metrics authorization is disabled automatically at the same time. It means that all users can use the capabilities of metrics value providers.

The metrics definition provider has lower security expectations for users, so all its instances and associations can be accessed by any user without checking authorization.

#### **Related concepts**

“User authorization on Universal Manageability Enablement CIMOM” on page 18

*User authorization* is a type of security check that verifies whether you have access to the objects you want to change. Authorization is needed not only for changing operations but sometimes for reading operations as well.

#### **Related tasks**

“Configuring Universal Manageability Enablement CIMOM” on page 4

If you have installed the Universal Manageability Enablement for i5/OS licensed program, use this information to configure the Common Information Model Object Manager (CIMOM).

“Working with authorization for metrics classes of Universal Manageability Enablement CIM” on page 20

You can use Application Administration to work with the authorization for CIM metrics classes.

#### **Related information**

User Function Registration APIs

### **i5/OS support for the CIM indication provider**

You can use the CIM metric indication provider to notify applications when a specific metric event occurs.

The CIM indication provider notifies user applications when specified metric data occurs on the server that the provider supervises. Each application must subscribe to the provider by providing, in query form, information about an event about which it wants data. Examples of events are occurrences such as authentication failures, disk-write errors, or even mouse clicks. The provider then notifies the application when the event occurs. Such an occurrence is called an *indication*. When metrics match client-submitted queries, the indication provider creates the indication and returns it to the client.

**Important:** The metric indication provider only accepts queries that filter on either the `InstanceId` or the `MetricDefinitionId` property. The provider rejects empty filters or a filter that provides only properties other than these two.

#### **Related information**

 The Open Group: CIMIndicationProvider documentation

## Troubleshooting the Universal Manageability Enablement CIM server

Use this information if the CIM server does not start or if the CIM server starts, but does not run as expected.

### The CIM server does not start

If the CIM server does not start, follow these steps:

1. Ensure that the correct options and product are installed on your system.
2. Ensure that the CIM server is configured correctly.

### The CIM server does not run as expected

If you have trouble with the CIM server, follow these steps:

1. Check whether the certificate is expired.  
To check whether the CIM server is running, type `WRKACTJOB JOB(QUMECIMOM)` at a command line. If there is no active job, type the `STRTCPSVR *CIMOM` command to start a server.
2. Check whether the CIMOM repository is corrupted.  
Verify whether the repository directory and configuration files exist in the `/QOpenSys/QIBM/UserData/UME/Pegasus/` directory of the integrated file system. If any of these files are missing, restore all the repository directories and files from your backup. If a backup does not exist, follow the instructions in “Restoring corrupted files” on page 25.
3. Verify whether you are attempting to process a request when the provider is not registered or enabled:
  - a. Type `cimprovider -l -s` to list the name and status of the registered provider modules.
  - b. Type `cimprovider -l-m module-name` to see the individual providers in that module.
4. Check the job log file.
  - a. Type `WRKACTJOB` at a command line.
  - b. Check the `QSYSWRK` subsystem to find the `QUMECIMOM` job.
  - c. Select 5 (Work with), and then type 10 (Display job log, if active, on job queue, or pending).
  - d. If the `QUMECIMOM` job is not running, type `WRKJOB QUMECIMOM`.
  - e. Select the most recent job by typing 1 (Select) next to it.
  - f. If the status is `OUTQ`, type 4 (Work with spooled files), and then type 5 (Display) next to the `QPJOBLOG` file.

#### Related concepts

“Setting the configuration properties” on page 6

Before starting the CIM server, you need to set several configuration properties using the `cimconfig -s -p` command.

---

## Operating system CIM

The Common Information Model (CIM) is supplied with the i5/OS operating system. The system provides an open source implementation of the Common Information Model Object Manager (CIMOM), which is also called Pegasus.

To work with CIM, developers should have a thorough understanding of the CIM standard defined by the DMTF. For more information about the CIM standard, see CIM Specification on the Distributed Management Task Force (DMTF) Web site.

**Note:** It is preferred that you use the CIM function of the IBM Universal Manageability Enablement for i5/OS licensed program (5722-UME). The CIM in the Universal Manageability Enablement for i5/OS licensed program includes all functions that the CIM of the operating system supplies.

Meanwhile, the licensed program includes enhanced CIM support with new features such as Secure Sockets Layer (SSL) and IPv6 support. However, you can still use the CIM server and providers that are supplied with the operating system. The CIM server and CIM providers that are supplied with the operating system are disabled if you install the Universal Manageability Enablement for i5/OS licensed program.

#### **Related concepts**

“Universal Manageability Enablement CIM” on page 4

The Common Information Model (CIM) is a function of the Universal Manageability Enablement for i5/OS licensed program.

#### **Related information**

 [DMTF - Web-Based Enterprise Management \(WBEM\)](#)

 [Common Information Model: Introduction to CIM](#)

 [Common Information Model \(CIM\) Standards](#)

 [The Open Group: OpenPegasus](#)

## **Configuring the operating system CIMOM**

The i5/OS operating system provides an open source implementation of the Common Information Model Object Manager (CIMOM), which is also called Pegasus. You need to configure Pegasus before you can use the program.

To use the operating system CIM on your system, do not install the Universal Manageability Enablement for i5/OS licensed program.

If you install the Universal Manageability Enablement for i5/OS licensed program, the CIM server that is supplied with the operating system is disabled. If you uninstall the licensed program, the operating system CIM server is enabled and it uses the original repository and configuration that existed before you installed the Universal Manageability Enablement licensed program.

To configure CIMOM, follow these steps.

1. Ensure that the operating system has the required installation requirements.
2. Set the configuration properties by using the `cimconfig` command.
3. Grant users the authorizations required to work with CIMOM. In the operating system, Application Administration controls operations that change the local CIM schema, and object authorities control operations that change the system objects.
4. Start CIMOM.

#### **Related concepts**

“Operating system CIMOM command-line utilities” on page 114

You can use a set of command-line utilities to control or change the CIMOM environment. The operating system CIMOM includes these commands: `cimmofl`, `cimconfig`, and `cimprovider`. These commands require `*IOSYSCFG` and `*ALLOBJ` special authorities.

“`cimconfig` usage information” on page 114

You can configure the startup options for the operating system CIMOM with the `cimconfig` command.

## **Ensuring that the system has the required installation options**

CIM requires the specific installation options on the i5/OS operating system.

The system must have the following options installed:

- Extended Base Directory Support (5722-SS1 option 3)
- International Components for Unicode (5722-SS1 option 39)
- Qshell Interpreter (5722-SS1 option 30)

## Setting the required configuration parameters

Before starting the operating system CIM server, you need to set several configuration properties using the **cimconfig** command.

In particular, set the HTTP Authentication (`httpAuthType`) property to specify the type of authentication you want to use. This property has the following values:

- Basic

Basic authentication does not protect passwords.

- Kerberos

To use Kerberos authentication, you need to set up and configure Kerberos, and set the Kerberos service name for the CIMOM service.

**Remember:** Most CIM clients support Basic authentication but not Kerberos authentication. Ensure that you know which type of authentication the CIM clients in your environment support before you configure the CIM server.

You can use the **cimconfig** command to set the current configuration properties or the planned configuration properties of the CIM server. You can change the following properties in the current configuration properties:

- `shutdownTimeout`
- `logLevel`
- `traceComponents`
- `traceFilePath`
- `traceLevel`

These properties are *dynamic*—that is, when you change these properties, the changes take place immediately. You do not need to restart the CIM server to carry out the changes. You can update the current configuration properties only while the CIM server is running.

All of the properties can be changed in the planned configuration properties, whether the CIM server is running or stopped. If the planned configuration properties are changed, those changes will not take effect until the CIM server is restarted. When the CIM server is started, the planned configuration properties become the current configuration properties.

### Related reference

“Troubleshooting the operating system CIM server” on page 133

Use this information if the CIM server does not start or if the CIM server starts, but does not run as expected.

### Basic startup options for the cimconfig command:

You can change basic startup options for the operating system CIMOM with the **cimconfig** command.

The following list describes the startup options and default values for the **cimconfig** command. None of the basic startup options are dynamic.

#### **enableHttpConnection**

Allows user access through the `httpPort`, using HTTP TCP/IP communication. The default is `false`, which means that the CIM server will not listen at the `httpPort`. Set this property to `true` if you are certain your environment is secure.

#### **Default value**

`false`

#### **httpPort**

Port to listen for HTTP requests. If set, then this must be set to a valid port number, and it

overrides the port number of the wbem-http service in the TCP/IP services table. If not set, then the port from the wbem-http service is used. If neither this property nor the wbem-http service port is set, then a hard-coded default of 5988 is used.

This property only takes affect if enableHttpConnection is set to true.

**Default value**  
5988

#### **httpAuthType**

Type of HTTP authentication (Basic, Kerberos).

**Note:** You should not use Basic authentication unless you have a highly secure environment, where passing clear-text passwords is not an issue.

This property determines the authentication to be performed over the HTTP port.

**Default value**  
Basic

**Note:** If the value of the httpAuthType is set to Basic, the user's password is sent in the clear. If this option is set to an unrecognized value the httpAuthType will automatically default to Kerberos.

#### **kerberosServiceName**

If the httpAuthType is set to Kerberos, this sets the Kerberos service name for the CIMOM service, which should match the CIMOM service name configured in the key distribution center (KDC).

**Default value**  
cimom

#### **Advanced startup options for the cimconfig command:**

You can change the advanced startup options for the operating system CIM server with the cimconfig command.

The following list describes the advanced startup options for the cimconfig command, their default values, and whether they can be changed dynamically.

**Note:** The shutdownTimeout, logLevel, traceLevel, traceComponents and traceFilePath settings can be changed dynamically. The others cannot. For all the other properties, you must use the **-p** parameter to indicate your change. You must then stop and restart the CIM Server for the change to take effect.

**Important:** These are options are intended to be used only by advanced users.

#### **messageDir**

The default directory to search for the message bundles. The default value points to the shipped message bundles.

**Default value**  
/QIBM/ProdData/OS400/CIM/msg

**Dynamic**  
No

#### **logLevel**

Sets the level of data logged. Set to TRACE, INFORMATION, SEVERE, FATAL. The log data is saved in the QYCMCIMOM job log.

|           **Default value**  
|           INFORMATION

|           **Dynamic**  
|           Yes

| **enableNormalization**  
|        If set to true, ensures objects delivered from providers are complete and accurate. The default is  
|        false. Do not normalize objects from trusted entities. Objects from the repository, control  
|        providers, IBM-shipped providers and certain vendor providers known to reliably produce valid  
|        objects should not be normalized. Only objects from 3rd party providers added to a distribution  
|        should be normalized. The values are true or false.

|           **Default value**  
|           false

|           **Dynamic**  
|           No

| **excludeModulesFromNormalization**  
|        Disables normalization for objects from specific provider modules. If enableNormalization is set  
|        to true, all provider objects will be normalized except for those on this exclusion list.

|           **Default value**  
|           ""

|           **Dynamic**  
|           No

| **repositoryIsDefaultInstanceProvider**  
|        Enables the repository component of the CIM server to provide CIM object instances by default.  
|        *Default* means that if there is no provider to service the client request for the CIM instance, then  
|        the CIM server repository is used. This includes both creating and retrieving instances. If the  
|        value of the repositoryIsDefaultInstanceProvider option is changed to false, the i5/OS providers  
|        that implement CIM metric classes will no longer function properly. The values are true or false.

|           **Default value**  
|           true

|           **Dynamic**  
|           No

| **enableAuthentication**  
|        If set to true, performs authentication before any request is allowed into the CIM server for  
|        processing. The default is true. Setting this property to false will allow unauthenticated access to  
|        the CIM server.

|        Set enableAuthentication to false only if you are certain your environment is secure and if you  
|        have a very good reason.

|        The values are true or false.

|           **Default value**  
|           true

|           **Dynamic**  
|           No

| **sslCertificateFilePath**  
|        Path to the CIM server's certificate file.

This property must be set to a valid certificate if enableHttpsConnection or enableSslExportClientVerification is set to true. Note that an expired certificate is considered valid when it is loaded by the CIM server.

If sslKeyFilePath is not specified then the CIM server will attempt to load the private key from the certificate file.

**Default value**

ssl/keystore/servercert.pem

**Dynamic**

No

**sslKeyFilePath**

Path to the CIM server's private key file. This property is not required to be set if the certificate specified in sslCertificateKeyPath contains the private key.

This file is not protected by a pass phrase and must be kept in a protected directory. The value that is specified in the default value is a protected directory.

**Default value**

ssl/keystore/serverkey.pem

**Dynamic**

No

**sslTrustStore**

Path to the directory or file containing the trusted certificates for CIM Operation requests. The truststore can include CA certificates.

This property must be set if sslClientVerificationMode is set to required.

If sslClientVerificationMode is set to optional, then this property may be set to empty. In this case no certificates are trusted.

If this property is set to an empty directory, or an empty file, then no certificates are trusted.

If sslClientVerificationMode is set to disabled, this property is not used.

**Default value**

ssl/truststore/

**Dynamic**

No

**exportSSLTrustStore**

Path to the directory or file containing the trusted certificates for CIM Export requests. The truststore can include CA certificates.

This property must be set if enableSslExportClientVerificationMode is set to true.

If this property is set to an empty directory, or an empty file, then no export certificates are trusted.

This property only takes effect if enableSslExportClientVerification is set to true.

**Default value**

ssl/exporttruststore/

**Dynamic**

No

**crlStore**

Path to the directory or file containing the certificate revocation lists.



| If this property is not set, set to an empty directory, or set to an empty file, then no CRLs are  
| loaded.

| This property only takes effect if sslClientVerificationMode is set to required or optional, or  
| enableSSLExportClientVerification is set to true.

| **Default value**  
| ssl/crlstore/

| **Dynamic**  
| No

#### | **sslClientVerificationMode**

| Sets the mode of SSL client certificate verification.

| Set to required, optional, or disabled.

| If set to required, the CIM server always requires verification of a client certificate on the HTTPS  
| port and rejects the request if the client certificate is not trusted. The httpAuthType property is  
| not used.

| Optional means the CIM server will verify a client certificate if available, otherwise the CIM  
| server will use the httpAuthType setting for client verification.

| Disabled means the CIM server will always use the httpAuthType setting for client verification.

| This property is only effective if enableHttpsConnection is set to true.

| **Default value**  
| optional

| **Dynamic**  
| No

#### | **sslTrustStoreUserName**

| Identifies the username that is to be user context for the CIM Operation request when certificate  
| authentication is used, and a username cannot be associated with a specific certificate file. The  
| user context is the i5/OS user profile under which the provider is invoked to perform the CIM  
| request. This property must be set to a valid user profile on i5/OS.

| If sslClientVerificationMode is set to disabled, this property has no effect.

| If sslTrustStore is set to a directory, then this property has no effect. The username associated  
| with the certificate file in the directory is the user context for the CIM operation request. The  
| default setting for sslTrustStore is a directory.

| If sslTrustStore is set to a single file, then this property must be set to a username, otherwise the  
| CIM server will log an error and not start. In this case, ALL certificates included in the file are  
| assigned to the username specified by sslTrustStoreUserName. This user name becomes the user  
| context for the CIM Operation request.

| **Default value**  
| ""

| **Dynamic**  
| No

#### | **enableSubscriptionsForNonprivilegedUsers**

| Set to true or false. The default is false. False means that only a user with \*IOSYSCFG and  
| \*ALLOBJ authorities will be allowed to create Indication Subscriptions.

| **Default value**  
| false

|           **Dynamic**  
|           No

| **enableSSEXPClientVerification**

|           Set to true or false. If true, allows export clients to connect using HTTPS on the port specified by the service name wbem-exp-https. Only CIM Export requests are allowed on this port.

|           **Note:** If the wbem-exp-https port is not defined in the system's TCP/IP services table, then the CIM server will log an error and not start. Since wbem-exp-https is an IANA standard service, it will be in the i5/OS services table by default.

|           If false, then no requests are allowed on the wbem-exp-https port.

|           **Default value**  
|           true

|           **Dynamic**  
|           No

| **shutdownTimeout**

|           Set to a number of seconds. When an ENDTCPSPVR \*CIMOM command is issued, the timeout is the maximum number of seconds allowed for the CIM server to complete outstanding CIM operation requests before shutting down. If the specified timeout period expires, the CIM server will shut down, even if there are still CIM operations in progress. Minimum value is 2 seconds. Default value is 10 seconds.

|           **Default value**  
|           10

|           **Dynamic**  
|           Yes

| **traceLevel**

|           Level of debug trace. Range is 1 to 4. A traceLevel of 1 only traces function exits, the minimum trace. A trace level of 4 is the maximum trace.

|           **Default value**  
|           1

|           **Dynamic**  
|           Yes

| **traceFilePath**

|           Path to the trace file.

|           **Default value**  
|           /qibm/userdata/os400/cim/cimserver.trc

|           **Dynamic**  
|           Yes

| **traceComponents**

|           Components of Pegasus to trace. The valid settings are listed in "Settings for the traceComponents option" on page 109.

|           **Default value**  
|           empty

|           **Dynamic**  
|           Yes

| **enableAssociationTraversal**

| Set to true or false. The default is true. True means association traversal is enabled. False will  
| disable association traversal.

| **Default value**

| true

| **Dynamic**

| No

| **enableIndicationService**

| Set to true or false. The default is true. True means the indication service is enabled. False will  
| disable the indication service.

| **Default value**

| true

| **Dynamic**

| No

| **tempLocalAuthDir**

| The directory where the Pegasus server writes temporary files that it uses during local  
| authentication.

| **Default value**

| /tmp

| **Dynamic**

| No

| **idleSessionTimeout**

| This property specifies the minimum timeout value for idle client connections. If the value is  
| zero, idle client connections are not disconnected.

| **Default value**

| 0

| **Dynamic**

| No

| **Settings for the traceComponents option:**

| The settings in this topic are valid for the traceComponents option.

- | • ALL
- | • AsyncOpNode
- | • Authentication
- | • Authorization
- | • BinaryMessageHandler
- | • Channel
- | • CimData
- | • CIMExportRequestDispatcher
- | • CIMOMHandle
- | • Config
- | • ConfigurationManager
- | • ControlProvider
- | • CQL
- | • DiscardedData
- | • Dispatcher

- | • ExportClient
- | • Http
- | • IndDelivery
- | • IndicationHandlerService
- | • IndicationService
- | • IndicationServiceInternal
- | • IndHandler
- | • IPC
- | • L10N
- | • Listener
- | • Memory
- | • MessageQueueService
- | • MetaDispatcher
- | • ObjectResolution
- | • OsAbstraction
- | • ProviderAgent
- | • ProviderManager
- | • ProvManager
- | • Registration
- | • Repository
- | • Server
- | • Shutdown
- | • SubscriptionService
- | • Thread
- | • UserManager
- | • WQL
- | • XmlIO
- | • XmlParser
- | • XmlReader
- | • XmlWriter

### | **Starting the operating system CIMOM job**

| All the functions of the operating system CIMOM run under a single TCP/IP server job, QYCMCIMOM.

| This job runs in the QSYSWRK subsystem, and is not started by default.

| To start the CIMOM job, follow these steps:

- | 1. Work with the CIMOM job in iSeries Navigator by selecting **Network** → **Servers** → **TCP/IP**
- | 2. Select **CIMOM** You can use this window to start or stop the CIMOM, and to determine whether the CIMOM starts with TCP/IP by default.

| **Note:** You can also start the CIMOM job from the command-line interface using the command  
| STRTCPSVR \*CIMOM.

| You can end the CIMOM job using the command ENDTCPSVR \*CIMOM.

## Operating system CIMOM security

The i5/OS operating system provides an open source implementation of CIMOM, which is also called Pegasus. You have several options to ensure that the CIM server that is supplied with the operating system is secure. In Pegasus, two types of security checks are available: authentication and authorization.

### Authentication

Pegasus uses an authentication process to determine which users can log into the CIMOM. Unless the `enableAuthentication` property of the `cimconfig` command is set to false, authentication is performed for every connection, before users can access the CIM data.

For Pegasus on i5/OS, users log in over HTTP or HTTPS, using either Basic or Kerberos authentication. In addition for HTTPS they have a choice of logging in using certificate-based authentication

When logging in, users are authenticated using their i5/OS profile, or using Enterprise Identity Mapping (EIM).

In the open source implementation, Pegasus maintains a separate access control list (ACL) that allows users to sign in using a CIM user profile, which does not necessarily require a corresponding profile on the system. In contrast, the i5/OS implementation of Pegasus requires each user to have a profile in i5/OS. After the user has been authenticated, a user (or the user's jobs) can have access to the providers and CIM schemas managed by the CIMOM.

### Authorization

A type of security check that is required for Pegasus on i5/OS is verifying that users have access to the objects they are trying to change. This process is called *authorization*.

In Pegasus, there are two types of operations that require users to have authorization to perform them: CIM class and qualifier operations, and CIM instance operations.

CIM class and qualifier operations change the local copy of the CIM schema (for example, `DeleteClass`). Users need authorization to these operations before being able to use the operations listed in the following information with systems management data provided by CIM. These operations do not change any i5/OS system objects, but because they do change the CIM schema exposed to clients, some authorization is required to use them. For the iSeries servers, authorization to these operations is controlled by Application Administration in iSeries Navigator.

CIM instance operations let users work with the server resources modeled by the Pegasus providers. These providers are implemented as server exit programs (\*SRVPGM) in i5/OS, and users require authorization to these service programs before they can use them. All of the providers included in V5R3 ship with PUBLIC \*USE authority, except for the metric provider QSYS/QYCPCSMV, which is shipped with PUBLIC \*EXCLUDE authority. If any providers are added that are not shipped with PUBLIC \*USE authority, administrators must explicitly grant users authorization to these objects.

#### Related concepts

Enterprise Identity Mapping (EIM)

"cimconfig usage information" on page 114

You can configure the startup options for the operating system CIMOM with the `cimconfig` command.

Network authentication service

Host name resolutions considerations

## Authorizing Pegasus

You can use Application Administration to work with authorization for CIM operations.

To work with Pegasus authorization, follow these steps:

1. Start iSeries Navigator.
2. From **My connections**, right-click the system you want to change.
3. Select **Application Administration**.
4. Select **Local Settings** (if available).
5. Select **Host Applications** tab.
6. Expand **CIMOM server**.
7. Add or remove a user or groups authorization to the following operations.

Application Administration allows users to be authorized to the following operations:

- GetClass
- DeleteClass
- CreateClass
- ModifyClass
- EnumerateClasses
- EnumerateClassNames
- GetQualifier
- SetQualifier
- DeleteQualifier
- EnumerateQualifiers

## Enabling Kerberos

Pegasus on iSeries supports both Kerberos and Enterprise Identity Mapping (EIM). To enable Kerberos, use the `cimconfig` commands to set the `httpAuthType` configuration option to Kerberos (this is the default value).

For all IBM server platforms, the Kerberos default server name is **cimom**. For i5/OS, you can also use the service name **krbsvr400**. See the Network Authentication Service topic for more information about Kerberos on i5/OS. For information about resolving the host name for Kerberos, follow the instructions in the Hostname resolutions considerations information in the Network Authentication Service topic collection.

For example, one method for setting the CIMOM service principal would be to enter the following commands:

1. On the i5/OS system where the KDC is running, add the service principal cimom with the following command:

```
addprinc cimom/<host>@<realm>
```

You will be prompted for the password to the KDC.

2. On each i5/OS where the CIMOM server will need to run, add the service principal cimom with the following command:

```
keytab add cimom/<host>@<realm>
```

You will be prompted for the password to the keytab file.

This example makes the following assumptions:

- The password in the KDC and keytab file must match.
- The host is in the case as determined by following the instructions in the Hostname resolutions considerations.

**Note:**

- Refer to the Keytab command information in the Network Authentication Service topic.
- If Kerberos authentication is enabled, only CIM clients that support Kerberos authentication can connect to the CIM server.

If EIM is not enabled, the Kerberos principal will be directly used as the user identity on the system where CIMOM is running. The administrator must set up matching user identities on all their systems. For example, if a customer chooses not to configure and enable EIM, then the administrator must be aware that a Kerberos principal john is always mapped to john as the local user identity.

## Backup and recovery considerations for operating system CIMOM

It is important to schedule backups of the repository directories and files. If the repository is moved, is lost, or becomes corrupted, restore the files that you have backed up.

Here are the namespaces that are installed with CIMOM:

**root** The root namespace conforms to the Distributed Management Task Force (DMTF) specifications.

**root/cimv2**

This is for standard CIM schemas for the shipped providers.

**root/PG\_InterOp**

This is for provider registration. This space is reserved exclusively for providers and all providers must be registered.

**root/PG\_Internal**

This space is reserved and used by CIMOM.

**root/ibmsd**

The namespace is owned and used by IBM Director.

The Pegasus repository is located in the qibm/userdata/os400/cim directory in the integrated file system. Pegasus keeps definitions of the data about managed objects and their providers in this repository. In addition, other definitions might be added by clients and providers.

Pegasus also stores two important configuration files in the qibm/userdata/os400/cim directory:

- cimserver\_current.conf. This file contains the current values that are not the default.
- cimserver\_planned.conf. This file contains planned values, not yet in effect and that are not the default.

**Attention:** Do not attempt to manually edit the configuration files. You must use the **cimconfig** command.

If the files in this directory are deleted, moved, or corrupted, you need to restore them from the backup.

**Important:** If the latest backed up repository is from i5/OS V5R3, do not restore it to a system that has Pegasus V2.5. After you install Pegasus V2.5 and upgrade the repository, back up the new repository immediately after the CIM server has been restarted.

**Related information**

Backing up your system

## Restoring corrupted files

Use this information if the backup copy of your CIM repository files are corrupted.

To recover your files, use the information in the following list:

**Repository classes and qualifiers (static data)**

1. Undo whatever was done to create the class or qualifier. For example, uninstall a client application or take manual steps to undo what was done.
2. Put the class or qualifier back the same way it was before. For example, reinstall a client application. If the problem persists, contact your service provider.

### Repository instances

1. Undo whatever was done to create the instance. For example, uninstall a client application or take manual steps to undo what was done.
2. Put the class or qualifier back the same way it was before. For example, reinstall a client application. If the problem still exists, contact your service provider.

### Provider registration data (also instances)

1. Use the cimprovider command to remove the provider registration.
2. Use the cimmof command to recompile and reregister the data. If the problem still exists, contact your service provider.

## Operating system CIMOM command-line utilities

You can use a set of command-line utilities to control or change the CIMOM environment. The operating system CIMOM includes these commands: cimmoftl, cimconfig, and cimprovider. These commands require \*IOSYSCFG and \*ALLOBJ special authorities.

All of the command-line utilities need to run from a QSHELL command-line, which requires that the QSHELL product (SS1 opt. 30) be installed on the system. You can run these commands from /QIBM/UserData/OS400/CIM.

During normal use, administrators should rarely need to use these commands.

### Related tasks

“Configuring the operating system CIMOM” on page 102

The i5/OS operating system provides an open source implementation of the Common Information Model Object Manager (CIMOM), which is also called Pegasus. You need to configure Pegasus before you can use the program.

### cimconfig usage information

You can configure the startup options for the operating system CIMOM with the cimconfig command.

If you change any configuration properties that are in the planned configuration settings, changes will not take effect until the CIM server is restarted.

**Note:** You can run this command from /QIBM/UserData/OS400/CIM.

**Name** cimconfig - get, set, unset or list CIMOM configuration properties.

### Synopsis

Usage:

- cimconfig -g name [ -c ] [ -d ] [ -p ] [ -q ]
- cimconfig -s name=value [ -c ] [ -p ] [ -q ]
- cimconfig -u name [ -c ] [ -p ] [ -q ]
- cimconfig -l [ -c | -p ]
- cimconfig -h
- cimconfig --help
- cimconfig --version

### Remarks

The cimconfig command provides a command-line interface to manage CIMOM configuration properties.



The first form of `cimconfig` provides the current, planned, and default value of the specified configuration property.

The second form allows to set the current value and planned value of the specified configuration property to the specified value.

The third form allows unsetting the current and planned values of the specified configuration property to its default value.

The fourth form of this command allows for all the configuration properties to be listed. If you specify the `-c` or `-p` option, the program provides a listing of all the current or planned configuration property names and values.

## Options

The `cimconfig` command recognizes the following options:

- | **-h, --help**  
| Displays command help information
- | **--version**  
| Displays CIMOM server version
- | **-g name**  
| Gets the current value of the specified configuration property. Returns an error when the CIMOM is not running.
- | **-g name -c**  
| Gets the current value of the specified configuration property. Returns an error when the CIMOM is not running.
- | **-g name -p**  
| Gets the planned value of the specified configuration property.
- | **-g name -d**  
| Gets the default value of the specified configuration property. Returns an error when the CIMOM is not running.
- | **-s name=value**  
| Indicates that a configuration property is to be added or updated by setting its current value to the specified value. Returns an error when the CIMOM is not running or the specified property cannot be updated dynamically.
- | **-s name=value -c**  
| Indicates that a configuration property is to be added or updated by setting its current value to the specified value. Returns an error when the CIMOM is not running or the specified property cannot be updated dynamically.
- | **-s name=value -p**  
| Indicates that a configuration property is to be added or updated by setting its planned value to the specified value.
- | **-u name**  
| Indicates that the current value of the specified configuration property is to be reset to the default value. Returns an error when the CIMOM is not running or the specified property cannot be updated dynamically.
- | **-u name -c**  
| Indicates that the current value of the specified configuration property is to be reset to the default value. Returns an error when the CIMOM is not running or the specified property cannot be updated dynamically.

- u name -p** Indicates that the planned value of the specified configuration property is to be reset to the default value.
- l** Displays the name of all the configuration properties. Returns an error when the CIMOM is not running.
- l -c** Displays the name and value pair of all the current configuration properties. Returns an error when the CIMOM is not running.
- l -p** Displays the name and value pair of all the planned configuration properties.
- q** Quiet option specifies that no output is sent to standard output or standard error.

**iSeries-specific usage:** On an iSeries server, this command requires the user to have \*IOSYSCFG and \*ALLOBJ authority.

**Note:** You can use the cimconfig command to set the current or planned configuration properties of the CIMOM. You can update the current configuration properties only while the CIMOM is running. All of the properties can be changed in the planned configuration properties, whether the CIMOM is running or stopped. If the planned configuration properties are changed, those changes will not take effect until the CIMOM is restarted. When the CIMOM is started, the planned configuration properties become the current configuration properties.

#### Related concepts

“Operating system CIMOM security” on page 111

The i5/OS operating system provides an open source implementation of CIMOM, which is also called Pegasus. You have several options to ensure that the CIM server that is supplied with the operating system is secure. In Pegasus, two types of security checks are available: authentication and authorization.

#### Related tasks

“Configuring the operating system CIMOM” on page 102

The i5/OS operating system provides an open source implementation of the Common Information Model Object Manager (CIMOM), which is also called Pegasus. You need to configure Pegasus before you can use the program.

### cimmofl usage information

Use this command to compile provider registrations and to compile CIM class descriptions (using the Managed Object Format [MOF] language) into the class schema stored in the repository.

The CIMOM must be stopped before using this command.

**Note:** You can run this command from /QIBM/UserData/OS400/CIM.

**Name** cimmofl - used to compile CIM class descriptions (using the MOF language) into the class schema stored in the repository. The CIMOM must be stopped before using this command.

#### Synopsis

Usage:

```
cimmofl -h | --help
```

```
cimmofl --version
```

```
cimmofl [ -w ] [ -E ] [ -uc ] [ -aE | -aV | -aEV ] [ -I path ] [ -n namespace |
--namespace namespace ] [ --xml ] [ --tracefile ] [ -q ]
[ -R repositorydir | --CIMRepository repositorydir ] [ -N repositoryname ] [ -M
repositorymode] mof_file...
```

#### Description

This command is used to compile provider registrations and to compile CIM class descriptions (using the MOF language) into the class schema stored in the repository. The CIMOM must be stopped before using this command.

The Pegasus MOF compiler is a command-line utility that compiles MOF files (using the MOF format defined by the DMTF CIM Specification) into a Pegasus repository. It allows compiling from structures of MOF files using the include pragma and can either compile into a Pegasus repository or perform a syntax check on the MOF files. The compiler requires that the input MOF files be in the current directory or that a fully qualified path be given. MOF files included using the #pragma include must be in the current directory or in a directory specified by a -I command-line switch.

## Options

### **-h, --help**

Print out usage message with command definitions.

### **--version**

Displays the CIMOM server version

**-E** Used to perform a syntax check on the input. This option does not update the repository.

**-w** Suppresses warning messages.

**-q** Used to suppress all messages except command-line usage errors.

**-uc** Used to allow the update of an existing class definition. This option lets you update a leaf class. It does not allow updates of superclasses or classes that have subclasses.

**-aE** Used to allow the addition or modification of classes with the experimental qualifier.

**-aV** Used to update a class that results in a version change. This option allows the major version of the class to be changed, allows the version to be down leveled, or allows the version to be removed. The version must be specified in a valid format. The format is m.n.u where m is major version, n is minor release and u is update. For example, 2.7.0 is a valid format for CIM schema 2.7.0. If the input class has the same version as the class in the repository, the class is not updated.

**-aEV** Allow both Experimental and Version Schema changes.

### **-R<path>**

Specifies the path to the repository to be written. Specify an absolute or relative path. The default is /QIBM/UserData/OS400/CIM.

### **--CIMRepository<path>**

If specified, this overrides the current repository path. Specify an absolute or relative path. The default is /QIBM/UserData/OS400/CIM.

### **-I<path>**

Used to specify a path to the included MOF files.

### **-n<path>**

Used to override the default CIM repository namespace. The default is root/cimv2.

### **--namespace<path>**

Used to override default CIM repository namespace. The default is root/cimv2.

**--xml** Used to generate XML to standard output. This option does not update the repository.

**--trace** Used to write trace information to a file. The output destination is standard output.

### **--trace=<tracefile>**

Used to write trace information to the specified file.

**-N repositoryname**

Used to specify the repository name. This is the relative path to the directory in the **-R** option. The default is **repository**.

**-M repositorymode**

Used to specify the Repository mode [XML, BIN].

**Note:** The default is **XML**, and this is the only allowed value on i5/OS.

**Examples**

```
cimmofl -w -Rtestrepository -I./myDir myDir/CIM_Schema.mof
```

**Note:** Compile the Managed Object Format (MOF) file located in directory `myDir` with the name `CIM_Schema.mof`. `CIM_Schema.mof` includes pragmas for other mof files that are also in the MOF directory. It will create the repository in directory `testrepository` using the default namespace `root/cimv2`. It assumes that the `testrepository` directory exists. Use the `-w` option to suppress warning messages.

```
cimmofl -w -R/qibm/userdata/os400/cim -I/qibm/proddata/os400/cim/schemas/cim
-nroot/cimv2 /qibm/proddata/os400/cim/schemas/cim/CIM_Schema.mof
```

**Note:** Compile the MOF file located in the directory `/qibm/proddata/os400/cim/schemas/cim` with the name `CIM_Schema.mof`. `CIM_Schema.mof` includes pragmas for other mof files that are also in the `/qibm/proddata/os400/cim/schemas/cim` directory. It will create the repository in directory `/qibm/userdata/os400/cim` using namespace `root/cimv2`. It assumes that the `/qibm/userdata/os400/cim` directory exists. Use the `-w` option to suppress warning messages.

**iSeries-specific usage:** On an iSeries server, this command requires the user to have `*IOSYSCFG` and `*ALLOBJ` authority.

**cimprovider usage information**

Enable or disable a registered provider, primarily during testing with this command. The CIMOM must be running to use this command.

**Note:** You can run this command from `/QIBM/UserData/OS400/CIM`.

**Name** `cimprovider` - disable, enable, remove or list registered CIM providers or CIM provider modules and module status.

**Synopsis**

Usage:

- `cimprovider -d -m module [ -q ]`
- `cimprovider -e -m module [ -q ]`
- `cimprovider -r -m module [ -p provider ] [ -q ]`
- `cimprovider -l [ -s | -m module ]`
- `cimprovider -h`
- `cimprovider --help`

**Limitations**

This command disables, enables, or removes only one CIM provider module or CIM provider at a time.

**Description**

The `cimprovider` command provides a command-line interface to disable, enable, unregister, and list registered CIM providers. If a CIM provider is disabled, the CIMOM rejects any requests to the provider. If a CIM provider is enabled, the CIMOM forwards requests to the provider. And if a CIM provider is unregistered, the CIMOM will no longer have any information about the

provider. In order to use the cimprovider command, cimserver has to be running and the specified provider module (a grouping of providers in the same \*SVRPGM) or provider has to be registered with the CIMOM.

The first form of cimprovider disables the specified provider module. When a specified provider module is in the disabled state, any new requests to the providers that are contained in the specified provider module will be rejected.

The second form of cimprovider enables the providers that are contained in the specified provider module. The providers that are contained in the specified provider module are now ready to accept new request.

The third form of cimprovider removes (unregisters) the specified provider module and all of its contained providers or the specified provider in the specified provider module. Once removed a provider or provider module, must be reregistered (typically by loading its registration schema using the cimmofl command).

The fourth form of cimprovider lists all the registered provider modules and the module status, or lists all the providers in the specified provider module. To list all providers in all modules, issue the cimprovider -l command, followed by cimprovider -l -m for each listed module.

## Options

The cimprovider command recognizes the following options:

- | **-h, --help**  
| Displays command help information.
- | **--version**  
| Displays the CIMOM server version.
- | **-d** Disables the specified CIM provider module. If the module is already disabled, an error message is returned.
- | **-e** Enables the specified CIM provider module. If the module is already enabled or is currently being disabled, an error message is returned.
- | **-r** Removes the specified provider module and all of its contained providers. If a provider is specified, removes the specified provider in the specified provider module without affecting any other providers in that module.
- | **-l** Displays all the registered provider modules.
- | **-m Module**  
| Specifies the provider module for the operation.
- | **-p Provider**  
| Specifies the provider for the operation.
- | **-q** Quiet option specifies no output is sent to standard output or standard error.
- | **-s** Displays the status of provider modules.

## Examples

**cimprovider -d -m myProviderModule**

Disable provider module myProviderModule and all of its contained providers (placing them in a stopped state).

**cimprovider -e -m myProviderModule**

Enable provider module myProviderModule and all of its contained providers (placing them in a OK state).

**cimprovider -r -m myProviderModule**

Remove (unregister) the myProviderModule provider module and all of its contained providers.

**cimprovider -r -m myProviderModule -p MyProvider**

Remove (unregister) the MyProvider provider that is contained in the myProviderModule provider module.

**cimprovider -l**

List the registered provider modules.

**cimprovider -l -s**

List the registered provider modules and their status (such as OK, Stopping, Stopped).

**cimprovider -l -m myProvider**

List the registered providers that are in the myProviderModule provider module.

**iSeries server-specific usage:** On an iSeries server, this command requires the user to have \*IOSYSCFG and \*ALLOBJ authority.

## Reference information for operating system CIM

The Common Information Model (CIM) that is supplied with the i5/OS operating system includes development tools, samples, and reference material. The operating system includes providers that support basic operating system information and some performance metrics.

Pegasus on i5/OS does not support Service Location Protocol (SLP).

### Related information

 [Common Information Model \(CIM\) Standards](#)

 [The Open Group: OpenPegasus](#)

## Supported CIM base operating system classes

IBM has implemented CIM classes as IBM-supplied providers to provide basic operating system information.

The providers supplied by IBM are as follows:

- IBMOS400\_ComputerSystem: subclass of CIM\_Computer\_System
- IBMOS400\_OperatingSystem: subclass of CIM\_OperatingSystem
- IBMOS400\_RunningOS: subclass of CIM\_RunningOS
- IBMOS400\_Process: subclass of CIM\_Process
- IBMOS400\_OSProcess: subclass of CIM\_OSProcess
- IBMOS400\_VirtualProcessor: subclass of CIM\_Processor
- IBM\_IPProtocolEndpoint: a subclass of CIM\_IPProtocolEndpoint
- IBM\_LocalFileSystem: a subclass of CIM\_LocalFileSystem
- IBM\_RemoteFileSystem: a subclass of CIM\_RemoteFileSystem
- IBM\_NFS: a subclass of CIM\_NFS
- IBMOS400\_NetworkPort: a subclass of CIM\_NetworkPort
- IBM\_EthernetPort: a subclass of CIM\_EthernetPort
- IBM\_TokenRingPort: a subclass of CIM\_TokenRingPort
- IBMOS400\_CSVirtualProcessor: a subclass of CIM\_SystemDevice
- IBM\_CSNetworkPort: a subclass of CIM\_SystemDevice
- IBMOS400\_HostedFileSystem: a subclass of CIM\_HostedFileSystem
- IBM\_BootOSFromFS: a subclass of CIM\_BootOSFromFS
- IBM\_NWPortImplementsIPEndpoint: a subclass of CIM\_PortImplementsEndpoint

Some property values are available in several languages to CIM clients that follow the globalization interface as described in the DMTF standards.

The following figure shows the CIM base classes that are extended by the IBM extension classes.




Figure 7. CIM Classes






Figure 8. CIM Classes--continued

The managed object format (MOF) files that define these classes can be found in the /QIBM/ProdData/OS400/CIM/Schemas/OS400/ directory. The file names are as follows:

- IBMOS400\_OSBase.mof
- IBMOS400\_BootOSFromFS.mof
- IBMOS400\_CSNetworkPort.mof
- IBMOS400\_CSVirtualProcessor.mof
- IBMOS400\_FileSystem.mof
- IBMOS400\_HostedFileSystem.mof
- IBMOS400\_NWPortImplementsIPEndpoint.mof
- IBMOS400\_NetworkPort.mof

- IBMOS400\_ProtocolEndpoints.mof
- IBMOS400\_VirtualProcessor.mof

## IBMOS400\_ComputerSystem

This class makes available basic computer system information such as computer name, and status information. This provider instrumenting this class is for use by clients as part of a basic understanding of the identity of the managed system on which it is running (typically a server or appliance).

The following properties have data that can be specific to i5/OS, or can map to i5/OS system-specific attributes.

Property	Property value and data source
string OtherIdentifyingInfo[]	Returns the system: <ul style="list-style-type: none"> <li>• Type</li> <li>• Serial number</li> <li>• Model</li> <li>• Partition identifier</li> </ul>
Name	The system name based on the first entry in the TCP/IP host table.

**Note:** The methods on IBMOS400\_ComputerSystem have not been implemented. This provider does not register as a method provider.

## IBMOS400\_OperatingSystem

This class is for use by clients as part of a basic understanding of the identity of the Managed System on which the corresponding provider is running (typically a server or appliance).

The following properties have data that may be specific to i5/OS, or may map to i5/OS specific attributes.

Property	Property value and data source
uint32 NumberOfUsers	The number of interactive jobs on the system
uint32 NumberOfProcesses	The total number of user jobs and system jobs that are currently in the system. The total includes: <ul style="list-style-type: none"> <li>• All jobs on job queues waiting to be processed.</li> <li>• All jobs currently active (being processed).</li> <li>• All jobs that have finished running but still have output on output queues to be produced.</li> </ul>
uint32 MaxNumberOfProcesses	The maximum number of jobs that are allowed on the system.
string LanguageEdition	Returns QLANGID system value.
string CodeSet (maximum length is 64)	Returns code page field from QCHRID system value.
uint32 DefaultPageSize (in bytes)	Always returns 4096.

**Note:** For the IBMOS400\_OperatingSystem class, the Shutdown() and Reboot() methods are implemented in V5R4.

## IBMOS400\_RunningOS

This provider for this class is for use by clients to find associations between a computer system and the operating system that is currently running on the computer system.

## IBMOS400\_Process

The provider for this class makes available basic process information such as process name (a fully qualified job name on i5/OS), priority, runtime state. An IBMOS400\_Process is mapped to i5/OS jobs on the iSeries server. Client applications can use this provider to give clients an understanding of the processes (jobs) running on the managed system within the context of its operating system.

**Note:** There are many (potentially thousands) of i5/OS jobs running or in queues on any given i5/OS system. For performance reasons, any CIM client application that needs to obtain a list of i5/OS jobs should first EnumerateInstanceNames and then perform a GetInstance for each i5/OS job for which instance data is required.

The following properties have data that can be specific to i5/OS, or can map to i5/OS specific attributes.

Property	Property value and data source
string ElementName	Returns string from the Name field below - the fully-qualified job name on i5/OS as viewed on command-line interface.
string Name	This is the fully-qualified job name on i5/OS as viewed on the command-line interface:  <i>Job number</i> field + / + <i>User name</i> field + / + <i>Job name</i> field where <i>Job number</i> is the system-generated job number. <i>User name</i> is the user name of the job, which is the same as the name of the user profile under which the job was started. <i>Job name</i> is the name of the job as identified to the system.
string Handle [Key]	This is the fully-qualified job name on the i5/OS as used in the i5/OS work management APIs: <i>Job name</i> field + / + <i>User name</i> field + / + <i>job number</i> field where <i>Job name</i> is the name of the job as identified to the system. <i>User name</i> is the user name of the job, which is the same as the name of the user profile under which the job was started. <i>Job number</i> is the system-generated job number.
uint16 ExecutionState	Based on the Job Status obtained from Retrieve Job Information (QUSRJOBI) API, Format JOBI0100, Job status field.  This is based on the i5/OS active job status. The i5/OS active job status values are mapped to the ExecutionState values as follows:

Property	Property value and data source	
	No status	0 ("Unknown")
	BSCA	4 ("Blocked")
	BSCW	4 ("Blocked")
	CMNA	4 ("Blocked")
	CMNW	4 ("Blocked")
	CMTW	4 ("Blocked")
	CNDW	4 ("Blocked")
	CPCW	4 ("Blocked")
	DEQA	4 ("Blocked")
	DEQW	4 ("Blocked")
	DKTA	4 ("Blocked")
	DKTW	4 ("Blocked")
	DLYW	6 ("Suspended Ready")
	DSC	1 ("Other")
	DSPA	5 ("Suspended Blocked")
	DSPW	5 ("Suspended Blocked")
	END	1 ("Other")
	EOFA	4 ("Blocked")
	EOFW	4 ("Blocked")
	EOJ	1 ("Other")
	EVTW	5 ("Suspended Blocked")
	GRP	6 ("Suspended Ready")
	HLD	6 ("Suspended Ready")
	HLDT	6 ("Suspended Ready")
	ICFA	4 ("Blocked")
	ICFW	4 ("Blocked")
	INEL	1 ("Other")
	JVAA	4 ("Blocked")
	JVAW	4 ("Blocked")
	LCKW	5 ("Suspended Blocked")
	LSPA	4 ("Blocked")
	LSPW	4 ("Blocked")
	MLTA	4 ("Blocked")
	MLTW	4 ("Blocked")
	MSGW	5 ("Suspended Blocked")
	MTXW	5 ("Suspended Blocked")
	MXDW	4 ("Blocked")
	OPTA	4 ("Blocked")
	OPTW	4 ("Blocked")
	OSIW	4 ("Blocked")
	PRTA	4 ("Blocked")
	PRTW	4 ("Blocked")
	PSRW	2 ("Ready")
	RUN	3 ("Running")
	SELW	4 ("Blocked")
	SEMW	5 ("Suspended Blocked")
	SIGS	8 ("Suspended Blocked")
	SIGW	5 ("Suspended Blocked")
	SRQ	6 ("Suspended Ready")
	SVFA	4 ("Blocked")
	SVFW	4 ("Blocked")
	TAPA	4 ("Blocked")
	TAPW	4 ("Blocked")
	THDW	4 ("Blocked")
	TIMA	6 ("Suspended Ready")
	TIMW	6 ("Suspended Ready")
	All other values	0 ("Unknown")

Property	Property value and data source
string OtherExecutionDescription	Returns the active job status as a string. Because most of the active job status take an entire sentence to explain, the CHAR(4) active job status itself is returned.
datetime CreationDate	Date and time job became active when the job began to run on the system. This information is not available if the job did not become active.
datetime TerminationDate	Date and time job ended. When the job running on the system was complete. If the job was not complete, zeros are returned.
uint64 KernelModeTime (in milliseconds)	System time spent running. Because i5/OS does not distinguish between system time and user time, this value cannot be reported. Returns 0 (zero) indicating information is not available.
uint64 UserModeTime (in milliseconds)	User time spent executing. Since i5/OS does not distinguish between system time and user time, this value reflects the processing unit time (in milliseconds) that the job used. This information is available only for active jobs.

### IBMOS400\_OSProcess

The provider for this class provides a link between the operating system and processes running in the context of this operating system. Client applications can use this provider to give clients an understanding of the processes (jobs) running on the managed system within the context of its operating system.

### IBMOS400\_VirtualProcessor

The provider for this class models an internal hypervisor array element that represents an internal virtual processor for the partition.

**Note:** Only active processors are returned.

Property	Property value and data source
string DeviceID [Key]	This number represents an index into an internal array in the hypervisor. This number is converted to a string.
uint16 OperationalStatus[] (ValueMap)	Indicates the current status of the element. Always returns 2 (OK).

### IBM\_IPProtocolEndpoint properties

An IBM\_IPProtocol Endpoint is mapped to a TCP interface on an i5/OS iSeries system.

Property	Property value and data source
string Description	The IP address and the associated line description. For example, The i5/OS IP protocol endpoint named 1.2.3.4, and associated with the line description TRNLINE.
string ElementName	The TCP interface IP address. For example 1.2.3.4.

### IBM\_LocalFileSystem, IBM\_RemoteFileSystem, IBM\_NFS Properties

The IBM\_LocalFileSystem class models the Root, QOpenSys, QDLS, QSYSLIB, UDFS, Optical and IASP QSYSLIB local file systems on i5/OS. The IBM\_RemoteFileSystem class models the QFileServer400, Netware and QNTC remote file systems for i5/OS. The IBM\_NFS class models the NFS file system for i5/OS.

Property	Property value and data source
string ElementName	Indicates the path name or other information defining the root of the file system.
string Name	Indicates the key of a file system instance within a computer system.
string Root	Indicates the path name or other information defining the root of the file system.

### IBMOS400\_NetworkPort, IBM\_EthernetPort, and IBM\_TokenRingPort Properties

The **IBM\_EthernetPort** property models the Ethernet line descriptions for i5/OS. The **IBM\_TokenRingPort** property models the token ring line descriptions for i5/OS. The **IBMOS400\_NetworkPort** property models all other line description types.

Property	Property value and data source
string Description	The name of the line description and its type.
string ElementName	The name of the line description.

### IBMOS400\_CSVirtualProcessor

IBMOS400\_CSVirtualProcessor is an association class that associates a partition virtual-processor with a computer system.

Property	Property value and data source
IBMOS400_ComputerSystem REF GroupComponent	The parent computer system in the association. Returns a reference to the IBMOS400_ComputerSystem class.
IBMOS400_VirtualProcessor REF PartComponent	The virtual processor that is a component of a computer system. Returns a reference to the IBMOS400_VirtualProcessor class representing this particular virtual processor.

### IBM\_CSNetworkPort

IBM\_CSNetworkPort is an association class that associates a network port with a computer system.

Property	Property value and data source
IBMOS400_ComputerSystem REF GroupComponent	The parent computer system in the association returns a reference to the IBMOS400_ComputerSystemIBM class. Returns a reference to the IBMOS400_ComputerSystem class.
CIM_NetworkPort REF PartComponent	The network port that is a component of a computer system. Returns a reference to the CIM_NetworkPort class representing this particular network port.

### IBMOS400\_HostedFileSystem

The IBMOS400\_HostedFileSystem association class associates a file system with a computer system.

Property	Property value and data source
IBMOS400_ComputerSystem REF GroupComponent	The parent computer system in the association. Returns a reference to the IBMOS400_ComputerSystem class.

Property	Property value and data source
CIM_FileSystem REF PartComponent	The file system that is a component of a computer system. Returns a reference to the CIM_FileSystem class representing this particular file system.

## IBM\_BootOSFromFS

The IBM\_BootOSFromFS association class associates a file system with an operating system.

Property	Property value and data source
CIM_FileSystem REF Antecedent	The file system from which the operating system is loaded. Returns a reference to the CIM_FileSystem class.
IBMOS400_OperatingSystemREF Dependent	The operating system. Returns a reference to the IBMOS400_OperatingSystem class.

## IBMOS400\_NWPortImplementsIPEndpoint

The IBMOS400\_NWPortImplementsIPEndpoint association class associates a logical port with a protocol endpoint.

Property	Property value and data source
CIM_NetworkPort REF Antecedent	The network port that represents the device behind the IP protocol endpoint. Returns a reference to the CIM_NetworkPort class.
IBM_IPProtocolEndpoint REF Dependent	The IPProtocolEndpoint implemented on the logical port. Returns a reference to the IBM_IPProtocolEndpoint class.

## Supported CIM metric classes

The following CIM classes have been implemented as IBM supplied providers to provide performance information:

- IBMOS400\_ColSrvMetricDefinition: a subclass of CIM\_BaseMetricDefinition
- IBMOS400\_ColSrvMetricValue: a subclass of CIM\_BaseMetricValue
- IBMOS400\_ColSrvMetricInstance: a subclass of CIM\_MetricInstance - association between metric definition and metric value classes or instances.
- IBMOS400\_ColSrvMetricDefForME: a subclass of CIM\_MetricDefForME - association between a managed element (resource) and metric definition class or instances.
- IBMOS400\_ColSrvMetricForME: a subclass of CIM\_MetricForME - association between a managed element (resource) and metric value class or instances.

**Note:** All instances of IBMOS400\_ColSrvMetricValue return volatile data; only current data is supported. Historical data is not supported this release.

For a list of the metrics supported in i5/OS, see i5/OS metrics. Also see the CIM class and instance MOF files. The class MOF file, IBMOS400\_ColSrvMetric.mof, and the instance MOF file, IBMOS400\_ColSrvMetricDefInstance.mof can be found in /QIBM/ProdData/OS400/CIM/Schemas/OS400/.

The following figure illustrates the relationship between the IBM extension classes, and the CIM base classes they extend:




Figure 9. CIM Classes extended by i5/OS metric classes

## i5/OS metrics

The i5/OS operating system supports the Common Management Model (CMM).



Table 88 describes the CMM metrics i5/OS supports:

Table 88. CMM metrics

Resource/Base CIM class	Metric
IBMOS400_OperatingSystem	<p><b>NumberOfUsers</b> Number of interactive jobs active during the sample interval</p> <p><b>NumberOfProcesses</b> Number of jobs active during the sample interval</p> <p><b>FreeVirtualMemory</b> Free space in system Auxiliary Storage Pool (ASP)</p> <p><b>FreePhysicalMemory</b> i5/OS always returns 0</p> <p><b>FreeSpaceInPagingFiles</b> Free space in system ASP</p> <p><b>PageInRate</b> Number of pages paged in per second in all pools</p> <p><b>OperationalStatus</b> i5/OS always returns OK</p> <p><b>UserModeTime</b> Total system CPU time used</p> <p><b>KernelModeTime</b> i5/OS always returns 0</p> <p><b>TotalCPUTime</b> Same as UserModeTime</p> <p><b>Internal view kernel mode percentage</b> i5/OS always returns 0</p> <p><b>InternalViewUserModePercentage</b> i5/OS always returns 0</p> <p><b>InternalViewTotalCPUPercentage</b> User mode percentage as seen from within the operating system</p> <p><b>InternalViewIdlePercentage</b> Idle percentage as seen from within the operating system</p> <p><b>CPUConsumptionIndex</b> CPU time used divided by CPU time which might have been used by this operating system.</p> <p><b>ExternalViewTotalCPUPercentage</b> External view CPU percentage</p> <p><b>ExternalViewUserModePercentage</b> External view user mode percentage</p> <p><b>ExternalViewKernelModePercentage</b> i5/OS always returns 0</p>

Table 88. CMM metrics (continued)

Resource/Base CIM class	Metric
IBMOS400_ComputerSystem	<p><b>PctPartitionDefinedCapacityUsed</b> System CPU time used as a percentage of configured capacity (the amount of CPU the logical partition is configured to use)</p> <p><b>ActiveVirtualProcessors</b> Average number of virtual processors active</p> <p><b>UnusedPartitionCPUCapacity</b> Reserved but unused capacity for this operating system container</p> <p><b>UnusedGlobalCPUCapacity</b> CPU time in milliseconds not used on global server level</p>
IBMOS400_Process	<p><b>KernelModeTime</b> i5/OS always returns 0</p> <p><b>UserModeTime</b> The CPU time used by the JOB (including all secondary threads)</p> <p><b>TotalCPUTime</b> Same as UserModeTime</p> <p><b>InternalViewKernelModePercentage</b> i5/OS always returns 0</p> <p><b>InternalViewUserModePercentage</b> Percentage value related to UserModeTime, the percentage the system CPUs were used for this process in user mode during the measurement interval.</p> <p><b>InternalViewTotalCPUPercentage</b> Percentage value related to TotalCPUTime</p> <p><b>ExternalViewTotalCPUPercentage</b> External view total CPU percentage</p> <p><b>ExternalViewUserModePercentage</b> External view user mode percentage</p> <p><b>ExternalViewKernelModePercentage</b> i5/OS always returns 0</p> <p><b>AccumulatedKernelModeTime</b> i5/OS always returns 0</p> <p><b>AccumulatedUserModeTime</b> CPU time in user mode spent for this process since process creation</p> <p><b>AccumulatedTotalCPUTime</b> CPU time spent for this process since process creation</p>
IBMOS400_Processor	<p><b>TotalCPUTimePercentage</b> The time a virtual processor was used as a percentage of the elapsed interval time.</p>
IBMOS400_NetworkPort	<p><b>BytesTransmitted</b> The total number of bytes transmitted, including framing characters.</p> <p><b>BytesReceived</b> The total number of bytes received, including framing characters.</p> <p><b>ErrorRate</b> Number of network errors per second</p>

## i5/OS support for the CIM indication provider

You can use the CIM metric indication provider to notify applications when a specific metric event occurs.

The CIM indication provider notifies user applications when specified metric data occurs on the server which the provider supervises. Each application must subscribe to the provider by providing, in query form, information about an event about which it wants data. An *event* is an occurrence of a phenomenon of interest. Examples of events are occurrences such as authentication failures, disk-write errors, or even mouse click. The provider then notifies the application when the event occurs. Such an occurrence is called an *Indication*. When metrics match client-submitted queries, the indication provider creates the indication and returns it to the client.

**Important:** The metric indication provider only accepts queries which filter on either the InstanceId or the MetricDefinitionId properties. The provider rejects empty filters or a filter which provides only properties other than these two.

The QYCP\_ColSrvMetricIndicationProvider C++ class is the main class involved in handling indications for metrics. The indication provider defines the following methods:

CIM provider types and operations	Description
enableIndications	Called when the provider is expected to begin generating indications.
createSubscription	Tells the provider to monitor for indications matching the specified subscription.
modifySubscription	Informs the provider that the specified subscription instance has changed.
deleteSubscription	Informs the provider to stop monitoring for indications matching the specified subscription.
disableIndications	Tells the provider not to generate any more indications.

### Related information

 [The Open Group: CIMIndicationProvider documentation](#)

## Troubleshooting the operating system CIM server

Use this information if the CIM server does not start or if the CIM server starts, but does not run as expected.

### The CIM server does not start

If the CIM server does not start, follow these steps:

1. Ensure that the correct options and product are installed on your system.  
Error CPDDF80 with reason code 07 indicates that the required option 39 is not installed. You need to install International Components for Unicode (ICU), i5/OS option 39.
2. Ensure that the CIM server is configured correctly. Verify whether you need to change your Kerberos configuration or change the CIM server to use basic authentication.

Error CPDDF82 indicates an error with your authentication.

CPDDF82: (Message appears in CIM server, QYCMCIMOM, joblog)  
PGS02000: The CIM server authentication handler for Kerberos failed to initialize properly. The CIM server is not started.

You need to fix your authentication or use another form of authentication, such as basic authentication. But use basic authentication only when you have a highly secure environment where passing clear text passwords is not an issue.

To use the cimconfig command to change your CIM configuration settings, you must have QSHELL (option 30) installed on the system.

To change the authorization to basic, type the following command at a command line.

```
qsh
cd / QIBM/UserData/OS400/CIM
cimconfig -shttpAuthType=Basic -p
```

## The CIM server does not run as expected

If you have trouble with the CIM server, follow these steps:

1. Check whether the CIM server is running.  
Type WRKACTJOB JOB(QUMECIMOM) at a command line. If no active job is running, type the STRTCPSVR \*CIMOM command to start a server.
2. Check whether the CIMOM repository is corrupted.  
Verify whether the repository directory and configuration files exist in the /QIBM/UserData/OS400/CIM directory of the integrated file system. If any of these files are missing, restore all the repository directories and files from your backup. If a backup does not exist, follow the instructions in "Restoring corrupted files" on page 25.  
You must use a backup of those files from the Pegasus V2.5 backup, not from an i5/OS V5R3 operating system that does not have the Pegasus V2.5 PTFs installed.
3. Verify whether you are attempting to process a request when the provider is not registered or enabled.
  - a. Type cimprovider -l -s to list the name and status of the registered provider modules.
  - b. Type cimprovider -l-m *module-name* to see the individual providers in that module.
4. Check the job log file.
  - a. Type WRKACTJOB at a command line.
  - b. Find the QYCMCIMOM job in the QSYSWRK subsystem.
  - c. Select 5 (Work with), and then type 10 (Display job log, if active, on job queue, or pending).
  - d. If the QYCMCIMOM job is not running, type WRKJOB QYCMCIMOM.
  - e. Select the most recent job by typing 1 (Select) next to it.
  - f. If the status is OUTQ, type 4 (Work with spooled files), and then type 5 (Display) next to the QPJOBLOG file.

## Message CPDDF82 appears in the CIM Server (QYCMCIMOM) job log

Message CPDDF82 might appear in the CIM Server (QYCMCIMOM) job log during server startup.

CPDDF82:

```
The Common Information Model Object Manager (CIMOM) server
logged an error or warning message. The message text is: SSL Exception:
PGS12425: WARNING: THE SSL FUNCTION IS NOT SUPPORTED AT THIS TIME. SSL HAS
BEEN DISABLED. TO REMOVE THIS MESSAGE, SET THE ENABLEHTTPSCONNECTION AND
ENABLESLEXPORTCLIENTVERIFICATION PROPERTIES TO FALSE. USE THE CIMCONFIG
COMMAND TO SET THESE PROPERTIES
```

Although SSL is configured by default, it is not yet supported. Therefore, you might see this message in the job log.

To remove message CPDDF82 from the CIM Server job log (QYCMCIMOM), use the following command:

**Note:** To use this command, you must have Qshell Interpreter (5722-SS1 Option 30) installed on your system.

```
qsh
cd /QIBM/UserData/OS400/CIM
cimconfig -s enableHttpsConnection=false -p
cimconfig -s enableSSLExportClientVerification=false -p
```

### Related concepts

“Setting the required configuration parameters” on page 103




Before starting the operating system CIM server, you need to set several configuration properties using the **cimconfig** command.

---


## Related information for Common Information Model

Listed here are the Web sites and information center topics that relate to the Common Information Model topic.

### Web sites

- Web-Based Enterprise Management (WBEM)(<http://www.dmtf.org/standards/wbem>)   
The site is the official home of the Web-Based Enterprise Management (WBEM) Initiative.
- Common Information Model: Introduction to CIM(<http://www.wbemsolutions.com/tutorials/CIM/cim.html>)   
This site provides a tutorial of CIM.
- The Open Group: OpenPegasus (<http://www.openpegasus.org>)   
This is the OpenPegasus home page.

### Other information


- Network authentication service
- Host name resolution considerations
- Managing keytab files
- Backing up your system
- Digital Certificate Manager (DCM)
- Common Information Model 

### Saving PDF files

To save a PDF on your workstation for viewing or printing:

1. Right-click the PDF in your browser (right-click the link above).
2. Click the option that saves the PDF locally.
3. Navigate to the directory in which you want to save the PDF.
4. Click **Save**.

### Downloading Adobe Reader

- | You need Adobe Reader installed on your system to view or print these PDFs. You can download a free copy from the Adobe Web site ([www.adobe.com/products/acrobat/readstep.html](http://www.adobe.com/products/acrobat/readstep.html)) .



---

## Appendix. Notices

This information was developed for products and services offered in the U.S.A.

IBM may not offer the products, services, or features discussed in this document in other countries. Consult your local IBM representative for information on the products and services currently available in your area. Any reference to an IBM product, program, or service is not intended to state or imply that only that IBM product, program, or service may be used. Any functionally equivalent product, program, or service that does not infringe any IBM intellectual property right may be used instead. However, it is the user's responsibility to evaluate and verify the operation of any non-IBM product, program, or service.

IBM may have patents or pending patent applications covering subject matter described in this document. The furnishing of this document does not grant you any license to these patents. You can send license inquiries, in writing, to:

IBM Director of Licensing  
IBM Corporation  
North Castle Drive  
Armonk, NY 10504-1785  
U.S.A.

For license inquiries regarding double-byte (DBCS) information, contact the IBM Intellectual Property Department in your country or send inquiries, in writing, to:

IBM World Trade Asia Corporation  
Licensing  
2-31 Roppongi 3-chome, Minato-ku  
Tokyo 106-0032, Japan

**The following paragraph does not apply to the United Kingdom or any other country where such provisions are inconsistent with local law:** INTERNATIONAL BUSINESS MACHINES CORPORATION PROVIDES THIS PUBLICATION "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF NON-INFRINGEMENT, MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. Some states do not allow disclaimer of express or implied warranties in certain transactions, therefore, this statement may not apply to you.

This information could include technical inaccuracies or typographical errors. Changes are periodically made to the information herein; these changes will be incorporated in new editions of the publication. IBM may make improvements and/or changes in the product(s) and/or the program(s) described in this publication at any time without notice.

Any references in this information to non-IBM Web sites are provided for convenience only and do not in any manner serve as an endorsement of those Web sites. The materials at those Web sites are not part of the materials for this IBM product and use of those Web sites is at your own risk.

IBM may use or distribute any of the information you supply in any way it believes appropriate without incurring any obligation to you.

Licensees of this program who wish to have information about it for the purpose of enabling: (i) the exchange of information between independently created programs and other programs (including this one) and (ii) the mutual use of the information which has been exchanged, should contact:

IBM Corporation

Software Interoperability Coordinator, Department YBWA  
3605 Highway 52 N  
Rochester, MN 55901  
U.S.A.

Such information may be available, subject to appropriate terms and conditions, including in some cases, payment of a fee.

- | The licensed program described in this information and all licensed material available for it are provided
- | by IBM under terms of the IBM Customer Agreement, IBM International Program License Agreement,
- | IBM License Agreement for Machine Code, or any equivalent agreement between us.

Some parts of this document were included from the web site [openpegasus.org](http://openpegasus.org).

Copyright (c) 2000, 2001, 2002 BMC Software; Hewlett-Packard Development Company, L. P.; IBM Corp.; The Open Group; Tivoli Systems. Copyright (c) 2003 BMC Software; Hewlett-Packard Development Company, L. P.; IBM Corp.; EMC Corporation; The Open Group. Copyright (c) 2004 BMC Software; Hewlett-Packard Development Company, L. P.; IBM Corp.; EMC Corporation; VERITAS Software Corporation; The Open Group. Copyright (c) 2005 Hewlett-Packard Development Company, L.P.; IBM Corp. EMC Corporation; VERITAS Software Corporation; The Open Group.

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

THE ABOVE COPYRIGHT NOTICE AND THIS PERMISSION NOTICE SHALL BE INCLUDED IN ALL COPIES OR SUBSTANTIAL PORTIONS OF THE SOFTWARE. THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL THE AUTHORS OR COPYRIGHT HOLDERS BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION.

Information concerning non-IBM products was obtained from the suppliers of those products, their published announcements or other publicly available sources. IBM has not tested those products and cannot confirm the accuracy of performance, compatibility or any other claims related to non-IBM products. Questions on the capabilities of non-IBM products should be addressed to the suppliers of those products.

#### COPYRIGHT LICENSE:

This information contains sample application programs in source language, which illustrate programming techniques on various operating platforms. You may copy, modify, and distribute these sample programs in any form without payment to IBM, for the purposes of developing, using, marketing or distributing application programs conforming to the application programming interface for the operating platform for which the sample programs are written. These examples have not been thoroughly tested under all conditions. IBM, therefore, cannot guarantee or imply reliability, serviceability, or function of these programs.

Each copy or any portion of these sample programs or any derivative work, must include a copyright notice as follows:

© (your company name) (year). Portions of this code are derived from IBM Corp. Sample Programs. © Copyright IBM Corp. \_enter the year or years\_. All rights reserved.

If you are viewing this information softcopy, the photographs and color illustrations may not appear.



---

## Programming interface information

This Common Information Model publication documents intended Programming Interfaces that allow the customer to write programs to obtain the services of IBM i5/OS.

---

## Trademarks

The following terms are trademarks of International Business Machines Corporation in the United States, other countries, or both:

- | i5/OS
- | IBM
- | IBM logo
- | iSeries
- | PowerPC
- | System i

Adobe, Acrobat, Portable Document Format (PDF), and PostScript are either registered trademarks or trademarks of Adobe Systems Incorporated in the United States, other countries, or both.

UNIX is a registered trademark of The Open Group in the United States and other countries.

Other company, product, or service names may be trademarks or service marks of others.

---

## Terms and conditions

Permissions for the use of these publications is granted subject to the following terms and conditions.

**Personal Use:** You may reproduce these publications for your personal, noncommercial use provided that all proprietary notices are preserved. You may not distribute, display or make derivative works of these publications, or any portion thereof, without the express consent of IBM.

**Commercial Use:** You may reproduce, distribute and display these publications solely within your enterprise provided that all proprietary notices are preserved. You may not make derivative works of these publications, or reproduce, distribute or display these publications or any portion thereof outside your enterprise, without the express consent of IBM.

Except as expressly granted in this permission, no other permissions, licenses or rights are granted, either express or implied, to the publications or any information, data, software or other intellectual property contained therein.

IBM reserves the right to withdraw the permissions granted herein whenever, in its discretion, the use of the publications is detrimental to its interest or, as determined by IBM, the above instructions are not being properly followed.

You may not download, export or re-export this information except in full compliance with all applicable laws and regulations, including all United States export laws and regulations.

IBM MAKES NO GUARANTEE ABOUT THE CONTENT OF THESE PUBLICATIONS. THE PUBLICATIONS ARE PROVIDED "AS-IS" AND WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING BUT NOT LIMITED TO IMPLIED WARRANTIES OF MERCHANTABILITY, NON-INFRINGEMENT, AND FITNESS FOR A PARTICULAR PURPOSE.







Printed in USA