



€





Attention

IMPORTANTES INFORMATIONS DE SÉCURITÉ

situatponnvantpue5.6(nr)-6(d)5.

Ce symbole d'avertissement indique un dangerp eous vous vSGtrouvezdangs vSGune

Aviso



Figure 2 *Cisco Unified IP Phone 7912G Cable Connections*

- | | | | |
|----------|--------------------------|----------|--|
| 1 | Network port (10/100 SW) | 4 | DC Adaptor port (DC48V) |
| 2 | Access port (10/100 PC) | 5 | Cisco-supplied power supply (optional) |
| 3 | Handset port | | |

An Overview of Your Phone

The Cisco Unified IP Phones 7905G and 7912G support:

- Voice communication over a data network
- Familiar telephony features to handle calls easily
- Special features to extend and customize your call-handling capabilities
- Online control from your User Options web pages
- Access to network data and services

Understanding Buttons and Hardware

Basic Call Handling

This section covers basic call-ha

4To end a call, hang up the handset or press 24

Tips

- When on-hook transfer is enabled, you can either hang up or press

Starting or Joining a Standard Conference Call

Some of the conference features in the table below might not be available to you depending on how your system administrator configured your phone.

Tips

- Engaging the Hold feature generates music or a beeping tone. For this reason, avoid putting a conference call on hold.
-

Understanding Shared Lines

Your system administrator might give you a “shared” line. Shared line features do not apply to standard, unshared lines. Typically, a shared line has two main uses:

-

Tips

-



Using Voice Messaging, Call Logs, and Directories

This section describes how you can access voice messages, call logs, and directories.

Accessing Voice Messages

Using Corporate Directory on Your Phone


You can use a corporate directory to place calls to coworkers.

Tip

Use the numbers on your keypad to enter character

Configuring Features and Services on the Web

The topics in this section describe how to configur



You can use Cisco Unified CallManager Address Book Synchronizer to synchronize your existing Microsoft Windows Address Book (if applicable) with your PAB. Entries from your Microsoft Windows Address Book will then be accessible on your

Controlling User Settings on the Web

User settings include your password, PIN, and locale (language) settings.

Log out of WebDialer Click the logout icon in the Make Call or Hang Up page.

Set up, view, or change WebDialer preferences Access the Preferences page.

The Preferences page appears the first time that you use WebDialer (after you click the number that you want to dial.)

To return to Preferences in the futu

Understanding Additional Configuration Options

Your system administrator can configure your phone to use specific button and softkey templates along with special services and features, if appropriate. The table below provides an overview of some

Replacement, Repair, or Refund Policy for Hardware

Cisco or its service center will use commercially reasonable efforts to ship a replacement part within ten (10) working days after receipt of a Return Materials Authorization (RMA) request. Actual

