



€





Avvertenza IMPORTANTI ISTRUZIONI SULLA SICUREZZA

Questo simbolo di avvertenza indica un pericolo. La situazione potrebbe

Warning!

Aviso

□



Adjusting the Handset Rest

When you connect your phone, you might want to adjust the handset rest to ensure that the receiver will not slip out of the cradle. See the table below for instructions.

Registering with TAPS

After your phone is connected to the network, your system administrator might ask you to auto-register your phone using TAPS (Tool for Auto

Understanding Feature Availability

The operation of your Cisco Unified IP Phone and

Basic Call Handling

This section covers basic call-handling tasks such as placing, answering, transferring, and conferencing calls. The features you use to perform these tasks are standard and available on most phone systems.

Placing a Call


Answering a Call

Ending a Call

Using Hold and Resume







Only one call can be active at any given time; all other calls must be placed on hold.

Using Voice Messaging

Use the Messages button  to access your voice messages as outlined in the table below.

Configuring Features on the Web

The topics in this section describe how to config

If you want to...	Then do this after you log in...
Change your PIN	<ol style="list-style-type: none"> 1. Choose  > . 2. In the Phone PIN area, enter information. 3. Click .
Change the locale (language) for your User Options pages	<ol style="list-style-type: none"> 1. Choose  > . 2. In the User Locale area of the User Settings page, choose an item from the Locale drop-down list. 3. Click .

Replacement, Repair, or Refund Policy for Hardware
Cisco or its service center will use commercially reason

